#### BELOW ARE THE DIFFERENT SECTIONS THAT WILL APPEAR IN THE INDEX:

- A) SORTED BY PRODUCT NAME (CURRENT AND ARCHIVABLE ITEMS):
  THIS INDEX IS FOR THE USER WHO IS
  RUNNING ARCHIVABLE SOFTWARE. IT WILL
  LIST, IN THE ORDER IN WHICH THEY SHOULD
  APPEAR IN THE LIBRARY, ALL CURRENT AND
  ARCHIVABLE PRODUCTS.
- B) SORTED BY PRODUCT NAME (CURRENT ITEMS ONLY): THIS INDEX IS FOR THE USER WHO IS RUNNING ALL CURRENT SOFTWARE ANY ITEMS NO LONGER LISTED WOULD BE OBSOLETE.
- C) SORTED BY PART NUMBER: THIS WILL GIVE YOU THE ABILITY TO LOOK UP A INDIVIDUAL FART NUMBER AND FIND THE LOCATION (OR LOCATIONS) OF IT IN THE LIBRARY,
- D) SORTED BY TITLE OF MANUAL:
  THIS WILL GIVE YOU THE ABILITY
  TO LOOK UP A MANUAL BY THE TITLE
  AND FIND THE LOCATION (OR LOCATIONS)
  UF IT THE LIBRARY.

WHEN YOU RECEIVE NEW UPDATES TO BE PLACED INTO YOUR LIBRARY REFER TO THE INDEX WHICH WOULD APPLY TO YOU (EITHER ARCHIVABLE OR CURRENT SOFTWAKE) AND PLACE THEM IN THE ORDER THEY APPEAR ON THE INDEX. TO FIND NEW ITEMS EASILY REFER TO THE 'DATE' COLUMN AND ALL ITEMS WHICH HAVE THE SAME DATE THAT IS ON THE HEADER OF THE TITLE STRIP ARE THE ONES THAT YOU WOULD BE RECEIVING.

EXAMPLE: YOU RECEIVE 'INDEX 83-JUN'

YOU WOULD REFER TO ANY ITEMS THAT HAVE
"JUN 83" IN THE DATE COLUMN, THESE ARE THE
ITEMS YOU WILL BE PLACING INTO YOU LIBRARY.

ALSO, INCLUDED ON THE INDEX WILL BE THE NEW ITEMS FOR THE UPCOMING MONTH. THE 'NUMBER OF THE FICHE' COLUMN WILL BE BLANK AND THE 'DATE' COLUMN WILL REFLECT THE MONTH YOU SHOULD BE RECEIVING THE FICHE.

IF YOU HAVE ANY PROBLEMS, QUESTIONS, OR SUGGESTIONS FLEASE WRITE TO:

DIGITAL EQUIPMENT CURP. CONTINENTAL BOULEVARD MERRIMACK, NH 03054

ATTN: DEBBIE DUSLING MA1-2/N34

# COLUR CODING FOR

# FEBRUARY 1984 RSX-11H/RSX-11H-PLUS/RSX-11S LIBRARY

RSX-11H	V4.1	LT. BLUE	0.1628
RSX-11M-PLUS	V2.1	FLAIN	9K500
RCX-11S	V4.1	GRAY	0.3642
BASIC+2 FOR RSX-11M/M+,PDP-11	V2.1.2.2	GREEN	QJ918
BCP	V1.0	WHITE	QJS05
CKR11/CHV11 SDFTWARE DRIVER	V1.0.3.0	GRAY	0J928
COBOL-81/RSX	V2.0	BEIGE	QJ994
COMM ICE-DUP	V1.0	BROWN	0.373401
COMM IGP-DZ	V1.0	PLAIN	QJ733CD
CORAL-66, PDP-11	V4.0	YELLOW	QP066
DATATRIEVE-11	V3.0	ORANGE	QF301
DBHS-11	V2.0,2.1	FINK	QF376
DECNET-11H	V3,1,4.0	RED	QJ684
DPH	V4,1	BLUE	QJ651
DT07-11H	V1.1	LY. BLUE	UJ925
DX/11H	V3.1	PURPLE	QJ704CD
FMS-11/RSX	V1.0	WHTTE	QJ715
FORTRAN IV/RSX	V2.6	GRAY	· 0P230
FORTRAN-77 DEBUG, PDP-11	V1.0	BROWN	QP232
FORTRAN-77/RSX, PIP-11	V5.0	REIGE	87978
IEC-11H	V3.0	YELLOW	QJS02
KHC-11 TOOLS	V1.0	RED	0.163311
KHV11-A HDLC FRAHING SOFTWARE	V1.0	PINK	QJ\$32
LSP-11	V1.2	PLAIN	QJ724AD
MUX200/RSX-IAS	V2.1	URANGE	03070
OBSERVER	V1.0,1.1	YELLOW	QSF40
PASCAL/RSX, PDP-11	V1.0,1.1	GRAY	QJ128
PDP-11 COROL	V4.1.4.4	BROWN	QF012
PLXY-11H	V1.1.1.3	GRAY	0JS90
PRO HOST COMMUNICATIONS	V1.5:1.7	GREEN	
PRO HOST TOOL KIT	V1.0	LT. GREFN	QBA14
PRO TOOL KIT BASIC-PLUS-2	V2.1.2.2	WHITE	QJ073
PRO TOOL KIT COBOL-81	V2.0	yellow	Q9A19
PRO TOOL KIT DIBOL	V1.0,1.6	RE1GE	QBA16
PRO TOOL KIT FORTRAN-77	V5.0	BRAY	QJ074
PRO TOOL KIT FORTRAN-77/UBG	V1.0	LT. BLUE	QBA21
PRO HOST TOOL KIT PASCAL	V1.1	ORANGE	QBA18
RGL/11	V1.1	BROWN	QJ123
RSX-11 2780/3780 EMULATOR	V4.1	PURPLE	0JD82
RSX-11 PSI/H	V2.0	PLUE	0.0191
RSX-11/PROVUE	V2.0	GRAY	03983
RSX-11H/3271 PROTOCOL EMULATOR	V3.0	GREEN	
RSX-11H/FORTAN ENHANC PKG HINC	V1.1,1.2	YELLUW	QJV43
RSX-11H/IAS RJE/HASP	V1.1	GREEN	03860
RSX-11H SNA PE	V1.1	GRAY	0.1069
RSX DLX-11	V1.0	WHITE	0.1687
RSX MDE/T11	V1.0	FLUE	0JA62
RTEH-11	V1.1.2.0	GREEN	0J291
SORT-11	V2.0	PINK	RP602

SSP-11	V1.3	RED	QJ962AD
UN1004/RSX	V2.0	ORANGE	0J170
VSV11-M DRIVER	V2+0	YELLOW	QJ\$27
VTV31-K RSX-11M DRIVE & SUB	PK6 V1.0	WHITE	QJ\$84

OPERATING SYSTEM	PRUDUCT • NAME	FITLE OF HANUAL	VERSION	PART NUABEC REV LEVEL	NUMBER OF FICHE	PATC
≱RSX į	RSX-11h	RSX-11M/RSX-11S RELEASE NUTES	4.1	AA-2573H-10-001	2	NOV 83
*RSX	RSX-11M	RSX-11H/11S INFORMATION DIRECTORY/INDEX	4.1	AA-25936-70-001	4	MOV 83
*RSX	RSX-11M	RSX-11M GUIDE TO WRITING AN I/O DRIVER	4.1	AA-2600E-TC-001	73	MOV 83
*RSX	RSX-11M	IAS/RSX-11 SYSTEM LIX ROUTINE REF MANUAL	4.1	AA-5580R-+0-001	2	HOV 83
*RSX	RSX-11H	RSX-11 SYS GENERATION AND INSTALLATION ODE	4.1	AA-H625C-TL-001	5	NOV 83
RSX *	RSX-11H	EDT EDITOR MANUAL	4.1	AA-J <sup>7</sup> 26A-10-001	3	NOV 83
*RSX	RSX-11M	RMS-11 PROGRAMMERS MANUAL	4.1	AA-L668A-[L-00]	5	MUV 83
*RSX	RSX-11M	RMS-11 USER'S GUIDE	4.1	AA-L669A-10-001	2	MUV 82
*RSX	RSX-11M	RMS-11 UTILITIES MANUAL	4.1	AA-L670A-51-001	3	NOV 83
*RSX	RSX-11M	RSX-11H/M-PLUS BATCH AND QUEUE OPERATIONS MAN	4.1	AA-L6/1A-TC-001	2	400-53
*RSX	RSX-11H	RSX-11M/M-PEUS COMMAND LANGUAGE MANUAL	4.1	AA-L6728-TU-091	£	MON 83
*RSX	RSX-11H	RSX-11H/H+ CRASH DUMF ANZ HEF MANUAL	4.1	AA-L6738-1U-001	į	NOO 33
*RSX	RSX-11H	RSX-11M/M-PLUS ERROR LOGGING MANUAL	4.1	AA-L574B-TL-001	3	NUV 83
*RSX	RSX-11M	RSX-11M/M PLUS EXECUTIVE REFERENCE MANUAL	4 - 1	AA-L675A-1E-(0)1	A	40V 33
*RSX	RSX-11H	RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L6/6A-TL-001	2	N3, 83
*RSX	RSX-11M	RSX-11H/H+ 1/O DRIVERS REF MAN (UPD41)	4.1	AA-L67 'A-TE-001	6	ND4 53
*RSX	RSX-11H	RSX-11M/M+ MCR OPERATIONS MANUAL (UFD+1)	4.1	AA-L5 'UA-11 -001	5	NUV 22
₩RSX	RSX-11fi	RSX-11M/M+ SYSTEM MANAGEMENT GDE (UPD41)	4.1	AA-L67/F-11-001	c	म्यूग, २३
*RSX	RSX-11H	RSX-11H/M-FLUS TASK BLDE MANUAL (UP(#1)	4,1	AA-ES808-1E-01.	5	NU. 93
WRSX	RSX-11H	RSX-11H/M-FLUS UTILITIES MANUAL (UFIRE)	4.1	AA-L681A-+L .01	٥	4(1) (
*RSX	RSX-11H	RMS-11: AN INTRODUCTION	1.1	AA-165./A- (1	1	MJ 33
*RSX	RSX-11H	INTRODUCTION TO RSX-11H AND RSX-11H-FLUS	4.1	All Line in the		411, 21
*RSX	RSx-11M	IAS/RSX-11 1/U OPERATIONS REFERENCE MANUAL	4.1	An 41 "		11 2
*RSX	RSX-11N	ENT ENTIOR MANUAL	2 ,	pa nalka-th-in,	1	rit it

OPERATING	PRODUCT	11TLE OF		HAR MUMBER MEN	NUMBER OF	
SYSTEM	NAME	- MANUAL	VERSION	LEVEL	FILHL	iroJE
*RSX,	RSX-11H	EDI DUICK REFERENCE MANUAL	4.1	AA-8477A-15-001	Year I	FLU 84
*RSX	RSX-11M	TAS/RSX-11 UNI REFERENCE MANUAL	4.1	AA-#50/A-10-001	1	NU9 82
⇒ <b>≇RSX</b>	RSX-11M	PDP-11 MACRU-11 LANGUAGE REF MANUAL	4.1	AA-V02/A-TC-001	3	KB VUN
* VRSX	RSX-11H	RSX-11M V4.1 SPN 14.35.20	4.1	AE-340/U-10-001	i	FEP 84
*RSX	RSX-11M	RSX-11M V4.1 SP0 14.32.21	4+1	AE-3407V-FC-001	1	HAY 84
WRSX	RSX-11H	RSX-11M CROSS REFERENCE TABLE	4.1	AE-#7/8F-10-001		JUL 54
#RSX	RSX-11M	RSX-11M MINI REFERENCE	4.1	AV-5570E- L-001	2	MDU 83
RSX	RSX-11M	EDT EDITUR REFERENCE CARD	4.1	AV-J/56A-10-001	1	MOV 83
*RSX	RSX-11M	PDP-11 PROGRAMMING CARD	4.1	EH-S1046-78-001	1	E8 V0M
*RSX	RSX-11M-PLUS	TAS/RSX-11 SYSTEM LIB RUUJINE REF MANUAL	2.1	AA-5580E-10-001	2	NOA 83
*RSX	RSX-11M-PLUS	RSX-11M-PLUS GUILLE TO WRITING 1/U DRIVER	2.1	AA-H2o/6-TC-001	4	NO7-83
WREX	RSX-11M-PLUS	RSX-11M-PLUS INFURMATION DIRECTORY AND INDEX	2.1	AA-H426L-TL-001	4	409 st
*RSX	RSX-11M-PLUS	RSX-11M-PLUS V2.1 RELEASE NOTES	2.1	AA-442/0-10-001	1	NOV 83
*RSX	RSX-11H-PLUS	RSX-11M-PLUS SYSTEM GEN/INSTALLATION GUILLE	2.1	AA-H431L-TU-001	\$	FB VUM
RSX	RSX-11M-PLUS	EDT EDITOR MANUAL	2.1	AA-J/26A-TC-001	3	NUV 03
*RSX	RSX-11M-PLUS	RMS-11 PROGRAMMERS MANUAL	2.1	AA-1668A-Tt-001	5.	NOV 83
*RSX	RSX-11M-PLUS	RMS-11 USER'S GUIDE	2.1	AA-L669A-10-001	2	NÚT OJ
#RSX	RSX-11M-PLUS	RMS-11 UTILITIES	2.1	AA-L6/0A-TC-001	Į.	MOV 83
*RSX	RSX-11M-PLUS	RSX-11M/M+ BATCH AND QUEUE OPER HANUAL	2.1	AA-L671A-16-001	3	NOV 83
*RSX	RSX-11M-PLUS	RSX-11M/M+ CUMMANI LANGUAGE MANUAL	2.1	AA-L6728-70-001	6	M60 63
*RSX	RSX-11M-PLUS	RSX-11M/N+ CRASH DUMP AND REF MANUAL	2.1	AA-L6738-FC-001	3	ES VUN
*RSX	RSX-11M-PLUS	RSX-11M/M-PLUS ERRUR LOGGING MANUAL	2.1	AA-Lo74P-TC-001	2	HQU 83
******	RSX-11M-PLUS	RSX-11M/M-PLUS EXECUTIVE REFERENCE MANUAL	2.1	AA-L6.'5A-f0-001	4	NOU 97
#RSX	RSX-11M-PLUS	RSX-11M/H+ GUIDE TO PROGRAM DEVELOPMENT	2.1	AA-E676A-10-001		N(III 03
*RSX	RSX-11M-PLUS	RSX-11M-M-PLUS 1/U DRIVERS REF MAN (UPD#1)	2.1	190-11-77 81-64	6	NUV 1:
*RSX	RSX-11H-PLUS	RSX-11M-H-PLUS MCR UF MANUAL (UP141)	7.1	AP-Lo '8A-1L=301	*,1	Mut =2

1 2 T

OPERATING SYSTEM	PRODUCT NAME	FITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11M-PLUS	RSX-11M-M-PLUS SYSTEM MANAGEMENT GDE (UPD#1)	2.1	AA-L6/98-10-001	É	N90 83
RSX	RSX-11H-PLUS	RSX-11M-M-PLUS TASK BUILDER MANUAL	2.1	AA-L6808-FC-001	5	E8 VON
*RSX	RSX-11M-PLUS	RSX-11H/H-PLUS UTILITIES MANUAL (UPB#1)	2.1	6A-L681A-TC-001	6	NOV 83
*RSX	RSX-11M-PLUS	RMS-11: AN INTRODUCTION	2.1	AA-L682A-10-001	1	NOV 93
*RSX	RSX-11M-PLUS	INTRODUCTION TO RSX-11H AND RSX-11H+	2.1	AA-L763A-TC-001	2	NOV 93
*RSX	RSX-11H-PLUS	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	2.1	AA-M176A-TC-001	3	MUA 83
*RSX	RSX-11M-FLUS	EDT EDITOR MANUAL	2.1	AA-H476A-TK-001	3	FEB 84
*RSX	RSX-11H-PLUS	EDT QUICK REFERENCE MANUAL	2.1	AA-8477A-1K-001	1	FLF 84
1RSX	RSX-11M-PLUS	IAS/RSX-11 ODT REFERENCE MANUAL	2.1.	AA-M507A-10-001	1	400 83
WRSX	RSX-11M-PLUS	PDP-11 MACRO-11 LANGUAGE REFERENCE HANUAL	2.1	AA-V027A-TU-001	3	MOV 83
**************************************	RSX-11M-PLUS	RSX-11M-PLUS V2.1 SPU 14.70.08	2.1	AE-H862I-TE-001	1	FEE 84
*RSX	RSX-11M-PLUS	RSX-11M-PLUS V2.1 SPN 14.70.09	2.1	AE-H8621-10-001		JUL 84
*RSX	RSX-11M-PLUS	RSX-11M-PLUS V2.1 CROSS REFERENCE SPD	2.1	AE-M7791-10-001	1	hay 84
*RSX	RSX-11M-PLUS	RSX-11M-PLUS MINI REFERENCE	2.1	AV-H435C-1C-001	3	NON 83
RSX	RSX-11M-PLUS	EDI EDITOR REFERENCE CAFD	2.1	AV-J756A-TC-001	1	NGV 83
*RSX	RSX-11M-PLUS	PDP-11 PROGRAMMING CARD	2.1	EH-S1046-78-001	1	NOV 83
*RSX	RSX-115	RSX-11M/RSX-11S RELEASE NOTES	4.1	AA-2573H-10-001	2	NU0 83
*RSX	RSX-11S	RSX-11M/RSX-11S INFORMATION DIRECTORY & INDEX	4.1	AA-25936-11-001	4	NON 83
*RSX	RSX-11S	RSX-11M GUIDE TO WRITING 1/O BRIVER	4,1	AA-2600E-FC-001	3	RU 83
#RSX	RSX-11S	RSX-115 SYS GEN/INSTL GDE (INCLUDES UF9#1)	4.1	AA-28/41-TE-001	2	HOV 83
WRSX	RSX-11S	IAS/RSX-11 SYS LIB ROUTINE REF MANUAL	4.1	AA-5586P-11-001	2	400 83
*RSX	RSX-11S	RSX-11H SYSTEM GENERATION/INSTALLATION GUIDE	4.1	AA-H625U-TU-001	i,	M(ii) 33
*RSX -	RSX-11S	RSX-11M/M+ CRASH DUMP ANZ REF HANUAL	4.1	AA-L6/3P-Tt-00	3	Milit Riz
*RSX	RSX-11S	RSX-11M/M-PLUS EXECUTIVE REFERENCE MANUAL	4,8	AA-L675A-:E-001	2	स्या) उर्
*RSX	RSX-115	RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-1676A-11 001	1 ~	Min 8 c
*RSX	RSX-115	RSX-11H/H+ 1/0 DIRVERS REF MANUAL (UP141)	4.1	fa-Lor 'a-IL-(a)	6	14(n) 87

Pade 4

~;			TITLE		PAL I NUMBER	HUMBE -	
	OPERATING SYSTEM	PRUDUCT NAME	OF HANUAL	VERSION	REV LEVEL	SICHE.	DATE
	*RSX	RSX-11S	RSX-11H/H-PLUS MCR OPERATIONS HANUAL (UFD41)	4 - 1	AA-L678A-T0-001	E .	NOV 83
	*RSX	RSX-11S	RSX-11H/H+ SYSTEM MANAGEMENT SUITE (UFU#1)	4.1	AA-L6798-T0-001	5	NDV 83
	*RSX	RSX-11S	RSX-11M/M-PLUS TASK BUILDER MANUAL	4.1	AA-L6808-TE-001	5	NO.2 83
	*PSX	RSX-11S	IAS/RSX-11 1/0 OPERATIONS REFERENCE MANUAL	4.1	AA-M176A-10-901	1	NOV 83
	*RSX	RSX-11S	IAS/RSX-I1 ODT REFERENCE MANUAL	4.1	AA-M507A-10-001	1	NOV 83
	*RSX	RSX-11S	PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	4.1	AA-9027A-10-001	3	HOU 83
	RSX	RSX-11S	RSX-11M/11S V4.1 UPDATE B INFORMATION	4.1	AA-W2598-TC-001	1	FEH 84
	*RSX	RSX-11S	RSX-11M/11S V4.1 UPNATE C INFORMATION	4.1	AA-82590-10-001	1	MAY 24
Q	¥RSX	RSX-11S	RSX-IIS V4.1 SPD 9.21.13	4.1	AE-3427N-TL-001	1	FEE 84
	*RSX	RSX-11S	RSX-11S V4.1 SPD 09.21.14	4.1	AE-34270-TU-001	1	PG1 E4
	*RSX	RSX-11S	RSX-11M MINI REFERENCE	4.1	AV-5570E-10-001	3	NOV 83
	*RSX	RSX-11S	PDP-11 PROGRAMMING CARD	4.1	EH-S1046-78-001	1	F9 464
- 3	*RSX	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	BASIC+2 RSX-11M/M-PLUS INSTL GDE/REL HUTES	2.1	AA-0158E-10-001	1	JAN 80
	*RSX	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	RASIC+2 RSX-11H/M-PLUS INSTL GDE/REL NOTES	2.2	AA-0158F-TC-001	1	MAY 54
	*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-Th-001	6	E8 39A
	*RSX	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	BASIC REFERENCE MANUAL (UFD#1)	2.2	AA-L334A-(N-002	5	MAY 84
	*RSX	BASIC-PLUS-2 FOR RSX-11M/K-PLUS	BASIC USER'S GUIDE	2.0-2.1	AA-L335A-1F-001	3	AFF 93
	*RSX	BASIC-PLUS-2 FOR RSX-11H/M-FLUS	BASIC USER'S GUIP'S (UFD#1)	2.2	AA-L335A-TN-002	\$	4A1 84
	*RSX	BASIC-PLUS-2 FOR RSX-IIM/M-PLUS	BASIC ON PSX-11H/h-PLUS SYSTEMS (UPD#1)	2.1	AA-1,338A-TE-001	3	JAN 84
	*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	DASIC 0": RSX-11h/H-PLUS SYSTEMS (UFD41 & \$2)	2+2	AA-L330A-11-002	!	wyl ha
	#RSX ·	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC-PLUS-2 V2.1 SPU 14.11.8	2.1	\$t-J1971-(c-001	1	FLr 81
	*KSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC-PLUS-2 V2.2 SFB 14.11.10	2.7	AE-J197K-11-J01	1	MAY 64
	*RSX	BASIC-PLUS-2 FOR RSX-I1H/H-PLUS	BASIC POCKET REFERENCE GUIDE	2,6-2,5	AU-LSAIR-IF-UNI	6 <sub>e</sub>	AP- ES
	RSX	BCF	RSX-11H BC: USER'S GUIDE	1.0	AA-8269A-1( 001	t be	The state
	tork	BCP	BCP USER'S GUIDE	1.0	AA-N2698-11-001		til a
	*RSX	BCP	BCF V1.0 SFD 14.72.0	1.0	AE-82024 L 001	1	FLE 24

	OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSIUN	PAFT NUMBEF PEV LEVEL	NUMBER OF CICHE	į lą T <b>L</b>
	*RSX	BCP	BCF VI.O RELEASE HOTES	1.0	AV-N2708-1U-001	1	A14 E3
4	RSX	CHR11/CHV11 SOFTWARE DRIVER	CMR11/CHV11 SOFTWARE DRIVER USERS BUIDE	1.0	AA: N960A-TL-001	1	APP E3
	*RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE	3.0	AA-NO60B-FC-001	1	FEB 84
	RSX	CHR11/CHV11 SOFTWARE DRIVER	CMR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	1.0	A4-N061A-TE-001	1	AFR 83
	≉RSX	CMR11/CMV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	3.0	AA-N061F-1L-001	1	FEE 84
	*RSX	CMR11/CMV11 SOFTWARE DRIVER	CHR11/CHV11 V3.0 SPN 14.76.01	3.0	AE-N0578-16-001	1	HAY BA
	RSX	CHR11/CHV11 SOFTWARE DRIVER	CMR11/CMV11 SOFTWARE DRIVER RELEASE MUTES	1.0	AS -N958A-16 (01	1	arr ei
	*RSX	CMR11/CMV11 SOFTWARE URIVER	CRN11/CHV11 SOFTWARE DRIVER RELEASE MOTES	3.0	AV-80188-11-001	1	FLE EA
	*RSX	COBOL-81/RSX	COBUL-81 LANGUAGE REFERENCE MANUAL	2.0	AA-J4348-16-001	4	JAH 14
	RRSX	COBOL-B1/RSX	RSX-11M/M-PLUS USER'S GUIDE	2.0	AA m1/98-10-001	ני	JAN E4
	*RSX	COBOL-81/RSX	RSX-11M/M-PLUS INSTALLATION/RELEASE NOTES	2.0	AF-#1811-TC-001	1	18 MAL
	*RSX	COPOL-81/RS%	COROL-81 RSX 92.0 SFD 14.26.03	2.0	AE-+47/E-10-001	1	fel 34
	*RSX	COBOL-81/RSX	CUBOL-81 POCKET GUIDE	2.0	AV H6300-11-001	2	144 84
	*RSX	COMM IOP-DUP	CONN TOF-DUF FROGRAMMER'S HANUAL	1.0	AA-5670A-10-001	1	ELF 82
	*RSX	CONH TOP-DUP	COMM TOP-DUP RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-11367A-11 001	1	5EF 82
	*RSX	COMM IOP-DUP	ADDENDUM 10 SPU	1.0	AE-8827A-1K-001	1	MAY 84
	*RSX	COMM TOP-DUP	COMM 10F-DUF V1.0 SPD 10.12.2	1.0	AE-1/12/0-10-001		JUL 54
	*RSX	COMM TOP-DZ	CONH TOT DZ FROBRANHER'S MANUAL	1.0	AA-512/A-10-001	1	SE1 82
	*RSX	COMM IOP-DZ	COMM TOP-DZ RELEASE NOTES (INCLUDES UPD11)	1.0	AA-8368A-16:001	1	SE+ 82
	*RSX	COMM TOP-DZ	ADDENDUM 10 SFD	1 0	65-1427A-16-601		N_ 84
	*RSX	CONN IOP-DZ	COMM 10F-DZ V1.0 SP0 10-11-2	1.0	Ac [1226-16-00]		300, 84
	*RSX	CORAL-66	PDF-11 CORAL-66 V4.0 INSIL GDE/FEL NUTES	4,0	AA-1744L-IL-001	1	F14 67
	*RSX	CORAL-66	CORAL-66 LANGUAGE REFERENCE MANUAL	4.0	AA-[1]][-])		nf ( C.
	*RSX	CORAL-66	RSX/VMS CORAL-66 USER'S GUDE	4,(1	A4-(-1111-1+	å	414 5:
	*RSX	CORAL-66	CORAL-66 04.0 SPD 13.56.10	4.0	AL BASOL HE WE	•	Mr. 84
	*RSX	DATATRIEVE-11	DATAIRIEVE-11 REFERENCE MANUAL	I.J	use - Highlift- It - 1 1	t	· [ + · 4

OPERATING SYSTEM		DUCT Me	TITLE OF MANUAL	VERSION	PAST NUMBER REV LEVEL	NUMBER UF • LLHE	141£
*RSX	DATATRIEVE-11	n ic.	DATATRIEVE-11 CALL INTESFACE MANUAL	3.0	AA-U050A-(E-001		JAN 84
→ <b>*</b> RSX	DATATRIEVE-11		DATATRIEVE-11 GUIDE TO WRITING REPORTS	3.0	6A-U051A- K-U01		FEE E4
231	*						
*RSX	DATATRIEVE-11		DATATRIEVE-11 SUMMARY DESCRIPTION	3.0	AA-U052A-10-001		JAN 54
#RSX	DATATRIEVE-11		DATATRIEVE-11 INSTALLATION ODE/REL NOTES	3.0	AA-X022A-11-001	1	394 J4
*R5X	DATATRIEVE-11		DHTATRIEVE-11 USER'S GUIDE	3.0	AA-X02JA-FN-001	3	FEE It's
*RSX	DATATRIEVE-11		INTRODUCTION TO DATATRIEVE-11	3.0	44-X0254-Tr-001	1	EFR Av
*RSX	DATATRIEVE-11		DATATRIEVE-11 POCKET GUIDE	3.0	4A-X103A-1+-00,	1	FEB Ba
*RSX	DATATRIEVE-11		PATATRIEVE-11 V3.0 SPD 12.48.11	3.0	AE-L///L-11-001	1	may 34
*RSX	DBMS-11		DBHS-11/H+ DDL/DEVICE HEDIA CON LANS REF MAN	2.0-2.1	AA-HENAR-(L-90	3	SER 82
<b>\$</b> ₹€X	DBMS-11		DRMS-11 DATA BASE ADMINISTRATOR'S (UPA) GUIDE	2.0-2.1	AA-HE058-10-1111	4	SLF 82
*RSX	DBMS-11		DBMS11 FORTRAN DATA MANIFULATION LANG PEF MAN	2.0-2.1	4A-1883R-1U-001	2	SEF 82
#RSX	DBMS-11		DRMS11 COROL DATA MANIPULATION LANG REF MAN	2,0-2,1	46-18848-11-001	)	SEF 82
#RSX	DBMS-11		DBMS-11 INSTALLATION GUIDE	2.0-2.1	46-K885R-TL 861	2	der 8
*RSX	DBHS-11		DBMS-11 V2.0 RELEASE NOTES	2.0-2.1	AA-N8568-10-00	1	SEF #3
*RSX	DBMS-11		USING THE NATATRIEVE-11/DBMS-11 INTEFFACE	2.0-2.1	AA-888 'B (I )01	1	err Ro
*RSX	DBMS-11		DBMS-11 V2.1 SPD 12.66.2	2.1	AE-M1300-10-001		FEB 82
*RSX	DB#S-11		BEFORE YOU INSTALL DUAS-11 V2.1	2.1	AV-P666A-TL-001	1	AFF 33
*RSX	DECHET-11H		RSX DECNET GUIDE TO USEK UTILITIES	1 - 1	AA-H2238-1(-()	6	rr B 84
*RSX	DECNET-11H		RSX DECNET GOIDE TO USER UTILITIES	4.0	Ar-H2230-10 003	da.	ns. 84
*RSX	DECNET-11M		RSX DECNET SYSTEM MANAGER'S GUIDE	4.1	AA-H2:48-TL-,601	E 3	FEE E4
≉RSX	DECNET-11H		RSX DECNET SYSTEM MANAGER'S GUIDE	4.(	An-H2,4(-1 /01	5	PA1 51
*RSX	DECNET-11H		RSX DECNET HETWORK GEN AND INSTERNATION	3.3	\$\$\$ \{\begin{align*} \( \begin{align*} \\ \\ \end{align*} \\ \end{align*} \\ \end{align*} \]	£	t F the a
*RSX	DECNET-11M		RSX DECNET NETWORK GEN AND INSTALLATION OUTDL	4.0	AA-4-1 - 1 -17 ]	4	MAT 14
¥RSX	DECNET-11H		INTRODUCTION TO DECHET	1.1	$\xi : \xi = i \ell_1 \rho_1 \cdot \xi = i \cdot \varphi = \delta i \cdot \ell \cdot \ell$	,	· in th
*RSX	DECNET-11H		INTRODUCTION TO DECNET	4,0	AC-J(" 1 1 = 1	į.	M1 1
#RSX	DETINET-11H		RSX DECNET POST-INSTE CHECKUUT FRUCEDURES	1.1	AA-J1101-11	4-	b } å

OFERATING SYSTEM		PRODUCT NAME	TITLE OF MANUAL	WESTON	FAFT NUMBER MEU LEVEL	ICHE De Miniber	[100   1
<b>‡</b> RSX	DECNET-11H		RSX DECNET POST-INSTL CHECKOUT PROCEDURES	4.0	AA-J319L-11-00.	1 6	nu 34
#RSX	DECNET-11H		RSX DECNET RELEASE NOTES	7.1	AA-J51/B-10-(01	1	*[] : 4
#RSX	DECNET-11M		RSX DECNET RELEASE NOTES	4,0	AA-3517L-1L-011	1	F11 8"
#RSX	DECNET-11H		OVERVIEW OF RSX DECNET	3.1	AA-m9964-10-901	2	<u> १८५</u> सर्
#RSX	DECNET-11H		OVERVIEW OF RSX DECNET	4.0	AA-M0968-TE-001	2	MAI EA
*RSX	DECNET-11M		RSX-DECNET REFERENCE GULDE	3.1	AA-MAY/A-11-061	1	FEE 84
			RSX DECNET PROGRAMMER'S REF MANUAL	4.1	AA-MQY8A-(1-00)	c	FEE: 94
*RSX	DECNET-IIH						
*RSX	DECNET-11M		RSX DECNET PROGRAMMER'S PEFERENCE MANUAL	4,3	86-40685-1(-60)		MAI 54
*RSX	DECNET-11H		OVERVIEW TO DIGITAL NUMBER PROCEDURES	1.0	AA-Y10'JA-TX-001	be	46. AJ
#RSX	DECNET-11H		VOLUME I GENERAL INFORMATION	4.0	\$\$-{V}\$		JUL 84
#RSX	DECNET-11h		VOLUME II USER'S INFORMATION	4.0	AA-XU_1)A-16-12		11 84
*RSX	DECNET-11M		VOLUME III GENZINSTALLATION INFURMATION	4.0	64-4921A-11 001		IC. 94
*R'SX	DECNET-11H		VOLUME IN SYSTEM MANAGEMENT INFORMATION	4.0	AA-1922A-10-001		JUL 34
PESX	DECNET-11H		DECNET RSX SYSTEM MANGER'S MINT REF SULLIE	4.0	PA 1924A-11-001	1	PS YAM
*RSX	DECNET-11H		DECNET-11M V4.0 SPD 10.75.10	4.0	AE 34318-10-001	1	MAT 84
BRSX	DECNET-11H		DECNET-RSX VULUME II USER'S INFORMATION	4.0	AV-1553A-16-001		PS JUL
*RSX	DPM		DPM/DPM+ DECDATA INTELL SUDS USES GDE (UPD#1)	4.1	AA-J5298-11-001	3	18 432
<b>PR</b> 3X	DPM		DEN/DENT TERMIAND USER'S GUIDE (UP) (1)	4,1	AA-J5301-11-001	4.	-Ft. 85
#RISS	DPH		DEN/DPH+ SYSTEM GENERALLUN/MANAGEMENT 3DE	4,1	AA-15111-Fi-(11)	2	SEF 81
v. 1.	DPH		PPH/DPH PLUS RELEASE NOTES	4,1	(0-N150A-11-10)	A	SEL 65
*RSX	DPM		DPH V4.1 SPB 15.6.6	4,1	AE-57104-11-001	1	OCF 91
*RSX	DPH		DPH/DPH PLUS REFERENCE GUIDE	4.1	40-41959-16-99		-(r -2
*RSX	0T07-11H		BEON 'IN VI.1 USEN S GUIDE	1.1	ea-rest -11-nat		(1)
#RSX	P107-11H		D107-11H V1.1 SPB 14.36.1	1.1	9F-+214b-+1-001	1	:11 3:
#RSX	DX/11m		DX FRODUCTS PROGRAMMEN S REFERENCE MANUAL	3.1	A3-54691, -11 00,	1	261 (1)
*RSX	BX/11M		DX PRODUCTS DRESS GRIDE	1.1	M 4 Sp 16 - M;	1	nen 3

PART TITLE NUMBER NUMBER 85 PRODUCT OF REV **OPERATING** F1CHE HANUAL VERSION LEVEL PATE SYSTEM NAME DX/11M INSTALLATION GUIDE 1.1 AA-D99/A-TC-001 1 APR 83 DX/11H **SRSX** APR B3 DX/11M VERSION 3.1 RELEASE NOTES AA-H288B-IC-001 1 DX/11H 3.1 \*RSX AE-5274F-10-001 1 DX/11H DX/11M V3.1 SPD 10.96.4 3.1 FEB 84 **BRSX** DX/11H ADDENDUM TO SPO 3.1 AE-BB27A-TK-001 JUL 84 ERSX PDP11 KEYPAD EDITOR USER'S GDE (UPD#1) AA-H853A-TC-001 2 RSX FMS-11/RSX 1.0 SEF 82 FMS-11/RSX11M SOFTWARE REF MANUAL (UPIM1) 1.0 AA-H855A-TC-001 3 SEF 82 \*RSX FMS-11/RSX FMS-11/RSX-11M RELEASE NOTES AA-H857A-IC-001 1 SEF 82 FHS-11/RSX 1.0 TRSX PDP11 KEYPAD EDITOR RELEASE NOTES AA-J692A-TC-001 1 SEF 82 FMS-11/RSX 1.0 PRSX FMS-11/RSX V1.0 SPD 12.27.5 1.0 AE-J405F-TC-001 1 FEB 84 \*RSX FMS-11/RSX FMS-11/RSX V1.0 SPU 12.27.07 1.0 AE-J405H- (C-001 JUL SA FMS-11/RSX arsx BRSX FMS-11/RSX PDP11 KEYPAD EDITOR RECERENCE CARD 1.0 AV-H854A-TC-001 1 SEF 82 SEF 82 BRSX FMS-11/RSX FHS-11/RSX-11M MINI REFERENCE GUIDE 1.0 AU-H856A-TL-001 1 RRSX FORTRAM IV/RSX PDF-11 FORTRAN LANGUAGE REFERENCE MANUAL 2.6 AA-R953A-TK-001 2 JAN 84 FORTRAN IV/RSX RSX/VMS FORTRAN IV INSTALLATION/REL NIS AA-F954A-1K-001 1 2AN 94 ERSX 2.6 \*RSX FORTRAM IV/RSX KSX/VAX/VMS FORTRAN IV USER'S GUIDE 2.6 AA-R955A-TK-001 2 JAN 84 RSX FORTRAN 14/RSX FORTRAN 19/RSX V2.6 SPB 14.63.9 2.0 AE-3443J-1(-001 1 FER 84 FORTRAN IU/RSX FORTRAN 1V/RSX V2.6 SPD 14.63.10 AE-3443h-10-001 1 MA1 84 **RRSX** 2.6 **BRSX** FORTRAN-77 DEBUG, PDF-11 PDP-11 FORTRAN-77/DEBUG USER'S GUIDE 1.0 AA-V197A-11-001 2 19N 84 FORTRAN-77 DEBUG, PDF-11 FORTRAN-77/DEBUG INSTAL GUIDE/REL NUTES AA-Y650A-TK-00, 1 JAN 84 \*RSX 1.0 **SRSX** FORTRAM-77 DEBUG, PDF-11 P'A-11 FORTHAN-77 BEEUG J1.0 SPE 30.33.00 1,0 AE-13988-15-001 1 FER EA AA- 41474 - 15 -001 3 **BRSX** FORTRAN-77/RSX, PDF-11 PDP-11 FORTRAN-7/ LANGUAGE REFERENCE MANUAL 5.0 FEF 814 **RSX** FORTRAN-77/RSX, PUP-11 PDF-11 FORTRAN-77 USER'S GUIDE 5.0 4A-0174A-15-001 3 FEB 84 AA-Ullyboth olds PBP-11 FORTRAN-7/ OTS REFERENCE MANUAL 1 FF 34 FORTRAN-77/RSX, PDF-11 5.0 #RSX FORTRAN-77/RSX, PPF-11 PDF-11 FORTRAN-/7 INSIL GUIDE/REL HOTE. 5.0 AA-9196A 11-001 1 144 64 **BRSX** FORTRAN-77/RSX, PDF-11 46-31395-TE-00: 1 FL 64 #RSX PDP-11 FORTRAN-77/PSX V5.0 SPI 14.31.06 5,1 AT - 1100-11 de FORTRAN-77/RSX, PHF-11 PDF-11 FOFTHAN-77/RSX Vt.C SPD 14,21,07 5.4 M., T . 14 **BRSX** 

CAL NUMPER NUMBEL TITLE 05 REV **OPERATING PRODUCT** OF SYSTEM NAME MANUAL **UERSIEN** LEVEL FILHE PATE IEC-11h RSX SOFTWARE MANUAL SE# 82 AA-M275A-TE-001 1 **2RSX** IEC-11H 3.0 SKSX IEC-11M IEC-118 V3.0 SPU 14.64.0 3.0 AE-N029A-10-001 1 FEB 84 **\$RSX** TEC-11M RELEASE NOTES 3.0 AV-V507A-TE-001 1 Ftt. 84 TEC-11M BRSX KMC-11 TOOLS KMC11 PRUGRANMER'S MANUAL 1.0 AA-5244B-1L-001 2 SEF 82 KMC-11 TOOLS KMC-11 TOULS VI.D SED 12.49.04 1.0 AE-0776E-F0~001 1 MAY BA BRSX APP 83 RRSX KHV11-A HILL FRANCIS SOFTWARE KNV11-A HULC FRAMING SETWARE FOR MSX MET MAN 1.0 AA-N565A-7C-001 1 KHV11A-HDEC FRAHING SOFTWARE VI.O SPE 14.22.0 1.0 AE-R298A-TC-001 1 FEP 84 KNV11-A HOLC FRAMING SOFTWARE #KSX SEP 82 LABORATORY SUB PROGRAMMER'S REF MAN (UPD41) AA-E984C-1C-001 1 **BRSX** LABORATORY SUBROUTINE PACKAGE 1.7 ERSX LABORATORY SUBROUTINE PACKAGE ADDENDUH TO SPD 1.2 AL-BE2/A-IN-001 JUL 34 **SKSX** LABORATORY SUBROUTINE PACKAGE LSP V1.2 SPR 15.44.5 AE-#607E-1E-001 1 FEH HA 1.2 RSX LABORATORY SUBROUTINE PACKAGE LSP V1.2 SPD 15.44.06 1.2 AE-86076-FL-001 1 MA1 84 1.3 MUX200/RSX-IAS MUX200/RSX-IAS V2.1 RELEASE MOTES 2.1 AA-1343C-TC-U01 JAN 84 NUX200/RSX-IAS MUX200/RSX-IAS SYSTEH MANAGER GUIDE 2.1 AA-13440-10-001 2 JAtr 84 **BRSX** MUX200/RSX-IAS USER'S GUIDE 2.1 AA-1346E-10-001 1 JAN 84 WUX200/RSX-IAS **\$RSX** NUX200/RSX-IAS HUX200/RSX-IAS V2.1 SP# 10.77.07 2.1 AL-34531-11-001 1 FER 34 ERSX RSX OBSERVER ORSERVER INSTE GUIDE AND GEN GUIDE AA-N959A-1E-001 1 AFR 83 1.0 ERSX **OBSERVER** DBSERVER INSTL GUIDE AND GEN GUIDE 1.1 AA-N9598-TL-001 1 FEB 84 RSX **OBSERVER** ORSERVER USER'S GUIDE 1.0 AA-N960A-TE-001 3 AFE 83 RRSX OBSERVER OBSERVER USER'S GUIDE 1.1 AA-N960B-TC-001 3 FEB 84 AFR 83 OBSERVER OBSERVER RELEASE NOTES AA-N962A-1E-001 1 RSX 1.0 #RSX OBSERVER RELEASE NOTES 1.1 AA-NY62B-TE-001 1 FE8 84 OBSERVER PRSX OBSERVER V1.1 SPP 13.18.02 AE-P335E-11-001 1 MAI BA OBSERVER 1.1 **2RSX** OBSERVER OBSERVER REFERENCE CARD 1.1 AV-X073A-TL-001 FEB 84 RSX OBSERVER ORSERVER EVENT MESSAGE REFERENCE MANUAL 1.1 AV->0/4A-1L-001 JUL BA RSX PASCAL/RSX, PDF-11 PDP-11 PASCAL LANGUAGE REFERENCE MANUAL 1.0 A6-4875A-10-001 JAN 84 EKSX PASCAL/RSX, PDP-11 PDP-11 PASCAL LANGUAGE REF MANUAL (UP:141) AA-ME LA-11-002 1 48 414

	1 2			FART		
UPERATING	PRODUCT	TITLE OF	HE INCTION	NUMBER	NUMBER UI	
SYSTE	NAME	MANUAL	VERSION	LEVEL	FICHE	DATE
RSX	PASCAL/RSX, PDP-11	PDF-11 PASCAL USER'S GUIDE	1.0	AA-MU7EA-16-001	2	JAN 81
*RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL USER'S GUIDE (UFD#1)	1.1	AA-M876A-10-002	2	FLB 84
RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL INSTALLATION GDE/REL NUTES	1.0	AA-H877A-TL-001	1	JAN 84
*RSX	PASCAL/RSX, PDP-11	POF-11 PASCAL INSTALLATION GUE/REL NOTES	1.1	AA-H8778-10-001	1	HAY 84
#RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL/RSX V1.1 SPD 14.18.02	1.1	AE-N917C-16-001	1	FEB 84
*RSX	PASCAL/RSX, FDP-11	PDF-11 PASCAL/RSX V1.1 SPD 14.18.03	1.1	AE-N9171- 10-001	1	MAY 84
*RSX	PDP-11 COBOL	PDP-11 COROL INSTALLTION GUIDE	4.4	AB-1745F-(U-QO)	1	SEP 82
*RSX	PDP-11 COROL	PIP11 COROL LANG REF MANUAL (UPIR1 8 12)	4.4	AA-1749E-10-001	3	SEH 82
*RSX	PDP-11 C080L	PDP-11 COBOL USER'S GUIDE (INCLUDES UPD#1)	4.4	An-175/U-TU-001	5	SEP 82
*RSX	PDP-11 COBOL	PDF-11 COBOL V4.4 SFU 12.40.13	4.4	AE-34179-10-001	1	FEP 94
*RSX	PLXY-11H	PLXY-11 V1.1 USER'S GUIDE	1.1	AA-J5354-TN-001	1	3EH 85
*RSX	PLXY-11H	PLXY-11 USER'S GUIDE	1.3	AA-J535E-IN-001	1	MAY 84
*RSX	PLXY-11M	PLXY-11 V1.3 SP# 14.39.01	1.3	4E-K7978-FE-001	1	MAY 81
*RSX	PRO TOOL KIT FORTRAN-77 DBG	PRO TOOL KIT FORTKAN-77/LIBG IG/DOC SUPL	1.0	AA-2384A-1K-001	1	MAY 84
*RSX	PRO TOOL KIT FORTRAN-77 DBG	FRO TOOL KIT FURTRAN-77/DBG V1.0 SPØ 40,25.00	1.0	AE-2847A-TH-001		JUL 84
WRSX	PROFESSIONAL HOST CONHUNICATIONS	PROFESSIONAL HOST COMM INSTL PROCEDURES	1.5	AA-P412P-TK-001	1	JAN 84
*RSX	PROFESSIONAL HUST COMMUNICATIONS	PROFESSIONAL HUST COMM INSTL PROCEDURES	1.7	AA-P41.C TK-001	1	MAY 84
*RSX	PROFESSIONAL HOST TOOL KIT	FMS-11/RSX SOFTWARE REFERENCE MANUAL	1.0	AA-HESSA-TC-901	3	APR 93
*RSX	PROFESSIONAL HOST (OOL KIT	FMS-11/RSX RELEASE NOTES	1.0	AA-H85/A-TC-001	1	AFR 83
#RSX	PROFESSIONAL HOST TOOL KIT	RSX/RMS USER'S GUIDE	1.0	AA-L669A-11-001	2	MAY 54
*RSX	PROFESSIONAL HOST TOUL KIT	RSX-11M/M-PLUS RMS-11 UTILITIES MANUAL	1.0	AA-L670A-TU-001	3	MAY 84
*RSX	PROFESSIONAL HOST TOOL KIT	RSX-11M/M-FLUS TASK BUILDER MANUAL	1.0	AA-L680R-11-001	L.	JAN 84
*RSX	PROFESSIONAL HOST TOOL KIT	IAS/RSX-11 ODT REFERENCE MANUAL	1.0	AA-M507A-TC-001	1	AP1 83
*RSX	PROFESSIONAL HOST TOOL KIT	TOOL KIT DOCUMENTATION DIRECTORY	1.0	AA-M6154:-TN-001	1	Jest 84
*RSX	PROFESSIONAL HOST TOOL KIT	TOOL KIT DOCUMENATION DIRECTORY	1.0	AA-M615C-11-001	1	H41 81
RSX	PROFESSIONAL HOST TOOL KIT	PRO TOOL KIT INSTE GOE/REL NIS	1.0	A4-45161- F-001	1	JAN 84

						rAf.1		
005041100		DOODUICT		FITLE UF		NEWBE?	NUMBER	
OPERATING SYSTEM		PRODUCT NAME		nanual	VERS1UM	TEAFT	· ICHE	BAIL
*RSX	PROFESSIONAL	HOST TOOL	KIT	TOOL KIT USER'S GUIDE	1.0	AA-M51/C-FE-901	t	MAY 94
#RSX	PROFESSIONAL	HOST TOOL	KIT	CORE GRAPHICS LIBRARY MANUAL	1.6	AA-MEISA-TK-001	-	Ark 83
arsx	PROFESSIONAL	HOST TOOL	KIT	CORE GRAPHICS LIBRARY MANUAL	1.0	AA-N619E-Th-001	2	MAY 84
*RSX	PROFESSIONAL	HOST TUOL	K11	P/CS SYSTEM REFERENCE MANUAL	1.0	AA-N620A-1F-001	4	APR 83
*RSX	PROFESSIONAL	HOST TOOL	KIT	P/OS SYSTEM REFERENCE MANUAL (UPU\$2)	1.0	AA-N620A-FN-002		JUL 94
RRSX	PROFESSIONAL	HOST TOOL	KII	DOCUMENTATION GUIDE LINES	1.0	AA-N621A-11-001	1	AFK 23
*RSX	PROFESSIONAL	HOST TOOL	KIT	TERMINAL SUBSYSTEM MANUAL	1.0	AA- NG23B-11-001	2	JAN 84
TRSX	PROFESSIONAL PROFESSIONAL	HOST TOOL	KIT	PRO/RMS-11: AN INTRODUCTION	1.0	AA-F9886-17,-901	1 4	APR 83
*RSX	PROFESSIONAL	HOST TOOL	KIT	PRO/RMS-11 MACKO PROGRAMMEN'S GUIDE	1.0	44-6004-18-001	¢ _	APP 81
*RSX	PROFESSIONAL	HOST TOOL	KIT	PRO/FMS-11 DOCUMENTATION SUPPLEMENT	i.0	AA-F103R-18-001	1	JAN 84
*RSX	PROFESSIONAL	HOST TOOL	KIT	IAS/RSX ODT REFERENCE MANUAL SUPPLEMENT	1.0	4A-F193E-FN-001	1	Jihn 94
*RSX	PROFESSIONAL	HOST TOOL	KII	PUP-11 MACKU-11 LANGUAGE REFERENCE MANUAL	1.0	94-V02 3-11-001	2	JAN E4
*RSX	PROFESSIONAL	HOST TOOL	KIT	PRO/1006 KIT DOCUMENATION DIRECTORY	1.0	WE KAICH-IH-GOI		PUL 34
*RSX	PROFESSIONAL	HOST TOOL	KIT	PRO/TOOL KIT INSTALLATION GDE/RELEASE MOTES	1.0	44-4011#-TH-(01		₩ <u>.</u> 94
*RSX	PROFESSIONAL	HOST TOOL	KIT	PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL	1.0	AA-YY1ZA-TH-001		JUL 134
#RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC REFERENCE HANUAL	7.0-2.1	AA-1334A-1K-00;	£	AFF 33
*RSX	PROFESSIONAL	TOOL NIT	BASIC-PLUS-2	BASIC REFERENCE MANUAL (UFT \$1)	2,2	AA-1334A 11-601		JLL 84
#RSX	PROFESSIONAL	TOOL KIT	RASIC-FLUS-2	BASIC USER'S GUIDE	2.0-2.1	AA-13754-18-01	1	96r 81
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC USER'S GUIDE (UPU41)	17 7	47-1351A-11 (11)		TW 81
*RSX	PROFESSIONAL	100L KIT !	BASIC-FLUS-2	BASIC UN NSX-11H/M-FLUS SYSTEMS UFD#1)	2.1	AV-FIZAN- 1-NO	1	अस हव
#RSX	PROFESSIONAL	TOOL KIT	BASIC-FLUS-2	BASIC ON RSX-11H/H-PLUS SYSTEMS (LFD#1)	2.	AA-1338A-1 00.		JUL 84
*RSX	PROFESSIONAL	190L KIT !	RASIC-FLUS-2	BASIC-PLUS-2 DUCUMENTATION SUPPLEMENT	2.1	instant 10 ml - the coll	1	204 64
#RSX	PROFESSIONAL	TOOL KIT	BASIC-FLUS-2	BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	B B b	$\hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s_{\theta} & \\ \end{array} \right] \hat{\mathcal{L}}_{\theta, s_{\theta}}^{A} = \left[ \begin{array}{cc} s$	1	eal ga
RRSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	PRO 1001 NIT BASIC + 2 INSIL GRE FEL MIL	j , g	Bert Olf is all il		F 18 124
*RSX	PROFESSIONAL	FOOL KIT	BASIC-FLUS-2	PRU TOUL NIT BASIC-PLUS-2 92.2 SPD ( . 17.2	3 - P do: 9 - 9	A - 1 e State - in .	1	ph. r 25
#RSX	PROFESSIONAL	100L KIT !	BASIC-FLUS-2	PASIC POCKET REFERENCE GUITE	1111 - 11	$y \in \{1\} \mapsto m_1$		\$ - \$ - \$

						PARI		
OPERATING SYSTEM		PRODUCT NAME		TETLE OF HANUAL	UEPS10N	NUMBER REV LEVEL	4048LF 0- -1+HE	[sps   E
*RSX	PROFESSIONAL	TOOL KIT O	COROL-81	COBOL-81 LANGUAGE FEFERENCE HANUAL	\$ 6m P m	AA-14349-TE-CO1		JUL 84
*RSX	PROFESSIONAL	TOOL KIT C	OFOL-81	RSX-11H/H-PLUS USER'S GUIDE	2.1	AA-m1/9R-TC-001		9UL 84
*RSX	PROFESSIONAL	TOOL KIT O	COBOL-81	PRO 1001 KII CUBOL-8: INSTE GIE/DOL SUFL	2.1	44-72854-14-001		JU- 84
*RSX	PROFESSIONAL	T00L KIT C	COBOL-81	COBOL-81 FUCKET 601DE	2.1	AV-8630L-10-001		JUL 64
*RSX	PROFESSIONAL	TOOL KIT I	DIBOL	INTRODUCTION TO DIROL	1.0-1.6	AA-F042A-TN-001	1	AF4 83
RSX	PROFESSIONAL	TOOL KIT I	IBOL	PROFESSIONAL TOOL KI, WIRDL USER'S GUIFE	1.0	AA-F043A-1F-001		aPP 83
*RSX	PROFESSIONAL	TOOL KIT I	DIBOL	PROFESSIONAL TOOL KIT DIROL USER'S GUIDE	1.0	AA-F043C-IX-001	des	MH7 84
RSX	PROFESSIONAL	TOOL KIT D	) I ROL	PROFESSIONAL TOOL NIT DIBOL LANG REF MANUAL	1,0	enthagant in	<u> </u>	Her Ai
RSX	PROFESSIONAL	TOOL KIT D	OTBOL	PROFESSIONAL 100L KIT DIBOL MEL MISTINSTE GIE	1.0	AA 1(444-F) 001	1	AFF 83
*RSX	PROFESSIONAL	TOOL KIT I	IROL	PROFESSIONAL TOOL HIT DISOL HEL HIS/INSTE GHE	1.6	$\hat{\mu}_{i,k}^{(k)} = \mathbb{E}\left(i\mathbf{A}_{i,k}^{(k)}, \dots, \kappa - \underline{\ell}\right) \epsilon_{i} \epsilon_{i}^{(k)}$	1	nai ,14
#RSX	PROFESSIONAL	TOOL KIT I	DIBOL	DIBOL-83 LANGUAGE REFERENCE MANUAL (UFD41)	1.6	As Justa Provide	e de	F'' L'4
RSX	PROFESSIONAL	TOOL KIT I	IBOL	DIBOL LANGUAGE REFERENCE CAMP	1.5	AA-(Kit-A-(K K)	1	1A) 94
*RSX	PROFESSIONAL	100L KIT I	IBOL	BIBOL-83 COMPATIBILITY MANUAL	1.6	AA-VUIGE-IE OCI		MG: 34
*RSX	PROFESSIONAL	TOOL KIT I	IROL	PRU 100L NIT MESSAGE MANUAL	1.5	AA515a-(1-001	1	tfi ha
≇RSX	PROFESSIONAL	TOOL KIT E	DIBOL	DIROL-83 LANGUAGE REFERENCE CARD	1.4	** \- ( ) A * \( ( ) = ( ) \);		JU 94
*RSX	PROFESSIONAL	TOOL KIT F	FORTRAN-77	PRO HOS1 TK :-77 16/000 SUPL	e , (j	34-178/H-11-1(1)	Į.	11 64
*RSX	PROFESSIONAL	TOOL KIT F	ORTRAN-77	PDP-11 F-77 LANGUAGE REFERENCE MANUAL	1,1	AA-17.6-18 mil	1	· E# 14
*RSX	PROFESSIONAL	100L KIT F	FURTRAN-77	PIF-11 FORTKAN-77 USER & GUILLE	C1 , 4	14-11-40-11-401		544 6
#RSX	PROFESSIONAL	TOOL KIT F	FURTRAN-77	PDF-11 FORTRAN-7/ DTS REFERENCE MENUAL	5.0	4A-,1, f 1; (n)1		1211 5.
*RSX	PROFESSIONAL	TOOL KIT F	ORTHAN-77	PRO 100L K11 FORTHAN-77 95.0 SER 30.381	· , ()	\$\$ W <sup>4</sup> 12 W 13 1		دمه
*RSX	PROFESSIONAL	TOOL KIT F	PASCAL	PRO FOOL KIT PASCAL INSTLUMENT NOTE:	1.	81 - S - D		h., f.
#RSX	PROFESSIONAL	TOOL KIT F	PASCAL	FRO 100L KIT FAUCAL USER & 6010c		( s) = ( ) ( a		1.
\$RSX	PROFESSIONAL	100L H.II F	PASCAL	PRO 1000 KII PASCAL LANGUAGE REFERENCE MENUAL	1,1	6,0		30
*R3X	PROFESSIONAL	100L NIF F	PASCAL	PRO 1001 : 11 PASIAL 71.1 EPU 10.55.0		M   1   2   2   1		_ 1
#RSX	RGL-11			RGL-11 PROGRAMMEN & PEFE ENCE MANUAL	۵	n /4 s		1
*RSX	RGL-11			RGL-11 INCIALLATION COULD	•	4 Mil 1 1		a final and a

OPERATING	PRODUCT	πε 111Γε		b langer blanker	ile Hilmret	
SYSTEM	NAME	HANUAL	NEEP104	LEGEL	P II II	Ifpe f a
RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AG-MB306-11-60.	1	4 1 1
*RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	44-4830h-10-60)	1	127 34
#RSX	R6L-11	RGL-11 V1.1 SPD 14.52.3	1.1	4F-4805[1-1(-00]	1	ret (14
*RSX	RGL-11	RGL-11 V1-1 SPI 14-62-04	1.1	AE-4802E-10-001	1	MAY 84
<b>ERSX</b>	RSX 11 2780/3780 EMULATOR	RSX-11 2780/3780 EMULATOR USER'S GUIDE	47 + 1	AA-3581A - (L-0/ 1	1	St b 85
*RSX	RSX 11 2780/3780 ENULATOR	RSX11 2780/3780 EHUL V4.1 SEU 10.01.01	4.1	AE-1907F-11-003	1	ME 1 84
*RSX	RSX 11 PS1/M	INTRODUCTION TO RSX-11 PSI	4.0	AA-#369A-11 001	1	5£F 82
*RSX	RSX 11 PSI/M	RSX-11 PSI SYSTEM MANAGER'S GUILLE	2.0	Ginna Trade ( - m)	1	FF 32
*RSX	RSX 11 PSI/M	RSX-11 PSI USER'S GUIUE	2.0	A4-43/14-11 00:	-	SE = 3.
<b>ERS</b> X	RSX 11 PSI/M	RSX-11 PS1 GENERATION GUIDE	2.0	AA-H37_A- (L-(())		SEE HJ
*RSX	RSX 11 PSI/h	RSX-11 PS1 NETWORK SPECIFIC INFORMATION	1.0	AG-#5/3A-TU-00.	1	75. RJ
*RSX	RSX 11 PSI/M	RSX-11 PSI RELEASE HOTES	2.0	\$\$ - m 1 7 4 5 - 1   1]	A	-FI. 63
*RSX	RSX I1 PSI/M	RSX-11 PSI/M U2.0 SPD 10.42.0	1.0	V2 -4:11[-1[-1]	1	ref 34
*RSX	RSX 11 PSI/M	RSX-11 PS1 REFERENCE CAPD	2.0	All-4-176-11-( )	1	CEL ST
*RSX -	RSX 11/PROVUE	PROVUE SYSTEM MANAGER'S GUIDE	2,0	AP-M0218-Fe OC.	9	JAH Sa
*RSX	RSX 11/FROVUE	PRODUE SYSTEM BUILD MANUAL	2.0	##-40578-1x-001	1,	नुवस १४
*RSX	RSX 11/PRUVUE	PROVUE TERMINAL USER'S GUILLE	2,0	AA-40235-11-00	1	JA4 34
*RSX	RSX 11/PROVUE	PROVUE OFFLINE PICTURE SYSTEM MANUAL	2.6	AC-MOJAR-IP-NO	4	jan ya
*RSX	RSX 11/PROUUE	PROVUE UNLINE FICTURE SYSTEM MANUAL	2.0	91-MI) 58 14 991	q A	Jan 84
*RSX	RSX 11/FROYUE	PROVUE FROGRAMMING GUIDE	2.0	Appendig to the second		144 64
*RSX	RSX 11/PROVUE	PROVUE UTILITY GUIDE	(	Anama Lal al	1	14 84 B4
*RSX	RSX 11/PROYUE	PROVUE V2.0 RELEASE MOTES	()	AR MIN M ]		ES MES
*RSX	RSX 11/PROVUE	PROVUE V2.0 SPI 11.33.1	(	H2 10 10		121 - 1
*RSX	RSX 11H 3271 PROTOCOL EMULATOR	RSX-11/3271 FE FF06HAMBER'S of the	2.1	· · · · · · · · · · · · · · · · · · ·		2++
*RSX	RSX 11H 3271 PROTUCOL EHULATOR	RSX-11/32/1 PE SYSTEM MANAGER'S U-115.	• ,1	Visit A		
*RSX	RSX 11M 3271 PROTECUL EMULATOR	RSX-11-3271 PE HELEASE MOTES V3.0	3 , +	99 ] 1 n   1		11 1

			with the time				
		111/2		NINGE	AT PERSON		
OPERATING	PRODUCT	⊕F.		r.£	lj-	7. 4. 7.1	
SYSTEM	HAME	nanuál	NEE IGN	EILL	, 41E	11416	
*RSX	RSX 11M 3271 PROTOCOL EMULATOR	3270 FERMINAL EMULATOR KEYBOARD LATCE	24.	4. P1 A- 1-0	1	ter 11	
*RSX	RSX 11H F ENHANC PKG FUR HINC	SCIENTIFIC SUBFUUTINES PRUG REF HAN (UFT*1)	1.1-1.2	P(\$1-1-1-1)	-	Gr 2	
#RSX	RSX 11M F ENHANC PKG FOR HINC	LAE SUBFOUTINES PROG FEE MAY TUPD#1	1.1-1.2	20 0841-11 .	7	* * t t	
*RSX	RSX 11M F ENHANC PKG FOR MINC	REALISM/HNC FORTIFRAN PROG HEF MAN (UFU41:2)	1.1-1.2	44-14411- (-m)	4	1 2 2	
*RSX	RSX 11H F ENHANC PKG FOR HINC	INTRODUCTION TO FEE AND FPE	1.1-1.2	AA- 1102E-1 -001	1	A Exp. 11	
BRSX	RSX 11H F EkamaC FKG FOR HINC	RSX-11M FEP AND FRP INSTALLATION USES DE	1.2	AA-1303[1-1(- n]		wer - A	
#RSX	RSX 11H F ENHANC FKG FOR HINC	RELEASE NOTES FUR RSX-11m/FEF AM. 114	1	## # 15th-fr QC1	1	7 4 33	
*RSX	RSX 11H F ENHANC PKG FOR HINC	REAL/11 PROGRAMMER'S REFERENCE MANUAL	1.1=1	physical physical particles of the second se	1	1 - 1 43	
₹RSX	RSX 11M F ENHANC PKG FOR HINC	RSX-11M/FEP V1.2 SPD 14.44.4	1	å_ = [ ]		16. 24	
WRSX	RSX 11M F ENHANC PKG FOR MINC	RGL/11 PROGRAMMERS REFERENCE MANUAL ERRATA	1	# 11 12 nt 15 nt 1		24 34	
*RSX	RSX 11H F ENHANC FKG FOR HINC	REAL-11 PROGRAMMERS SEFERENCE MANUAL EFFATA	1.5	Ale to figure		15 11+	
*RSX	RSX 11H F ENHANC PKG FOR HINC	SSP REFERENCE MANUAL ERRATA SHLET	1.	An-11/160, 11 - 191		44 64	
*RSX	RSX 11H F ENHANC PKG FOR HINC	LSP REFERENCE MANUAL ERRATA SHEET	9 & E 6s-	** 1 * 31 ** 1 ** 1 ** 1 ** 1 ** 1 ** 1	1	JA 84	
PREX	RSX 11M F ENHANC PKG FOR MINC	INTRO TO FEP & FRO ERRATA SHEET	d + do	au 71915- ( )	1	124 52	
<b>‡</b> RSX	RSX 11M F ENHANC PKG FOR HINC	MICROCOMPUTERS AND MEMO-IES HANDPOOL	1. 1.0.			AF 63	
#RSX	RSX 11M F ENHANC PKG FOR HINC	PIF-11 MICROCOMPUTER INTERFACES HANDBOOM	1 . 1	EP-2144 (		1 L pr 10	
*RSX	RSX 11H F ENHANC PKG FOR HINC	DECLAR-11/MINC USER S GUITE	1.1 1.2	- MA - 1 + -11 + -1),		10 S S S S S S S S S S S S S S S S S S S	
#RSX	RSX 11M F ENHANC PKG FOR MINC	MINC THEFROCOUPLE PREAMPLIFIER USER 1 60116	1.1 1.2	FA-WHEIR- IE-		6 8	
*RSX	RSX 11H 1AS RUE/HASP	RUEZHASE WORKSTATION INJ ALLASION BUILD	1.1	A*- 14. (1 )	)	0 L p- tor	
*RSX	RSX 11M IAS RJE/HASP	RUE/HASP WORKSTATION OFERATOR'S GUIDE	1.1	Spi A. T.	7	£1 ·	
#RSX	RSX 11H 1AS RUE/HASP	PSX11B IAS RUE/HASP Ut.1 580 10.01.6		off to all the	1	116 -	
#RSX	RSX 11M SNA PE	RSX11H/SNA PE CONCEPTS AND FACILITIES (U. +1)	å 9 a	1119 mm		1.1	
*RSX	RSX 11H SNA PE	REXIIM/SNA PE SYSTEM MANAGEM'S GUIDE /URD#10	B A	A Distilled		į, t	
*RSX	RSX 11M SNA PE	RSX11M75NA PE AFFLICATIONS PROGRAMMER 2 CUITOL	1, 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		i h	
*RSX	RSX 11H SNA PE	RSXIIA/SHA PE PELEASE MUTES (UPIT)	4	AP 144		11.0	
*RSX	RSX 11M SHA PE	RSX 11M SNA PE VI.1 5FD 14.04.1	1.1	ئ، اِ اِ		-11 1	

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX DLX-11	RSX DLX-11 USER'S GUIDE	1.0	AA-K142A-TC-001	2	SEP 82
*RSX	RSX DLX-11	RSX INLA-11 RELEASE NOTES	1.0	AA-K143A-TC-001	1	SEP 82
≇RSX	RSX DLX-11	RSX DLX-11 V1.0 SPD 10.6.0	1.0	AE-K434B-TC-001	1	FER 84
*RSX	RSX HDE/T11	MDE/T-11 USER'S GDE/REF MANUAL	1.0	AA-M845R-TK-001	3	APR 83
#RSX	RSX HDE/T11	RSX11H/H+ HDE/T11 SFTW INSTL GDE/REL NTS	1.0	AA-N998A-TC-001	1	APR 83
#RSX	RSX HDE/T11	RSX MBE/T-11 V1.0 SPB 14.23.0	1.0	AE-F081F-10-001	1	FEB 84
*RSX	RSX HDE/T11	MDE/T11 REFERENCE CARD	1.0	AV-H846R-TK-001	1	FER 84
#RSX	RSX HDE/T11	MDE/1-11 V1.0 INSIL GBE/REL NIS	1.0	AV-F511A-TU-001	1	AFR 83
*RSX	RTEH-11	RTEH-11 USER'S MANUAL	1.1	AA-N435P-TK-001	2	JAN 84
*RSX	RTEH-11	RTEM-11 USER'S GUIDE	2.0	AA-N435C-TK-001	2	MAY 84
*RSX	RTEH-11	RTEM-11 INSTL GUIDE/RELEASE NOTES (UFD#1)	1.1	AA-H436A-FN-001	2	JAN 84
*RSX	RTEH-11	RTEM-11 INSTALLATION GUIDE	2.0	AA-N436B-TK-001	1	MAY 84
*RSX	RYEH-11	RTEM-11 RELEASE MOTES	2.0	AA-W325A-TK-001	1	HAY 84
*RSX	RTEH-11	RTEM-11 V2.0 SPD 30.21.04	2.0	-E-N571E-1K-001	1	MAY 84
*RSX	SOR (-11	PDP11 SORT REFERENCE MANUAL (UPDATE #1)	2.0	AA-3341C-TC-001	2	SEF 82
*RSX	SORT-11	SORT-11 V2.0 SPI 12.7.5	2.0	AE-54296-10-001	1	FER 84
*RSX	99P-11	SCIENTIFIC SUB PROGRAMMER'S REF MAN (UFD#1)	1.3	AA-1101D-TC-001	2	SEP 82
*RSX	SSP-11	SSP-11 V1.3 SPN 15.45.9	1.3	AE-3413H-16-001	1	FEP 84
*RSX	SSP-11	SSP-11 V1.3 SPD 15.45.10	1.3	AE-34131-TC-001	1	MAY 84
*RSX	SSP-11	ADDENDUM TO SPD	1.3	AE-BP27A-1K-001		JUL 84
*RSX	UN1004	UN1004/RSX RELEASE NOTES	2.0	AA-1341C-1C-001	1	SEP 82
*RSX	UN1004	UN1004/RSX USRS GRE/SYS ULN GDE (UPP\$1)	2.0	AA-1342F-10-001	4	SEF: 82
*RSX	UN1004	UN1004 V2.0 SPB 10.79.06	2,0	AE-3454G-TE-001	1	FEN 84
*RSX	USV11-H DRIVER	VSV11-N SOFTWARE DRIVER GUIDE	2.0	64-17878-18-901	1	8EH 85
BRSX	VSV11-M DRIVER	VSV11-H SOFTWARE DRIVER GUIDE	2.1	AA-J287,-EN (01		JUL 81
1RSE	USV11-M DRIVER	VSV11-H V2.0 RELEASE MUTES	2.0	AA-861°A-11-001	1	्कम हव

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VER510N	PART NUMBER FEV LEVEL	NUMBER UF FICHE	DATE
*RSX	VSV11-M BRIVER	VSV11-H V2.1 SPD 14.53.03	2.1	ΔE-8510-10-001	1	FEE' 84
*RSX	VTV31-K RSX11M DRIVE/SUR FKG	VTV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY	1.0	AA-M809A-10-001	1	APH 83
*RSX	VTV31-K RSX11M DRIVE/SUB PKG	VIV31-K/RSX V1.0 SPD 14.73.0	1.0	AE-8079A-10-001	1	FEB 84

PART

OPERATING	S PRODUCT	TITLE OF		NUMBER REV	NUMBER: OF	
SYSTEM	NAME	MANUAL	VERSION	LEVEL	FICHE	DATE
*RSX	RSX-11H	RSX-11M/RSX-11S RELEASE NOTES	4 - 1	AA-2573H-TC-001	2	NOV 83
, *RSX	RSX-11H	RSX-11H/11B INFORMATION DIRECTORY/INDEX	4.1	AA-2593G-TC-001	4	NOV 83
*RSX	RSX-11M	RSX-11M GUIDE TO WRITING AN I/O DRIVER	4.1	AA-2600E-TC-001	3	NOV 83
*RSX	RSX-11H	IAS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL	4.1	AA-5580R-TC-001	2	NOV 83
*RSX	RSX-11H	RSX-11 SYS GENERATION AND INSTALLATION GDE	4.1	AA-H625C-TC-001	5	NOV 83
*RSX	RSX-11H	RMS-11 PROGRAMMERS HANUAL	4.1	AA-L668A-TC-001	5	NOV 83
*RSX	RSX-11H	RMS-11 USER'S GUIDE	4.1	AA-L669A-TC-001	2	NOV 83
BRSX	RSX-11H	RMS-11 UTILITIES MANUAL	4.1	AA-L670A-TC-001	3	NOV 83
*RSX	RSX-11H	RSX-11H/H-FLUS BATCH AND QUEUE OPERATIONS MAN	4.1	AA-L671A-TC-001	2	E8 00M
*RSX	RSX-11H	RSX-11H/K-PLUS COMMANI LANGUAGE MANUAL	4.1	AA-L6728-TC-001	6	E8 VON
*RSX	RSX-11H	RSX-11H/H+ CRASH DUMP ANZ REF MANUAL	4.1	AA-L673B-TC-001	3	NOV 83
*RSX	RSX-11H	RSX-11M/H-PLUS ERROR LOGGING MANUAL	4.1	AA-L674R-TC-001	3	NOV 83
*RSX	RSX-11H	RGX-11H/H-PLUS EXECUTIVE REFERENCE MANUAL	4.1	AA-L675A-TU-001	4	NOV 83
*RSX	RSX-11H	RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L676A-TC-001	2	NOV 83
*RSX	RSX-11H	RSX-IIH/H+ I/O DRIVERS REF MAN (UFD#1)	4.1	AA-L677A-TC-001	ć	NOV 83
*RSX	RSX-11M	RSX-11H/H+ MCR OPERATIONS MANUAL (UPD41)	4.1	AA-L678A-TC-001	5	NOV 83
*RSX	RSX-11H	RSX-11H/H+ SYSTEM MANAGEMENT GDE (UPD#1)	4.1	AA-L679E-TC-001	5	NOV 83
* *RSX	RSX-11H	RSX-11H/M-PLUS TASK BLDR MANUAL (UPD#1)	4.1	AA-L680B-TC-001	5	NBV 83
*R9A	RSX-11H	RSX-114/H-PLUS UTILITIES MANUAL (UPD#1)	4.1	AA-L681A-FC-001	6	NUV 83
#RSX	RSX-11H	RMS-11: AN INTRODUCTION	4.1	AA-L682A-1E-001	1	NOA 83
*RSX	RSX-11H	INTRODUCTION TO RSX-11H AND RSX-11H-PLUS	4 - 1	AA-L763A-TC-001	2	KB V9N
*RSX	RSX-11H	IAS/MSX-11 1/U OPERATIONS REFLEENCE MANUAL	4.1	AA-#176A-16-001	3	MON 83
*RSX	RSX-11H	EDT EDITOR MANUAL	4,1	AA-M474A-TN-001	8	FER 94
#RSX.	RSX-11H	EDT BUICK REFERENCE MANUAL	4.1	\$A-M477A-18-001	1	FE8 84

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER PEV LEVEL	NUMBER OF FICHE	BATE
*RSX	RSX-11M	IAS/RSX-11 ODT REFERENCE MANUAL	4.1	AA-H507A-TC-001	1	MON 83
<b>VRSX</b>	RSX-11H	PDF-11 MACRU-11 LANGUAGE REF MANUAL	4.1	AA-V0276-TC-001	4	MON 83
*RSX	RSX-11M	RSX-11H V4.1 SFD 14.35.20	4.1	AE-3407U-TC-001	1	FEB 84
ERSX	RSX-11M	RSX-11H V4.1 SFU 14.32.21	4.1	AE-3407V-TC-001	1	MAY 84
#RSX	RSX-11h	RSX-11M CROSS REFERENCE TABLE	4.1	AE-h778F-TE-001		JUL 94
*RSX	RSX-11M	RSX-11M HINI REFERENCE	4.1	AV-5570E-:C-001	3	NUV 83
*RSX	RSX-11H	PDP-11 PROGRAMMING CARD	4.1	EH-S1046-78-001	1	NO4 83
#RSX	RSX-18X-PLUS	TAS/ESX-11 SYSTEM LIB ROUTINE HEF MANUAL	2.1	AA-5580R-1L-001	2	NOV 83
*RSX	RSX-11H-PLUS	RSX-11K-PLUS GUIDE TO WRITING I/O DRIVER	2.1	44-H267R-TC-001	4	NOV 83
*RSX	JISX-11H-PLUS	RSX-11M-PLUS INFORMATION DIRECTORY AND INDEX	2.1	AA-H426C+1C-001	4	10V 83
*RSX	RSX-11M-11 us	RSX-11K-FLUS V2.1 RELEASE NOTES	2.1	AA-H427C-10-001	1	NOV 83
*RSX	RSX-11H-PLUS	RSX-11N-PLUS SYSTEM GEN/INSTALLATION GUIDE	2.1	AA-H431C-TC-001	3	HOV 83
*RSX	RSX-11M-PLUS	RMS-11 PROGRAMMERS MANUAL	2.1	AA-L668A-TC-001	5	NOV 83
*RSX	RSX-11H-PLUS	RMS-11 USEF'S GUIDE	2.1	AA-L569A-TC-001	2	NOV 83
*RSX	RSX-11M-PLUS	RMS-11 UTILITIES	2.1	AA-L670A-TC-001	3	NOV 83
*RSX	RSX-11M-PLUS	RSX-11M/K+ BATCH AND QUEUE OFER MANUAL	2.1	AA-L671A-TC-001	2	88 VUN
*RSX	RSX-11M-PLUS	RSX-11H/H+ COMMAND LANGUAGE MANUAL	2.1	AA-L672B-FC-001	5	NOV 93
*RSX	RSX-11M-PLUS	RSX-11M/M+ LRASH DUMP ANZ REF MANUAL	2.1	AA-L673P-10-001	3	NOA 83
*RSX	RSX-11M-PLUS	RSX-11H/H-PLUS ERROR LOGGING MANUAL	2.1	AA-L6748-1C-001	3	NOV 83
TRSX	RSX-11M-PLUS	RSX-11H/H-PLUS EXECUTIVE REFERENCE MANUAL	2.1	AA-U575A-10-001	4	M00 83
*RSX	RSX-11H-PLUS	RSX-11M/M+ GUIDE TO FROGRAM DEVELOPMENT	2.1	AA-L676A-TC-001	2	NOV 93
*RSX	RSX-11M-PLUS	RSX-11M-H-FLUS I/U PRIVERS REF MAN (UPD#1)	2.1	AA-L67/A-TC-001	6	NUV 83
<b>PRSX</b>	RSX-11M-PLUS	RSX-11H-H-FLUS HCP OF MANUAL (UPD#1)	2.1	AA-L678A-TC-001	5	MO0 83
TRSX	RSX-11M-PLUS	RSX-11M-M-FLUS SYSTEM MANAGEMENT GDE (UPUH1)	2.1	AA-L6798-10-001	6	HBh 83
*RSX	RSX-11H-PLUS	RSX-11M-H-PLUS TASK BUILDER MANUAL	2.1	AA-L680P-TL-001	e.	E8 VOH
#RSX	RSX-11M-PLUS	RSX-11M/M-PLUS UTILITIES MANUAL (UFD#1)	2.1	AA-L681A-11-001	b	404 63

#### INDEX FOR THE CURRENT SOFTWARE USER

FAFT TITLE NUMBER NUMBER **OPERATING** PRODUCT 0F REV ÐF. SYSTEM NAME MANUAL VERSION LEVEL FICHE DATE \*RSX RMS-11: AN INTRODUCTION MOV 83 RSX-11M-PLUS 2.1 AA-L682A-TE-001 1 #RSX RSX-11H-PLUS INTRODUCTION TO RSX-11H AND RSX-11H+ 2.1 AA-L763A-TC-001 2 NOV 83 \*RSX RSX-11H-PLUS IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL 2.1 AA-h176A-TC-001 3 NOV 83 \*RSX RSX-11M-PLUS EDIT EDITOR MANUAL 2.1 AA-M476A-1h-001 8 FEB 84 #RSX RSX-11M-PLUS EDI QUICK REFERENCE MANUAL 3.1 AA-M477A-TK-001 1 FEB 84 **BRSX** RSX-11H-PLUS IAS/RSX-11 DUT REFERENCE MANUAL 2.1 NEV 83 AA-M507A-TU-001 1 \*RSX PDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL 2.1 AA-V027A-TC-001 3 **NOV 83** RSX-11M-PLUS \*RSX RSX-11M-FLUS V2.1 SFI 14.70.08 2.1 AE-H8621-10-001 1 RSX-11M-PLUS FEE 84 **\*RSX** RSX-11M-PLUS RSX-11M-PLUS V2.1 SPB 14.70.09 2.1 AE-H8521-TC-001 JUL 34 **PRSX** RSX-11M-PLUS RSX-11M-PLUS V2.1 CROSS REFERENCE SPD 2.1 AE-M7791-TC-001 1 MAY 84 \*RSX RSX-11M-PLUS RSX-11M-PLUS MINI REFERENCE 2.1 AV-H435C-TU-001 3 NOV 83 \*RSX RSX-11M-PLUS PDF-11 PROGRAMMING CARD 2.1 EH-S1046-78-001 1 NUU 83 #RSX RSX-11S RSX-11M/RSX-11S RELEASE NUTES 4.1 AA-2573H-TC-001 2 NOU 83 PRSX RSX-115 RSX-11H/RSX-11S INFORMATION DIRECTORY & INDEX 4.1 AA-25936-TE-001 4 NOV 83 **¥RSX** RSX-11S RSX-11H GUIDE TO WRITING I/O DRIVER 4.1 AA-2600E-TE-001 3 **88 404** \*RSX RSX-115 RSX-11S SYS GEN/INSTL GDE (INCLUDES UPD#1) 4.1 AA-2874E-10-001 2 NBN 83 \*RSX **RSX-11S** IAS/RSX-11 SYS LIR ROUTINE REF MANUAL 4.1 AA-5580E-TC-001 2 NOU 83 **#RSX** RSX-11S RSX-11M SYSTEM GENERATION/INSTALLATION GUIDE AA-H625C-TC-001 5 NOV 83 \*RSX RSX-11S RSX-11M/K+ CRASH DUMP ANZ REF MANUAL 4.1 AA-L6738-TE-001 3 **83 VON** \*RSX **RSX-115** RSX-11M/H-PLUS EXECUTIVE REFERENCE MANUAL 4.1 NOV 83 AA-L675A-TC-001 4 2RSX RSX-115 RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT 4.1 AA-E676A-TU-001 2 NOV 83 \*RSX RSX-115 RSX-11H/H+ I/O DIRVERS REF MANUAL (UPI41) 4.1 AA-L677A-TE-001 6 MON 63 \*RSX RSX-11S RSX-11M/M-PLUS MCR OPERATIONS MANUAL (UPR#1) 4.1 AA-L578A-TU-001 S NOV 83 \*RSX RSX-11S RSX-11M/H+ SYSTEM MANAGEMENT GUIDE (UPIN1) 4.1 AA-L6/9R-10-001 6 NU7 83 \*RSX RSX-11S RSX-11H/M-PLUS TASK BUILDER MANUAL 4.1 A4-L680E-TE-001 5 NOU 33 #RSX RSX-11S TAS/RSX-11 I/O UPERATIONS REFERENCE MANUAL 4.1 4A-M176A-11-001 3 NBN 83

# INDEX FOR THE CURRENT SUFTWARE USER

ODE'DATTING		SERALET	T TTLE OF		PART NUMBER	NUMBER:	
OPERATING SYSTEM		PRODUCT NAME	NANUAL	VERSION	REV LEVEL	OF FICHE	DATE
*RSX	RSX-11S		IAS/RSX-11 OUT REFERENCE MANUAL	4.1	AA-M507A-TC-001	1	NOV 83
*RSX	RSX-11S		PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	4.1	AA-V027A-1C-001	3	NOV 83
*RSX	RSX-11S		RSX-11H/11S V4.1 UPDATE B INFORMATION	4.1	AA-W259E-TC-001	1	FEB 84
*RSX	RSX-11\$		RSX-11M/11S V4.1 UPDATE C INFORMATION	4.1	AA-W259L-YC-001	1	HAY 24
*RSX	RSX-115		RSX-115 V4.1 SPD 9.21.13	4.1	AE-3427N-TC-001	1	FEB 84
*RSX	RSX-11S		RSX-115 V4.1 SPR 09.21.14	4 - 1	AE-34270-10-001	1	MAY 84
*RSX	RSX-11S		RSX-11H HINI REFERENCE	4.1	AV-5570E-TE-001	3	NOV 83
*RSX	RSX-11S		PDP-11 FRUGRAMMING CARD	4.1	EH-S1046-78-001	1	NUV 83
#RSX	BASIC-PLUS-2	FOR RSX-11H/H-PLUS	BASIC+2 RSX-11H/M-PLUS INSTL GDE/REL NOTES	2.1	AA-0158E-TC-001	1	JAN 84
*RSX	BASIC-PLUS-2 F	FOR RSX-11H/H-PLUS	BASIC+2 RSX-11M/M-PLUS INSTL GDE/REL NOTES	2.2	AA-0158F-TC-001	1	MAY 84
*RSX*	BASIC-PLUS-2	FOR RSX-11H/H-PLUS	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-Th-001	6	APR 83
<b>SRSX</b>	BASIC-PLUS-2 F	OR RSX-11H/H-PLUS	BASIC REFERENCE MANUAL (UPIII)	2.2	AA-L334A-1E-002	6	MAY 84
*RSX	BASIC-PLUS-2	FOR RSX-11H/H-PLUS	BASIC USER'S GUIDE	2.0-2.1	AA-L335A-TK-001	3	APR 83
BRSX	BASIC-PLUS-2 F	FOR RSX-11H/H-PLUS	BASIC USER'S GUIDE (UFD\$1)	2.2	AA-L335A-TK-002	3	MAY 84
#RSX	BASIC-PLUS-2	FOR RSX-11H/H-PLUS	BASIC ON RSX-11M/M-FLUS SYSTEMS (UPD#1)	2.1	AA-L338A-TC-001	3	JAN 84
*RSX	BASIC-PLUS-2 F	FOR RSX-11M/M-PLUS	RASIC ON RSX-11H/H-PLUS SYSTEMS (UP #1 & #2)	2.2	AA-L338A-TC-002	3	MAY 84
*RSX	BASIC-PLUS-2	FOR RSX-11M/N-FLUS	BASIC-PLUS-2 92.1 SPD 14.11.8	2.1	AE-J197[-TC-001	1	FEB 84
*RSX	BASIC-PLUS-2 F	FOR RSX-11H/H-PLUS	BASIC-PLUS-2 V2.2 SPN 14.11.10	2.2	AE-J197h-FC-001	1	MAY 84
*RSX	BASIC-PLUS-2	FOR RSX-11H/H-PLUS	BASIC POCKET REFERENCE GUIDE	2.0-2.2	AV-L341A-TK-001	2	APR 83
*RSX	BCP		RCP USER'S GUIDE	1.0	AA-N259B-TN-001	2	FER 84
*RSX	BCP		RCF V1.0 SFB 14.72.0	1.0	AE-N202A-IC-001	1	FEB 84
*RSX	BCP		BCP V1.0 RELEASE NOTES	1.0	AV-N2708-10-001	1	APR 83
*RSX	CHR11/CHV11 SC	DETWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE	3.0	A4-N050B-TC-001	1	FEB 84
RSX z	CHR11/CHV11 SC	DETWARE DRIVER	CMR11/CMV11 SOFTWARE DRIVER REFERENCE MANUAL	3.0	AA-N0615-TC-001	1	FEB 84
*RSX	CHR11/CHV11 90	OFTWARE DRIVER	CMR11/CHU11 V3.6 SPD 14.76.01	3.0	AE-N0597-10-001	1	MAY 8ª
*RSX	CHR11/CHV11 SE	DETWARE DELVER	CRM11/CHV11 SOFTWARE DRIVER RELEASE NOTES	3.0	AV-N058B-10-001	1	FEB 84

OPERATING SYSTEM		PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	MATE
*RSX	COBOL-81/RSX		COBOL-81 LANGUAGE REFERENCE MANUAL	2.0	AA-J434B-TC-001	4	JAN 84
*RSX	COBOL-81/RSX		RSX-11M/M-PLUS USER'S GUIDE	2.0	AA-M1798-10-001	5	JAN 34
*RSX	COMOL-81/RSX	1.00	RSX-11M/M-FLUS INSTALLATION/RELEASE NOTES	2.0	AA-81810-TE-001	1	JAN 84
*RSX	COBOL-81/RSX		COBOL-81 RSX V2.0 SFU 14.26.03	2.0	AE-F077E-T0-001	1	FEB 84
*RSX	COBOL-81/RSX		COROL-81 POCKET GUIDE	2.0	AV-H630C-TC-001	2	JAN 84
#RSX	CONN TOP-DUP		CONN TOP-DUP PROGRAMMER'S MANUAL	1.0	AA-5679A-10-001	1	SEF 82
*RSX	COMM 19F-DUF		COMM TOP-DUP RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-D36/A-TC-001	1	SEF 82
WRSX	COMM 10P-DUP		ADDENDUM TO SPD	1.0	AE-BB27A-1N-001	1	mAY 84
*RSX	COMM TOP-DUP		COMM 10F-DUP V1.0 SPD 10.12.2	1.0	AE-01210-16-001		JUL 94
#RSX	CONN IOP-NZ		COMM 10P-DZ PROGRAMMER'S MANUAL	1.0	AA-5127A-10-001	1	SEF 82
*RSX	CONH IOP-DZ		CONH TOP-FIZ RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-D368A-TC-001	1	SEF 82
<b>BRSX</b>	COMM IOP-DZ		addenium to spd	1.9	AE-B827A-1K-001		JUL 84
*RSX	COM IOP-DZ		COMM IOP-DZ V1.0 SPB 10.11.2	1.0	AE-D122C-TC-001		JUL 84
*RSX	CORAL-66		PDP-11 CORAL-66 V4.0 INSTE GDE/REL NOTES	4.0	AA-1744E-TC-001	1	AFF 83
*RSX	CORAL-66		CORAL-66 LANGUAGE REFERENCE MANUAL	4.0	AA-D111C-FA-001	2	AFR 83
*RSX	CORAL-66		RSX/VMS CORAL-66 USER'S GUDE	4.0	AA-U112C-TK-001	4	APR 83
BRSX	CCRAL-66		CORAL-66 V4.0 SPD 14.56.10	4.0	AE-3450I-TC-001	1	MAY 84
WRSX	DATATRIEVE-11	L,	DATATRIEVE-11 REFERENCE MANUAL	3.0	AA-UQ49A-1K-001	4	FEB 84
*RSX	DATATRIEVE-1	1	DATATRIEVE-11 CALL INTERFACE MANUAL	3.0	AA-U050A-TL-001	2	JAN 84
RRSX	DATATRIEVE-11		DATATRIEVE-11 GUIDE TO WRITING REPORTS	3.0	AA~U051A-1K-001	1	£FF 84
*RSX	DATATRIEVE-1	1	DATATRIEVE-11 SUMMARY DESCRIPTION	3.0	AA-U04(2A-TE-001	1	JAN 84.
*RSX	DATATRIEVE-11	1	DATATRIEVE-11 INSTALLATION GNE/REL NOTES	3.0	AA-X022A-1E-001	1	JAN 84
*RSX	BATATRIEVE-1	1	DATATRIEVE-11 USER'S GUIDE	3.0	AA-X023A-1K-001		FEF 84
#RSX	DATATRIEVE-11	l	INTRODUCTION TO DATATETEVE-11	3.0	44-14254-11-001	1	FEB 84
*RSX	BATATRIEVE-1	1	DATATRIEVE-11 FOCKET GUIDE	3.0	44-Y1034-11-901	1	+++ +4
TRSX	DATATR1EVE-11	1	DATATRIEVE-11 93.0 SPP 12.48.11	3.0	AE-0/7/L-10-001	1	мат на

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERS10N	PART NUMBER FLV LEVEL	NUMBER OF	PATE
*RSX	DBMS-11	BBMS-11/M+ BDL/DEVICE MEDIA CON LANG REF MAN	2.0-2.1	AA-H804E-TC-001	3	SEP 82
*RSX	DRMS-11	DRMS-11 DATA BASE ADMINISTRATOR'S (DRA) GUIDE	2.0-2.1	AA-H805E-TU-001	*	SEP 92
*RSX	DBMS-11	DEMS11 FOFTRAN DATA MANIPULATION LANG FEE MAN	2.6-2.1	AA-1883B-TC-001	2	SEF 82
*RSX	DBMS-11	DEMS11 COROL MATA MENIFULATION LANG HEF MAN	2.0-2.1	4A-1884F-10-001	,	SEF 82
*RSX	DBM5-11	DEMS-II INSTALLATION GUIDE	2.0-2.1	AA-K885P-TL-001	2	SEF 82
*RSX	DBMS-11	DBMS-11 V2.0 RELEASE NOTES	2.0-2.1	AA-K886K-10-001	1	SEP 82
*RSX	DBHS-11	USING THE DATATRIEVE-11/DBM5-11 INTERFACE	2.0-2.1	AA-N9870-TC-001	1	SEF 82
*RSX	DBMS-11	DEMS-11 V2.1 SPN 12.66.2	2.1	AE-M1300-10-001	1	FEB 84
*RSX	DBMS-11	BEFORE YOU INSTALL DAMS-11 92.1	2.1	AV-P666A-10-001	1	AFF 83
*RSX	DECNET-11H	RSX DECNET GUIDE TO USER UTILITIES	3,1	AA-H223E-TL-001	* j	FEF 84
*RSX	DECNET-11H	RSX DECNET GUIDE TO USER UTILITIES	4.0	AA-H223C-TC-001	2	mAY 84
*RSX	DECNEY-11H	RSX DECNET SYSTEM MANAGER'S BULLNE	3.1	AA-H224E-TC-001	5	FEB 84
*RSX	DECNET-11H	AS) DECNET SYSTEM MANAGER'S GUIDE	4.0	AA-H224C-11-001	e,	MA1 84
*RSX	DECNET-11H	RSX DECNET NETWORK GEN AND INSTE GUIDE	3.1	AA-H225k-16-001	3	FEE 84
*RSX	DECRET-11H	RSX DECNET NEIWORN GEN AND INSTALLATION GUIDE	4.0	AA-H225C-16-001	5	#A1 84
#RSX	DECNET-11H	INTRODUCTION TO DECNET	3.1	AA-J055L-IN-001	2	FEF 84
*RSX	DECNET-11M	INTRODUCTION TO DECNET	4.0	AA-J055U-1:-001	3	ner 84
*RSX	DECNET-11H	RSX DECNET POST-INSTE CHECKUUT PROCEDURES	3.1	4A-J319B-18-001	2	FER 84
#RSX	DECNET-11H	RSX DECNET POST-INSTE CHECKOUT PROCEDUPES	4.0	AA-J3190-7K-001	1	MAT 84
*RSX	DECNET-11H	RSX DECNET HELEASE MOTES	7.1	AA-J5178-TE-001	1	FEE 84
*RSX	DECNET-11h	RSX DECNET MELEASE NOTES	4.0	AA JUL-11-001	1	MAY 84
#RSX	DECNET-11H	GNEKATEM OF KRX DECNET	3.1	AA-m0+64-10-001	2	fth 84
*RSX	DECHET-11H	OVERVIEW OF RSX EECHET	4.0	AA-M976E IC 021		NAT 84
#RSX	DECHET-11H	PSX-MECHET REFERENCE DUTTE	1.1	AA-#09/A-([-00]	1	FEE 84
*RSX	DECNET-11h	RS) DECNET PROGRAMMER'S REF MANUAL	3.1	94-40-84-11-661	5	IFF 84
*R5X	DECNET-11H	RSY DELNET PROGRAMMEN & PEFERENCE MANUAL	4.0	Ar-Mark. 11 wil	a	## F## 84

			11716		HART MUMBER	NUMBER	
OPERATING		PRODUCT	11TLE OF		PEV	124mur 96	
SYSTEM		NAME	PANUAL	UEF5IUM	LEVEL	FILHE	11418
#RSX	DECNET-11H		OVERVIEW TO DIGITAL NETWORK PROCEDURES	4,0	6A-X165A-(1-001	2	HAT 84
WRSX	DECNET-11H		VOLUME I GENERAL INFORMATION	4.0	AA-X919A-10-001		JUL 84
#RSX	DECNET-11H		VOLUME II USER'S INFORMATION	4.0	AA-X920A-TL-001		JUL 84
*RSX	DECNET-11H		VOLUME 111 GEN/INSTALLATION INFORMATION	4.0	AA-A921A-11-001		JUL 84
*RSX	DECNET-11H		VOLUME IV SYSTEM MANAGEMENT INFORMATION	4.0	AA-X922A-IL-001		JUL 84
*RSX	DECNET-11H		DECNET RSX SYSTEM MANGER'S MINT REF GUIDE	4.0	AA-X924A-3C-001	1	4AY 84
*RSX	DECNET-11M		DECNET-11M 94.0 SPD 10.75.10	4.0	AE-34311-10-001	1	MAY 84
*RSX	DECNET-11H		DECNET-RSX VOLUME II USER'S INFORMATION	4.0	AV-1553A-10-001		JUL 84
*RSX	DPH		DPM/DPM+ DECDATA INTELL SUBS USRS GDE (UPD#1)	4.1	AA-J5398-TC-001	3	SEP 82
#RSX	DPH		DPH/DFH+ TERMIANL USER'S GUIDE (UFL41)	4.1	AA-J530F- C-001	2	SEF 82
*RSX	DPH		DPH/DPH+ SYSTEM GENERALION/MANAGEMENT GDE	4.1	AA-J5310-TC-001	?	SEP 82
WRSX	DPK		DEM/DEM PLUS RELEASE NOTES	4,1	AA-N150A-10-001	1	SEP 82
*RSX	DPH		IPH V4.1 SPB 15.6.6	4.1	AE-5730H-TU-001	1	FEE 84
*RSX	DEH		DPH/DPH PLUS REFERENCE GUIDE	4 - 1	AV-M195A-10-001	1	SEF 82
PRSX	DT07-11H		DTO7-11H VI-1 USER'S GUIDE	1.1	AA-r 568A-11-001	1	SEF 82
*RSX	DT07-11H		DT07-11H V1.1 SPD 14.36.1	1.1	AE-1.534F-10-001	1	FEP 84
*RSX	0X/11F		DX PRODUCTS PROGRAMMER'S REFERENCE MANUAL	3.1	44-54690-10-001	1	AFR 83
*RSX	DX/11H		DX PRODUCTS USER'S GUIDE	3.1	AA-5476II-IL-001	1	AFF 83
*RSX	DX/11H		DX/11M INSTALLATION GUIDE	3.1	AA-[1497A-[L-00]	1	APK 83
#RSX	DX/11 <del>H</del>		DX/11H VERSION 3.1 HELEASE MOTES	3.1	AA-H288H-10-001	1	APR 83
*RSX	DX/11m		DX/11H 93.1 SPU 10.95.4	3.1	AE-5274F-1,-(0)1	1	FER 94
*RSX	DX/11H		ADDENDIGHTU SES	3.1	AE-FF2/A-FF-001		JUL 84
#RSX	FHS-11/RSX		POP11 KEYPAD EDITOR USER 5 GDE (UFD\$1)	1.0	AA-H853A-TU UU1	*)	SEP 82
*RSX	FMS-11/RSX		FHS-11/RSX11H SOFTWARE REF MANUAL (UPIN1)	1.0	AP-H855A-HL-001	į	SLF 82
*RSX	FMS-11/RSX		FMS-11/PSY-11H PELEASE NUTES	1.0	AA-M3576-11-001	1	FF1 85
*RSX	FHS-11/RSX		PDP11 KEYPAD EDITOR MELEASE NUTES	1.0	AA-J652A-TE-001	100	eft. A"

OPERATING SYSTEM	PRODUCT NAME	FITLE OF MANUAL	VERSION	PART NUMBER PEV LEVEL	NUMBER OF FICHE	<u> IIA1E</u>
\$RSX	FMS-11/RSX	FMS-11/RSX V1.0 SPD 12.27.5	1.0	AE-J405F-TC-001	1	FEB 94
*RSX	FMS-11/RSX	FMS-11/RSX V1.0 SPD 12.27.0/	1.0	AE-J405H-1C-001		JUL 84
TRSX	FMS-11/RSX	PDP11 KEYPAD EDITOR REFERENCE CARD	1.0	AV-H854A-FC-001	1	SEP 82
*RSX	FMS-11/RSX	FHS-11/RSX-11H HINI REFERENCE SUIDE	1.0	AV-H856A-TC-001	1	SEP 82
*RSX	FORTRAN IV/RSX	PDP-11 FURTRAN LANGUAGE REFERENCE MANUAL	2.6	AA-R953A-TK-001	2	JAN 84
*RSX	FORTRAN IV/RSX	RSX/VMS FORTEAN IV INSTALLATION/REL NTS	2.6	AA-R954A-TK-001	1	JAN 84
*********	FORTRAN IV/RSX	RSX/VAX/VMS FORTRAN 10 USER'S GUIDE	2.6	AA-R955A-TN-001	2	JAN 84
* TRSX**	FORTRAN IV/RSX	FORTRAM IV/RSX V2.6 SPI 14.63.9	2.6	AE-3443J-TC-001	1	FER 84
*RSX	FORTRAN IV/RSX	FORTRAN IV/RSX V2.6 SPD 14.63.10	2.6	AE-3443K-FC-001	1	HAY 84
ORSX	FORTRAN-77 DERUG, PDP-11	PDP-11 FORTRAN-77/DEBUG USER'S GUIDE	1.0	AA-V197A-TK-001	2	JAN 84
*RSX	FORTRAN-77 DEBUG, PDF-11	FORTRAN-77/DEBUG INSTAL GUIDE/REL NOTES	1.0	AA-X650A-FK-001	1	JAN 84
RSX	FORTRAN-77 DEBUG, PDP-11	FDP-11 FORTRAN-77 DEBUG V1.0 SPD 30.33.00	1.0	AE-Y398R-TK-001	1	FER 84
*RSX	FORTRAN-77/RSX, PDP-11	PDP-11 FORTRAN-77 LANGUAGE REFERENCE MANUAL	5.0	AA-V193A-TK-001	3	FEB 84
*RSX	FORTRAN-77/RSX, PDP-11	FDF-11 FORTRAN-77 USER'S GUILLE	5.0	AA-V194A-1K-001	3	FER 84
TRSX	FORTRAN-77/RSX, PDP-11	PDP-11 FORTRAN-77 OTS REFERENCE MANUAL	5.0	AA-V195A-TN-001	2	FEB 84
*RSX	FORTRAN-77/RSX, PDF-11	PDF-11 FORTRAN-77 INSTL GUIDE/REL NOTES	5.0	AA-V196A-IK-001	1	JAN 84
*RSX	FORTRAN-77/RSX; PDP-11	PDP-11 FORTRAN-77/RSX V5.0 SPD 14.31.06	5.0	AE-J1396-IC-001	1	FEB 84
*RSX	FORTRAN-77/RSA, PDP-11	PDP-11 FORTRAN-77/RSX V5.0 SPD 14.31.07	5.0	AE-J139H-TC-001	1	MAY 84
*RSX	IEC-11M	IEC-11M RSX SOFTWARE MANUAL	3.0	AA-M275A-TC-001	1	SEP 82
*RSX	IEC-11M	IEC-11H V3.0 SP1 14.64.0	3.0	AE-N029A-TC-001	1	FEH H4
#RSX	1EC-11M	IEC-11M RELEASE NOTES	3.0	AU-V50/A-TC-001	1	FEB 84
*k3X	KMC-11 100LS	KMC11 PROGRAMMER'S MANUAL	1.0	AA-5244R-TC-001	2	SEF 82
*RSX	KMC-11 TOOLS	KMC-11 TOOLS V1.0 SPD 12-49-04	1.9	AE-L/76E-FC-001	1	MAT 84
#RSX =	KNV11-A HOLD FRAMING SOFTWARE	KNV11-A HILL FRAMING SETWARE FOR ESX HEF MAN	1,0	AA N565A-10-001	1	AFR 83
*RSX	KHV11-A HOLC FRAMING SOFTWARE	KMV11A-HULC FRAMING SUFTWARE V1.0 SPU 14.22.0	1.0	AE-R298A-10-001	1	FER 84
\$RSX	LABORATORY SUBROUTINE PACKAGE	LABORATORY SUB PROGRAMMER'S REF MAN (UPD41)	1.2	AA-L994C-TE-001	1	281 445

		TITLE		PART NUMBER	NUMBER	
OPERATING SYSTEM	PRODUCT Name	OF HANUAL	VERSION	REV LEVEL	OF FICHE	NATE
*RSX	LABORATORY SUBROUTINE PACKAGE	ADDENDUM TO SPD	1.2	AE-BB27A-TN-001		JUL 84
*RSX	LABORATORY SUBROUTINE PACKAGE	LSP V1.2 SPD 15.44.5	1.2	AE-06071-10-001	1	FEP 84
*RSX	LATOKATORY SUBROUTINE PACKAGE	LSP V1.2 SPU 15.44.06	1.2	AE-D607G-TC-001	1	MAY 84
WRSX	NUX200/RSX-1AS	MUX200/RSX-IAS V2.1 RELEASE NUTES	2.1	AA-1343C-TC-001	1	JAN 84
*RSX	MUX200/RSX-IAS	MUX200/RSX-IAS SYSTEM MANAGER GUIDE	2.1	AA-13440-10-001	2	JAH 84
TRSX	MUX200/RSX-IAS	MUX200/RSX-1AS USER'S GUIDE	2.1	AA-1346C-TC-001	1	JAN 84
*RSX	MUX200/RSX-IAS	HUX200/RSX-IAS V2.1 SPB 10.77.07	2.1	AE-3453I-YC-001	1	FEB 84
WRSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.1	AA-N9598-1C-001	1	FEP 84
BRSX	OBSERVER	OBSERVER USER'S GUIDE	1.1	AA-N960B-TC-001	3	FER 84
#RSX '	ORSERVER	ORSERVER RELEASE NUTES	1.1	AA-N962B-1C-001	1	FER 84
*RSX	ODSERVER	OBSERVER V1.1 SPD 13.18.02	1.2	AE-F3350-F0-001	1	MAY 84
<b>VPSX</b>	OBSERVER	OBSERVER REFERENCE CARD	1.1	AV-X073A-10-001	1	FER 84
BRSX	OBSERVER	ORSERVER EVENT MESSAGE REFERENCE MANUAL	1.1	AV-X074A-TU-001		JUL 84
*RSX	PASCAL/RSX, PDP-11	FDP-11 PASCAL LANGUAGE REF MANUAL (UPIM1)	1.1	AA-M875A-10-002	2	FER 84
*RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL USER'S GUIDE (UPD#1)	1.1	AA-M876A-TC-002	2	FEB 84
#RSX	PASCAL/RSX: PDP-11	PDP-11 PASCAL INSTALLATION GDE/REL NOTES	1.1	A4-M877B-TC-001	1	6AY 84
WRSX	PASCAL/RSX, PDP-11	PDF-11 PASCAL/RSX V1.1 SPD 14.18.02	1.1	AE-N91/C-TC-001	1	FEF 84
#PSX	PASCAL/RSX, PDP-11	PDP-11 FASCAL/RSX V1.1 SPD 14.18.03	1.1	AE-N9179-10-001	1	mAY 84
RSX	PPP-11 COBOL	PDP-11 COBOL INSTALLTION GUIDE	4.4	AA-1745F-FC-001	1	SEF 82
#RSX	PDP~11 COBOL	PDP11 COPOL LANG REF MANUAL (UP141 & 42)	4.4	AA-1749E-TC-001	3	SEF 82
*RSX	PDP-11 COBOL	PDP-11 COROL USER'S GUIDE (INCLUDES UPD#1)	4.4	AA-1757E-TC-001	6	SEF 82
<b>URSX</b>	PDP-11 CUBOL	PRF-11 COROL V4.4 SPU 12.40.18	4.4	AE-341/5-10-001	1	FEB 84
TRSX	PLXY-11M	PLXY-II VI.1 USER'S GUIDE	1.1	100-31-Ad2dt-AA	1	SEP 82
- RRSX	PLXY-11H	PLXY-11 USER'S GUIRE	1.3	AA-J535R-TK-001	1	may 84
*RSX	PLXY-11M	FLXY-11 VI.3 SPD 14.39.01	1.3	AE-K7978-10-001	1	MAY 84
*RSX	PRO TOOL KIT FORTRAN-77 DBG	PRO TOOL KIT FORTRAN-77/DMG 16/DOC SUPI	1.0	AA-2384A-1h-001	1	MAY 84

OPERATING SYSTEM		PROD NAM		TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	PRG TOOL KIT	FORTR	AN-77 DBG	PRO TOOL KIT FURTPAN-77/DBG V1.0 SPD 40.25.00	1.0	AL-2847A-TH-001		JUI. 84
*RSX	PROFESSIONAL	HOST	COMMUNICATIONS	PROFESSIONAL HOST COMM INSTE PROCEDURES	1.5	AA-F412B-Th-001	1	JAN 84
*RSX	PROFESSIONAL	HOST	COMMUNICATIONS	PROFESSIONAL HOST COMM INSTE PROCEDURES	1.7	AA-P412C-TK-001	1	MAY 34
*RSX	PROFESSIONAL	HOST	TOOL KIT	FMS-11/RSX SOFTWARE REFERENCE MANUAL	1.0	AA-H855A-10-001	3	APR 83
*RSX	PROFESSIONAL	HOST	JOOL KIT	FMS-11/RSX RELEASE NOTES	1.0	AA-H857A-TC-001	1	APR 83
#RSX	PROFESSIONAL.	HOST	T00L K1T	RSX/RMS USER'S GUIDE	1.0	AA-L669A-10-001	2	may 84
*RSX	PROFESSIONAL	HOST	100L KIT	RSX-11M/H-PLUS RMS-11 UTILITIES MANUAL	1.0	AA-L670A-TL-001	3	MAY 84
*RSX	PROFESSIONAL	HOST	TOOL KIT	RSX-11M/M-PLUS TASK RUILDER MANUAL	1,0	AA-L680B-TC-001	5	JAN 84
*RSX	FROFESSIONAL	HOST	TOOL KIT	IAS/RSX-11 ODT REFERENCE MANUAL	1.0	AA-M50/A-FE-001	1	APR 83
*RSX	PROFESSIONAL	HOST	TOOL KIT	TOOL KIT DOCUMENTATION DIRECTORY	1.0	AA-N615F-1N-001	1	JAN 84
*RSX	PROFESSIONAL	HOST	TOOL KIT	TOOL KIT DOCUMENATION DIRECTORY	1.0	AA-N615C-TN-001	1	hay 84
*RSX	PROFESSIONAL	HOST	TOOL KIT	TOOL KIT USER'S GUIDE	1.0	AA-N617C-TK-001	3	deY 84
*RSX	PROFESSIONAL	HOST	TOOL KIT	CORE GRAPHICS LIBRARY MANUAL	1.0	AA-N619A-IN-001	2	49H 83
*RSX	PROFESSIONAL	HOST	TOOL KIT	CORE GRAPHICS LIRRARY MANUAL	1.0	AA-N619B-1K-001	2	MAY 84
*RSX	PROFESSIONAL	HOST	T00L KIT	P/OS SYSTEM REFERENCE MANUAL	1.0	AA-N620A-TN-001	4	APR 83
*RSX	PROFESSIONAL	HOST	IOOL KIT	P/OS SYSTEM REFERENCE MANUAL (UPD#2)	1.0	AA-N620A-TN-092		THE 84
*RSX	PROFESSIONAL	HOST	TOOL KIT	DOCUMENTATION GUIDE LINES	1.0	AA-N621A-TK-001	1	APR 83
*RSX	PROFESSIONAL	HOST	TOOL KIT	TERMINAL SURSYSTEM MANUAL	1.0	AA-N6238-TN-001	2	JAN 84
*RSX	PROFESSIONAL	HOST	TOOL KIT	PROZEMS-11: AN INTRODUCTION	1.0	AA-P098A-Th-001	1	APR 83
*RSX	PROFESSIONAL	HUS7	TOOL KIY	PRO/RMS-11 MACRO PROGRAMMER'S GUIDE	1.0	PA-F0994-1N-001	5	APR 83
*RSX	PROFESSIONAL	HOST	TOOL KIT	FRO/FMS-11 DUCUMENTATION SUPPLEMENT	1.0	AA-P1038-1K-001	1	JAN 84
*RSX	PROFESSIONAL	HOST	10 <b>0</b> L K11	TAS/RSX OUT REFERENCE MANUAL SUFFLEMENT	1.0	AA-F1938-1K-001	1	JAN 84
CRSX	PROFESSIONAL	HOST	TOOL KIT	POP-11 MACRO-I1 LANGUAGE REFERENCE MANUAL	1.0	AA-0027A-10-001	3	JAM 84
*RSX	PROFESSIONAL	HOST	YOOL KIT	PROVIDUL KIT DOCUMENATION DIRECTORY	1.0	AA-X910A-JH-001		स्म स्व
*RSX	PROFESSIONAL	HOST	100L KIT	PRO/TOOL KIT INSTALLATION GDE/RELEASE NUTE:	1.0	AA-Y911A-1H-001		JUL 84
#RSX	PROFESSIONAL	HUST	100L KH	PROZIQUE NII COMMAND LANGZUTILI IES MARUAL	1.0	AA-1912A-14-(0)1		JUL #4

OPERATING		PRODUCT		YITLE OF		PART NUMBER REV	NUMBER UF	
SYSTEM		NAME		HANUAL	VERSION	FEAFF	FICHE	DATE
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC REFERENCE MANUAL	2.0-2.1	AA-L354A-FK-001	6	APR 83
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC REFERENCE MANUAL (UP) \$1)	2.2	AA-L334A-1N-002		JUL 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC USER'S GUIDE	2.0-2.1	AA-L335A-TN-001	3	APR 83
*RSX	PROFESSIONAL	TOOL KIT	RASIC-PLUS-2	RASIC USER'S GUIDE (UP141)	2.2	AA-L335A-1K-002		JUL 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	RASIC ON RSX-11H/H-PLUS SYSTEMS (UPD#1)	2.1	AA-L338A-TC-001	1	JAN 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-FLUS-2	BASIC ON RSX-11H/M-PLUS SYSTEMS (UPD#1)	2.2	AA-L338A-10-002		JUL 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC-PLUS-2 DOCUMENTATION SUPFLEHENT	2.1	AA-P102B-Th-001	1	JAN 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC-PLUS-2 DOCUMENTATION SUFFLEMENT	2.2	AA-F102C-+K-001	1	MAT 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	FRO TOOL KIT BASIC + 2 INSTL GDE/REL NIS	2.1	AA-P104R-TK-001	1	JAN 84
*RSX	PROFESSIONAL	TOOL KIT	RASIC-PLUS-2	PRO 10GL KIT BASIC-PLUS-2 92.2 SPN 30.27.01	2.2	AE-F650B-TK-001	1	MAY 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-PLUS-2	BASIC POCKET REFERENCE GUIDE	2.0-2.2	AV-L341A-TN-001	2	APR 83
WRSX	PROFESSIONAL	TOOL KIT	COROL-81	COROL-81 LANGUAGE REFERENCE MANUAL	2.1	AA-J434B-TC-001		JUL 84
*RSX	PROFESSIONAL	TOOL KI	COROL-81	RSX-11H/H-PLUS USER'S GUIDE	2.1	AA-M179R-Tu-001		JUL 84
*RSX	PROFESSIONAL	TOOL KIT	COBOL-81	PRO TOOL KIT COROL-81 INSTE GDE/DOC SUPL	2.1	AA-Y285A-1H-001		JUL 84
*RSX	PROFESSIONAL	TOOL KIT	COBOL-81	COROL-61 POCKET GUIDE	2+1	AV-H630C-TC-001		JUL 84
*RSX /	PROFESSIONAL	TOOL KIT	DIBOL	INTRODUCTION TO DINOL	1.0-1.6	AA-F042A-TK-001	1	APR 83
*RSX	PROFESSIONAL	TOOL KIT	DIBOL	PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE	1.6	AA-P043C-TK-001	2	MAY 84
*RSX	PROFESSIONAL	TOOL KIT	DIBOL	PROFESSIONAL TOOL KIT DIPOL PIL HIS/INSTE GDE	1.6	AA-F045U-1E-001	1	may 84
*RSX	PROFESSIONAL	TOOL KIT	DIBOL	DIBUL-83 LANGUAGE REFERENCE MANUAL (UPD#1)	1.6	AA-U066A-TK-001	2	FEB 84
<b>MRSX</b>	PROFESSIONAL	TOOL KIT	DIBOL	DIBOL-83 COMPAIIBILITY MANUAL	1.6	AA-V810B-1F-001	1	MAY 84
*RSX	PROFESSIONAL	TOOL KIT	DIROF	PRO FOOL KIT MESSAGE MANUAL	1.6	AA-2515A-1K-001	1	FEB 84
*RSX	PROFESSIONAL	TOOL KIT	DIROL	DIBOL-83 LANGUAGE REFERENCE CARD	1.6	AV-U06/A-1K-001		JUL 84
*RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77	PRO HOST TN K-7/ 16/00C SUPL	5.0	AA-R38/B-IN-001	1	John 64
*RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77	PDP-11 F-77 LANGUAGE REFERENCE MANUAL	5.0	AA-V193A-TF-001	3	FEB 84
#RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77	PDF-11 FORTKAN-77 USER'S GUIDE	5.0	AA-V194A-11-001	3	FEF 84
*RSX	PROFESSIONAL	TOOL KII	FORTERN-77	PIP-11 FORTRAN-77 OTS REFERENCE MANUAL	5.0	44-91954-IE-901	2	FEF 84

OPERATING	PRODUCT	TITLE		PAHT NUMBER REV	NUMBER	
SYSTEM	NAME	MANUAL	VERSIUN	LEVEL	FILHE	DATE
*RSX	PROFESSIONAL TOOL KIT FORTRAM-77	PRO 100L KII FORTRAN-77 V5.0 SPU 30.38.01	5.0	AE- <b>U</b> 58 '8-11-001	1	MAY 84
#RSX	PROFESSIONAL 100L KIT PASCAL	PRO TOOL KIT PASCAL INSTL/REL NOTES	1.1	AA-E7598-TK-001	1	MAY 84
*RSX	PROFESSIONAL TOOL KIT PASCAL	PRO FOOL KIT PASCAL USER'S GUIDE	1.1	AA-U046A-15-001	2	JAN 84
*RSX	PRCFESSIONAL TOOL KIT PASCAL	PRO TOOL KIT PASCAL LANGUAGE REFERENCE MANUAL	1.1	AA-U047A-TK-001	2	JAN 84
*RSX	PROFESSIONAL TOOL KIT PASCAL	PRO TOOL NIT PASCAL VI.1 SPD 40.20.00	1.1	AE-Y991A-TH-001		JUL 84
*RSX	RGL11	RGL-11 FROGRAMMER'S REFERENCE MANUAL	1.1	AA-8837A-16-001	3	AFR 83
*RSX	RGL-11	RGL-11 INSTALLATION GUIDE	1.1	AA-M838A-FL-001	1	AFR 83
*RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AA-M839E-16-001	1	FER 84
*RSX	RGL-11	RGL-11 V1.1 SPN 14.62.3	1.1	AL-MEOLD-TC-001	1	FES 84
#RSX	RGL-11	RGL-11 VI.1 SFU 14.62.04	1.1	AE-M802E-10-001	1	may 84
*RSX	RSX 11 2780/3780 EMULATOR	RSX-11 2780/3780 EMULATOR USER'S GUIDE	4 + 1	AA-J581A-[E-001	1	SEF 82
#RSX	RSX 11 2780/3780 EMULATUR	RSX11 2780/3780 EMUL V4.1 SFP 16.01.01	4.1	AE-N997F-11-001	1	MAY 84
₽RSX	RSX 11 PSI/H	INTRODUCTION TO RSX-11 PSI	2.0	AA-M36YA-TE-001	1	SEP 82
*RSX	RSX 11 PSI/M	RSX-11 PSI SYSIEM MANAGER'S GUILLE	2.0	AA-#370A-11-001	3	SEF 82
*RSX	RSX 11 PSI/M	RSX-11 FSI USER'S GUIDE	2.6	AA-M3/1A-FC-001	2	SEP 82
#RSX	RSX 11 PS1/M	RSX-11 FS1 GENERATION GUIDE	2.0	AA-m372A-1L-001	2	SEP 82
*RSX	RSX 11 PSI/H	RSX-11 PSI NETWORK SPECIFIC INFORMATION	2.0	AA-M3/3A-TU-001	1	SEP 82
*RSX	RSX 11 FSI/M	RSX-11 FSI RELEASE NOTES	2.0	AA-M3/4A-TC-001	1	SEP 82
*RSX	RSX 11 PSI/M	RSX-11 FSI/M V2.0 SPC 10.42.0	2.0	AE-N1418- FL-001	1	FER 84
*RSX	RSX 11 PS1/M	RSX-11 PSI REFERENCE CARD	2.0	AV-M/49A-10-001	1	SEP 82
*RSX	RSX 11/PROVUE	PROVUE SYSTEM MANAGER'S GUILLE	2.0	AA-M0218-TH-001	1	JAN 84
#RSX	RSX 11/PROVUE	PROVUE SYSTEM BUILD MANUAL	2.0	AA-M022P-IF-001	1	JAN 84
*RSX	KSX 11/PROVUE	PROPUE TERMINAL USER'S GUIDE	2.0	AA-m-238-fr-001	1	JAN 84
#RSX	RSX 11/FROVUE	PROVUE OFFLINE PICTURE SYSTEM MANUAL	, (1	AA-M024B-11, 001	1	स्थत १४
#RSX	RSX 11/PROVUE	PROVUE ONLINE PICTURE SISTEM MANUAL	<u>-</u> , n	AA-40258-11-001	1	JAN 84
₩RSX	RSX 11/FROVUE	PRODUE PROGRAMMING GUIDE	6. 8 4	AA-M0268-18-001	1	Joh ha

#### INDEX FOR THE CUPRENT SOFTWARE USER

FARA TITLE NUMBER NUMBER UE **OPERATING** PRODUCT 0F REV VERSION FILHE SYSTEM NAME MANUAL LEVEL HATE PROVUE UTILITY GUIDE **\$RSX** RSX 11/PROVUE 2.0 AA-M0278- [F-001 1 JAN 84 \*RSX **RSX 11/PROVUE** PROVUE V2.0 RELEASE NOTES 2.0 AA-8089R-15-001 1 JAN 84 2.0 RSX 11/PROVUE PROVUE V2.0 SPD 14.33.1 \*RSX AE-N2/18-TC-001 1 FEP 84 \*RSX PSX 11N 3271 PROTOCOL EMULATOR RSX-11/3271 PE PROGRAMMER'S GUIDE 3.0 AA-L/39R-1L-001 2 AFR B3 4A-07390-FE-001 3 \*RSX RSX 11M 3271 PRUTOCOL EMULATOR RSX-11/3271 PE SYSTEM HANAGER'S GUIDE 3.0 AFF 83 RSX RSX 11H 3271 PROTOCOL EMULATOR RSX-11/32/1 PE RELEASE NOTES 93.0 3.0 AA-H032L-10-001 1 AFF 83 **PRSX** RSX 11H 3271 PROTOCOL EMULATOR 414 83 3270 TERMINAL EMULATOR KEYBOARD LAYOUT 7.0 AU-F0/5A-TE-001 1 **BRSX** RSX 11M F ENHANC PKG FUR MINU SCIENTIFIC SUBROUTINES PROG FEE MAN (UPIN) 1.1-1.2 44-11011-((-(0)) AFF 83 ERSX RSX 11M F ENHANC PKG FOR HINC LAR SUBROUTINES PRUG REF MAN (UPD#1) 1.1-1.2 AA-E984C-[L-00] 3 APE 83 #RSX REX 11M F ENHANC PKG FOR MINC REALITH/HNC FORTTRAN PROG REF HAN (UPD:11-2) 1.1-1.2 AA-9631L-10-001 4 AFF 91 **PRSX** RSX 11M F ENHANC PKS FOR MINC INTRODUCTION TO FER AND FRE 1.1-1.2 4A-J302F-Y6-001 1 AFR: 83 \*RSX RSX 11H F ENHANC PKG FOR HINC RSX-11M FEP AND FRF INSTALLATION/USES GDE 1.2 AA-330311- [L-001 2 JAN 34 **BRSX** RSX 11M F ENHANC PKG FOR HINC RELEASE NUTES FOR RSX-11M/FEP AND FRE 1.2 AA-4055[I-TC-001 1 JAN 84 #RSX RSX 11H F ENHANC PKG FOR HINC ROL/II PROGRAMMER'S PEFERENCE MANUAL AF4: 83 1:1-1:2 AA-M83/A-TE-001 3 \*RSX RSX 11H F ENHANC PKG FOR MINC RSX-11M/FEF V1.2 SPE 14.44.4 1.. AE-L762E-11-001 1 FER 84 #RSX RSX 11H F ENHANC FKG FOR HINC RGL/11 FROGRAMMERS REFERENCE MANUAL ERRATA 1.2 AU-V185A-10-001 1 JAN 84 #RSX RSX 11N F ENHANC PKG FOR HINC REAL-11 PROGRAMMERS REFERENCE MANUAL EMMATA AU-V167A-FL-001 JUL 84 **XRSX** RSX 11M F ENHANC PKG FOR MINC SSF REFERENCE MANUAL ERRATA SHEET 1.7 AV-V1894-11-001 1 HAN HA #RSX RSX 11H F ENHANC PKG FOR MINC LSP REFERENCE MANUAL LARATA SHEET 1.2 AV-V190A-TC-001 1 JAN 84 **#RGX** RSX 11H F ENHANC PKG FOR HINC INTRO TO FEP & FRP ERRATA SHEET 1.1 49-9191A-11-905 1 JAN 84 #RSX RSX 11H F ENHANC FKG FOR HINC MICROCOMPUTERS AND MEMORIES HANDBOOM 1.1-1.2 28-20912-20-001 8 AFF 83 \*FSX RSX 11M F ENHANC PKG FOR MINC PRP-11 HICKUCOMPUTER INTERFALES HANDBOUN 1.1-1.2 (8-23144-18-061 ) ALK E3 \*RSX RSX IIM F ENHANC PKG FOR MINC DECLAR-11/MING USER S GUIDE LA -MN[ ! ] - [] [ - ( ) ] AFF 83 \*R3X RSX-11M F ENHANC PKG FOR MINU MINC THERMOCOUPLE FREAMPLIFIER USER'S HUTHE 1.1-1.2 Et-MALER UK (0) 1 SE 446 #RSX RSX 11M IAS RJE/HASF RUE/HASP WORKSTATION INSTALLATION SUIDE 1.1 AA-54.60=11-001 1 51 F F. \*RSX RSX 11H IAS RJE/HASP RUE/HASE MUNISTATION LIPERATUR 5 (41) IE 1.: AA -4 - [ - H ] 1 11 21

OPERATING SYSTEM	PRODUCT NAME	FITLE UF MANUAL	VERSIUN	PAM ( NUMBER REV LEVEL	NUMPER UF FICHE	إنفاإ
TRSX	RSX 11M TAS RJE/HASP	RSX11H 1AS RJE/HASP V1.1 SPB 10.51.6	1.1	AE-52480-10-001	1	FEB 84
*RSX	RSX 11M SNA PE	RSX11H/SHA FE CONCEPTS AND FACILITIES (UFU#1)	1.1	AA-5501A-1L-(9)1	) 60	3EF 82
*RSX	RSX 11H SNA PE	RSX11H/SNA FE SYSTEM MANAGER'S GUIDE (UFD#1)	1.1	AA-5502A-TL-001	2	SEF: 82
*RSX	RSX 11H SNA PE	RSX11M/SNA PE APPLICATIONS PROGRAMMER'S GUIDE	1.1	AA-5503K-10-001	2	SEP 82
*RSX	RSX 11M SNA PE	RSX11M/SNA PE RELEASE NOTES (UPD#1)	1.1	AA-J549A-IL-001	1	SEP 82
*RSX	RSX 11M SNA PE	RSX 11M SNA PE V1.1 SPU 14.04.1	1 1	AE-35126-16-001	1	FEF 84
*RSX	RSX DLX-11	RSX DLX-11 USER'S GUIDE	1.0	AA-K142A-TU-001	2	SEP 82
#RSX	RSX DLX-11	RSX DLX-11 RELEASE NOTES	1.0	AA-K143A-10-001	1	SEF 82
*RSX	RSX DLX-11	RSX DLX-11 V1.0 SPB 10.6.0	1.0	AE-K4348-TC-001	1	FEE 84
*RSX	RSX MDE/T11	HDE/3-11 USER'S GDE/REF MANUAL	1.0	AA-M845E-TK-(101	3	APR 83
*RSX	RSX MDE/T11	RSX11M/M+ MDE/III SETW INSTE GDE/REL NIS	1.0	AA-HY98A-16-001	1	APK 83
<b>tr</b> sx	RSX MDE/T11	RSX MDE/T-11 V1.0 SPR 14.23.0	1.0	AE-F0818-10-001	1	FEB 84
*RSX	RSX MDE/T11	HDE/T11 REFERENCE CARD	1.0	AV-H346E-TK-001	1	FEB 84
*RSX	RSX MDE/T11	MDE/T-11 V1.0 INSTE GRE/REL NIS	1.0	AV-P511A-10-001	1	AFE 83
#RSX	RTEM-11	RTEM-11 USER'S MANUAL	1.1	AA-N4358-TN-001	f) to	JAN 84
*RSX	RTEH-11	RTEM-11 USER'S GUIDE	2.0	AA-N4350-JK-001		may 84
*RSX	RTEM-11	RTEM-11 INSTE GUIDE/RELEASE NOTES (UPD#1)	1.1	AA-N436A-Fr-001	3	JAN 84
*RSX	RTEH-11	RTEM-11 INSTALLATION GUIDE	2.0	AP-N436R-18-001	1	MAY 44
*RSX	RTEM-31	RIEK-11 RELEASE NUTES	2.0	AR-W325A-TN-001	1	MAT 84
*RSX	RTEH-11	RTEM-11 V2.0 SPI 30.21.04	2.0	AE-N5/1E-15-001	1	may 84
PRSX	SORY-11	POP11 SORT REFERENCE MANUAL (UPDATE \$1)	2,0	AA-3341L-TU-001	,)	SEF 82
*RSX	<b>SORT-11</b>	SOR1-11 V2.0 SPD 12.7.5	2.0	AF-54296-16-001	1	FEB 84
#RSX	SSP-11	SCIENTIFIC SUP PROGRAMMER'S REF MAN (UP(11))	1.3	AA-11010-(L-001	)	SEF 82
ŧŘSX	SSP-11	SSP-11 V1.3 SPI 15,45.9	1.3	At-1413H (L-001	1	FLH W4
*RSX	SSP-11	\$SF-11 V1.3 SPD 15.45.10	1.3	AL-34,31 Te-(0.1)	1	MHT E4
*RSX	SSP-11	ADDENDUR TO SER	1 /	4F-86519-19-001		ाम मुक

OPERATING SYSTEM	PRODUCT Name	TITLE OF MANUAL	VERS10N	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
#RSX	UN1004	UN1004/RSX RELEASE NOTES	2.0	AA-13416-FC-001	1	SEP 82
*RSX	UN1004	UN1004/RSX USRS GDE/SYS GEN GDE (UFD#1)	2.0	AA-13428-TC-001	1	SEF 82
*RSX	UN1004	UN1004 92.0 SPf 10.79.06	2.0	AE-34540-TC-001	1	FEB 84
*RSX	VSV11-M DRIVER	VSV11-H SUFTWARE DRIVER GUIDE	2.0	AA-J287P-TK-001	1	SEP 82
#RSX	VSV11-H DRIVER	VSV11-M SOFTWARE DRIVER GUIDE	2.1	AA-J28/C-TR-001		JUL 84
*RSX	VSV11-N DRIVER	VSV11-M V2.0 RELEASE NOTES	2:0	AA-M615A-1C-001	1	JAN 84
*RSX	VSV11-N DRIVER	VSV11-H V2.1 SPD 14.53.03	2.1	AE-K8510-FC-001	1	FEB 84
*RSX	VTV31-K RSX11M DRIVE/SUB FKG	VTV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY	1.0	AA-M809A-10-001	1	APR 83
*RSX	VTV31-5 RSX11N DRIVE/SUR PKG	UTU31-K/RSX V1.0 SPD 14.73.0	1.0	AE-00/9A-TC-001	1	FEB 84
RSX	RSX-11H	EDT EDITOR MANUAL	4.1	AA-J726A-1C-001	3	E8 VUN
RSX	RSX-11H	EDT EDITOR REFERENCE CARD	4.1	AV-J/56A-T0-001	1	NOV 83
RSX	RSX-11M-PLUS	EDT EDITOR HANUAL	2+1	AA-J726A-TC-001	3	E3 VON
RSX	RSX-11M-PLUS	EDT EDITOR REFERENCE CARD	2.1	AV-J756A-TC-901	1	NOV 83
RSX	BCP	RSX-11H PCP USER'S GUIDE	1.0	AA-N269A-TE-001	2	SEP 82
RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE	1.0	AA-N060A-TC-001	1	APR 83
RSX	CHR11/CHV11 SOFTWARE DRIVER	CMR117CMV11 SUFTWARE IRIVER REFERENCE MANUAL	1.0	AA-N061A-1C-001	1	APR 83
RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/UNVII SOFTWARE DRIVER RELEASE NOTES	1.0	AV-N058A-TC-001	1	APR 83
RSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.0	AA-N959A-1C-001	1	APR 83
RSX**	OBSERVER	OBSERVER USER'S GUIDE	1.0	AA-NYSOA-TL-001	3	APR 93
RSX	ORSERVER	ORSERVER RELEASE NOTES	1.0	AA-N962A-1E-001	1	AFR 83
RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL LANGUAGE REFERENCE MANUAL	1.0	AA-M8/5A-TE-001	2	JAH 84
RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL USER'S GUIDE	1.0	AA-M876A-TL-001	2	JAN 84
RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL INSTALLATION GDE/REL NOTES	1.0	AA-#8/?A-TE-001	1	JAN 84
RSX	PROFESSIGNAL MOST TOOL KIT	PRO TOOL KIT INSTE GDE/REL MIS	1.9	99-N919R-1V-001	1	JAN 84
REX	PROFESSIONAL TOOL KIT DISUL	PROFESSIONAL TOOL NIT DIBOL USER'S GUIDE	1.0	AA-F043A-IN-G01	2	APR 83
RSX	PROFESSIONAL TOOL KIT DIROL	PROFESSIONAL TOOL KIT DIRDL LANG KEE MANUAL	1.0	AA-HO44A-1K-001	3	Vi-6 83

				PART			
		TITLE		N MBER	NUMBER		
OPERATING	PRODUCT	OF		REV	10		
SYSTEM	NAME	MANUAL	VERSION	LEVEL	FICHE	HATE	
RSX	PROFESSIONAL TOOL KI! DIBOL	PROFESSIONAL TOOL KIT DIBOL REL MISTINSFL GDE	1.0	AA-F045A- FK-001	1	AFF 83	
RSX	PROFESSIONAL TOOL KIT DIBOL	DIBOL LANGUAGE REFERENCE CARD	1.6	AA-U06/A-IN-001	1	MAY 94	
RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AA-M839A-TE-001	1	AFF 83	

### INDEX BY PART NUMBER

PART

NUMBER TITLE NUMBER REV 0F OPERATING PRODUCT (it FILHE LEVEL VERSION MANUAL SYSTEM HAME DATE SEP 81 IAS/RSX/VMS FORTRAN IV INSTL/REL NUTES VAX/VHS FORTRAN IV/VAX TO RSX AA-1821E-TC-001 2.5 AA-1855D-TC-001 2.5 PDP-11 FORTRAN LANGUAGE REFERENCE MANUAL VAX/VHS FORTRAN 10/VAX TO ESX SEP 82 PDP-11 FORTRAN-77 OTS REFERENCE MANUAL AA-1874C-TC-001 1.0 VAX/VHS NOU 83 PRO TOOL KIT FORTRAN-77 AA-1884D-TC-001 1.0 PDP-11 FORTRAN-77 USER'S GUIDE (UPD 11) VAX/VHS NOV 83 PRO YOOL KIT FORTRAN-7/ AA-1936F-TC-001 2.5 IAS/RSX/VAX/VMS FORTRAN IV USER'S GUIDE VAX/VHS FORTRAN JUZVAX TO RSX SEP 82 AA-25736-TC-001 4.0 RSX-11M/RSX-11S RELEASE NOTES #VAX/VHS RSX-11S SEP 92 AA-2593F-TC-001 4.0 RSX-11M/11S INFO DIRECTORY/INDEX #UAX/VMS RSX-115 SEF 82 AA-2600E-TC-001 4.0 RSX-11M GUINE TO WRITING 1/0 DRIVER \*VAX/UHS RSX-115 SEE 83 RSX-11S SYS GEN/INSL GDE (INCLUDES UPD#1) \*VAX/VMS SEP 82 AA-2874E-TC-001 4.0 RSX-11S AA-5075B-TC-001 1.4 PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL \*VAX/VHS M1CROPOWER/PASCAL-UPS FEB 94 SEP 82 AA-5075B-TC-001 4.0 PDP-11 MACRO-11 LANG REF MAN (INCLUBES UP041) \*VAX/VHS RSX-115 AA-5075B-TC-001 1.0 PDP-11 MACRO LANG REF MAN (INCLUDES#1) VAX/VHS FRO DEVELOPER'S FOOL KIT HAY 83 SEP 82 AA-5530B-TC-001 3.0-3.4 PDP-11 TECO USER'S GUIDE VAX/VHS SEF 82 AA-5580A-TC-001 4.0 IAS/RSX11 SYS LIB ROUT REF (INCLUDES UPD#1,2) #VAX/VHS RSX-119 MICROPONER/PASCAL-VMS INSTALLATION GUIDE \*VAY/VHS MICROPONER/PASCAL-VHS JUL 84 AA-AI16A-TE-001 1.5 AA-AI17A-TE-001 1.5 MICROPOWER/PASCAL-VHS RELEASE NOTES \*VAX/UNS MICROPOWER/PASCAL-UMS JUL 34 AA-AJ56A-TE-001 2.2 VAX DATATRIEVE INSTALLATION GUIDE \*VAX/VHS VAX-II CURAL-56 JUL 84 AA-AK13A-TK-001 1.5 MICROPONER/PASCAL-RSX/VMS SYS USER'S GUIDE VAX/VHS MICROPOWER/PASCAL-VHS JUL 84 AA-AK14A-TK-091 1.5 MICROPOWER/PASCAL-RSX/VMS HESSAGE MANUAL **RVAX/VHS** MICROPOWER/PASCAL - UME IUL 81 FEB 24 AA-AT45A-TK-001 4.0 BLISS POCKET GUIDE \*VAX/VHS VAX-11 BLISS-32 IMPLEM LANG AA-C7428-TC-001 2.4-2.6 USER'S GUIDE TO DATATRIEVE-11 #VAXZVMS PDF-11 BATATRIEVE/VAX SEI 82 SET 32 AA-C985A-TE-001 4.4 COROL-74 LANG REF MAN (INCLUDES UPB#1,2) VAXZVHS: VAX-11 COROL-74 AA-C986A-TE-001 4.4 VAX-11 COROL-74 USER'S GBE (INCLUDES UP0#1;2) VAX/VHS VAX-11 CUBOL-74 SEF BI · LE 81 AA-D015B-TE-001 3.0 VAX/VMS V3.0 RELEASE NOTES #UAX / VHS AA-DOIGE-TE-001 3.0-3.5 VAX-11 INFORMATION DIRECTORY AND INDEX #UAX/UMS AA-DO17C-TE-001 3.0-3.5 VAX/VHS SYS MESS AND RECOVERY PROC MANUAL #UAXZUHS 111 12

PART NUMBER REV LEVEL	VEKSION	TITLE OF HANUAL	OFERATING SYSTEM	FRODUCT NAME	FICHE OF	IIATE
AA-D018C-TE-001	3.0-3.5	VAX/VMS SYS SERVICES REF MANUAL	#VAX/VHS		5	SEF 82
AA-D019C-TE-001	3.0-3.5	VAX-11 LINKER REFERENCE MANUAL	*VAX/VMS		2	SEP 82
AA-D020C-TE-001	3.0-3.5	VAX-11/RSX-11H PROGRAMMER'S REFERENCE MANUAL	#VAX/VKS		2	SEP 82
AA-D022C-TE-001	3.0	VAX/VHS SUMMARY DESCRIPTION AND GLOSSARY	VAX/VMS		2	SEF 82
AA-B022C-TE-002	3.1-3.5	VAX/VMS SUMM DESC & GLOSSARY (INCLUDES UPD#1)	#VAX/VMS		6.4 4	MAR 83
AA-D023C-TE-001	3.0-3.5	VAX/VMS COMMAND LANGUAGE USER'S GUIDE	#VAX/VHS		8	SEP 82
AA-D024B-TE-001	3.0-3.5	INTRODUCTION TO VAXII RECORD MANAG SYS	#VAX/VHS		1	SEN 85
AA-D026D-TE-001	3.0-3.5	VAX-11 SYMBOLIC DEDUGGER REFERENCE MANUAL	¥VAX/VKS		3	SEF 92
AA-D030C-TE-001	3.0-3.5	VAX/VNS PRINER	*VAX/VMS		1	SEP 82
AA-DORID-TE-001	3.0-3.5	VAX-11 RMS REFERENCE MANUAL	*VAX/VHS		4	SEP 82
AA-D032D-TE-001	3.0-3.5	VAX-11 MACRO LANGUAGE REFERENCE MANUAL	*VAX/VHS		2	SEP 82
AA-D033D-TE-001	3.0-3.5	VAX-11 MACRO USER'S GUIDE	*VAX/VHS		2	SEF: 82
AA-9034C-TE-v01	3.0-3.4	VAX-11 FORTRAN LANGUAGE REFERENCE MANUAL	#VAX/VHS	VAX-11 FORTRAN	3	SEF 82
AA-D035C-TE-001	3.0-3.4	VAX-11 FORTRAN USER'S GUIDE	*VAX/VMS	VAX-11 FORTRAN	3	SEP 92
AA-D036C-TE-0G1	3.0-3.5	VAX-11 RTL REFERENCE MANUAL	#VAX/VHS		5	SEF 82
AA-D037C-TE-001	3.0-3.5	VAX-11/RSX-11M USER'S GUIDE	*VAX/VHS		3	SEP 82
AA-D110D-TC-001	2.4-2.6	DATATRIEVE-11 RELEASE NOTES	#VAX/VHS	PDP-11 DATATRIEVE/VAX	1	SEP 82
AA-D111B-TC-001	1.1	CORAL-66 LANGUAGE REFERENCE MANUAL	#VAX/VMS	VAX-11 CUFAL-65	2	SEP 82
AA-D111C-TC-001	1.1	CORAL-66 LANGUAGE REFERENCE MANUAL	#VAX/VHS	VAX-11 CORAL-66		JUL 84
AA-D111C-TK-001	2.0	CORAL-66 LANGUAGE REFERENCE MANUAL	*VAX/VHS	CURAL-66/VAX 10 RSX	2	mak 33
AA-D112B-TK-001	1.1	TAS/RSX/VMS CORAL-66 URS GDE (INCLUDES UP041)	*VAX/VHS	VAX-11 CORAL-66	4	SEF 82
AA-D112C-TK-001	2.0	CORAL-66 USER'S GUIDE	\$VAX/VMS	CORAL-66/VAX TO HSX	ģ	MAR 83
AA-B112C-TK-001	1.1	IAS/RSX/VMS CORAL-66 USERS GUIDE	#VAX/VMS	VAX-11 CORAL-66	4	FEB 84
AA-D113C-TE-001	3.0-3.5	VAX-11 SORT/MERGE USER'S GUIDE	#VAX/VHS		2	3EF 52
AA-D631C-TC-001	1.0	REAL-11 HNC F PRORGRAMMERS REF MAN (UPB#1,2)	VAX/VMS	REAL-11/115	4	JAY BA
AA-D643C-TE-001	3.0-3.5	VAX/VMS UETP USER'S GUIDE	#UAX/VHS		† 	LEF 1/2

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM		FRODUCT NAME	NUMBER OF FICHE	Pált
AA-D870A-TK-001		DX USER'S GUIDE	*VAX/VHS	DX/VMS		1	MAF 83
			*VAX/VNS	EX/UMS		1	MAR 22
AA-D874R-TE-001		INSTALLATION GUIDE				1	
AA-H169C-TC-001	2.4-2.6	DATATRIEVE-11 V2.4 INSTALLATION GUIDE	#VAX/VHS	FBF-11	BATATRIEVE/VAX	1	SEH 82
AA-H275C-TK-001	3.0	RLISS LANGUAGE GUIDE	VAX/VHS	VAX-11	BLISS-16 IMPLEM LANG	ó	SEP 82
AA-H275C-TK-001	3.0	VAX-11 BLISS-32 LANGUAGE GUIDE	VAX/VHS	VAX-11	RLISS-32 IMPLEM LANG	5	SEP 82
AA-H275C-TK-002	4.0	BLISS ( AMGUAGE GUIDE (UPD#1)	*VAX/VMS	VAX-11	BLISS-16 IMPLEM LANG	6	CER 84
AA-H275C-TK-002	4.0	VAX-11 BLISS-32 LANGUAGE GUIDE (UFD#1)	#UAX/UMS	VAX-11	PLISS-32 IMPLEM LANG	5	FEB 84
AA-H306B-TE-001	2.0	VAX-11/780 MPT USER'S GUILLE	*VAX/VHS	VAX-11	780 HICROPROGRAMMING TOOLS	2	MAR 83
AA-H307A-TE-001	2.0	VAX-11/780 DATA PATH DESCRIPTION	*VAX/VHS	VAX-11	780 MICROPROGRAMMING TOOLS	4	MAR 83
AA-H308R-TE-001	2.0	VAX-11/780 HPT RELEASE NOTES	*VAX/VMS	VAX-11	780 MICROPHOGRAMMING TOOLS	4	MAR 83
AA-H322C-TE-001	3.0	VAX-11 BLISS-32 USER'S GUIDE	VAX/VHS	VAX-11	BLISS-32 IMPLEM LANG	2	SEF 82
AA-H322D-TE-001	4.0	VAX-11 RLISS-32 USER'S GUIDE	<b>≭VAX/UHS</b>	9AX-11	BLISS-32 IMPLEM LANG	4	FER 84
AA-H473A-TE-001	1.3-1.4	VAX11 2780/3780 PE USRS GDE (INCLUDES UPD#1)	*VAX/VMS	VAX-11	2789/3780 PE	2	SEP 82
AA-H4B4B-TE-001	1.3	VAX-11 PASCAL LANGUAGE REFERENCE MANUAL	VAX/VMS	VAX-11	FASCAL	19	SEF 82
AA-H484C-TE-001	2.0-2.2	VAX-11 PASCAL LANGUAGE REFERENCE MANUAL	#VAX/VHS	VAX-11	FASCAL	4	HAR 83
AA-H485B-TE-001	1.3	VAX-11 PASCAL USER'S GUIDE	VAX/VHS	VAX-11	FASCAL	7	SEP 82
AA-H485C-TE-001	2.0-2.2	VAX-11 PASCAL USER'S GUIDE	#VAX/VHS	VAX-11	PASCAL	3	MAR 83
AA-H499C-TE-001	3.0-3.5	VAX/VMS GUIDE 10 WRITING A DEVICE DRIVER	*VAX/VMS			5	SEF 32
AA-H500C-TE-001	3.0-3.5	VAX-11 GDE TO CREATING MODULAR LIB PROCEDURES	*VAX/VMS			2	SEP 82
AA-H510D-TE-001		VAX-11 BLISS-32 RELEASE NOTES		U6Y-11	RL19S-32 IMPLEM LANG	1	SEP 32
AA-H510E-TE-001		VAX-11 BLISS-32 RELEASE NOTES			BLISS-32 INFLEM LANG	1	FER 84
AA-((5314-TE-001					780 MICROPROGRAMMING (OULS	2	MAR 23
AA-H625B-TG-001	1.	RSX-11 SYS GENERATION/INSIL GUIDE		RSX-11	5	4	SEP UT
AA-H631B-TE-001	2.0-2.2	VAX-11 COROL LANGUAGE REFERENCE MANUAL	*VAX/VHS	06X-11	COROL	7	EFr. 87
AA-H631C-TE-001	3.0	VAX-11 COROL LANGUAGE REFERENCE MANUAL	#VAX/VHS	VAX-11	CCBOL		301, 54
AA-H6778-TE-001	2.0-2.2	VAX-11 COROL USER'S GUIDE	FVAX/VHS	VAX-11	CURUL	5	EL1 42

PART NUMBER		TITLE	oper a vive	DIAGONAL	MUNBER	
REV LEVEL	VERSION	OF MANUAL	OPERATING SYSTEM	PRODUCT NAME	FICHE	1/41£
AA-H632C-TE-001	3.0	VAX-11 COBOL USER'S GUIDE	*VAX/VMS	VAX-11 COROL		JUL 84
AA-H781B-TE-001	3.0-3.5	VAX-11 UTILITIES REFERENCE MANUAL	*VAX/VMS		Ę	SEF 92
AA-H782B-TE-001	3.0-3.5	VAX/VHS GDE TO USING COMMAND PROCEDURES	*VAX/VHS		2	SEC 82
AA-H784B-TE-001	3.0-3.5	VAX/VMS REAL-TIME USER'S GUIDE	≉VAX/VHS		2	SEF 82
AA-H785B-TE-001	3.0-3.5	VAX-II PATCH UTILITY REFERENCE MANUAL	*VAX/VHS		2	SEP 82
AA-H800A-TE-001	1.2	VAX-11 DSM USERS GUIDE	VAX/VHS	VAX-11 uSM	3	SEP 82
AA-H800B-TE-001	2.0	VAX-11 DSM USER'S GUIDE	#VAX/VHS	VAX-II PSh	4	mar 83
AA-H802B-TE-001	3.0-3.5	DECNET-VAX USER'S GUIDE	*VAX/VHS		2	SEP 32
AA-H803B-TE-001	3.0	DECNET-VAX SYSTEM MANAGERS GUIDE	VAX/VHS		3	SEF 82
AA-H803B-TE-002	3.1-3.3	DECNET-VAX SYSTEM HAN GRE (INCLUDES UFT#1)	VAX/VHS		4	MAR 83
AA-HB03C-TE-001	3.4-3.5	DECNET-VAX SYSTEM MANAGER'S GUIDE	*VAX/VHS		-	PCT 83
AA-H803C-TE-001	2.1	DECNET-VAX SYSTEM MANGER'S BUIDE	*VAX/VHS	VAX-11 PST	5	MON 83
AA-H8228-TE-001	2.0-2.2	VAX-11 COBOL-74 TRANSLATOR UTILITY	‡VAX/VHS	VAX-11 (OPOL	1	SEP 82
AA-H822C-TE-001	3.0	VAX-11 COBOL-74 TRANSLATOR UTILITY	#VAX/VHS	VAX-11 COPOL		JUL 94
AA-H855A-TC-001	1.0	FMS-11/RSX/IAS SOFTWARE REFERENCE MANUAL	rVAX/VM5	PRO DEVELOPER'S FOOL XIT	3	MAY 83
AA-H857A-TC-001	1.0	FMS-11/RSX RELEASE NOTES	*VAX/VHS	PRO BEVELOPER'S FOOL NIT	1	wdik BS
AA-H865C-TK-001	3.0	VAX-11 BLISS-16 USER'S GUIDE	VAX/VHS	VAX-11 BLISS-16 IMPLET LANG	Δ	eft 65
AA-H865D-TE-001	4.0	VAX-11 BLISS-16 USER'S GUIDE	#VAX/VHS	VAX-11 BLISS-16 IMPLEM LANG	4	FEB 34
AA-H867A-TE-001	1.4	VAX11 BASIC LANG REF MAN (INCLUDES UFD#1:2:3)	VAX/VN5	VAX-11 BASIC	4	FC. 81
AA-H868C-TE-001	1.4	VAX-11 BASIC INSTE GUIDE/REL MOTES	VAX/VMS	VAY-11 FASIC	1	111 52
AA-H869A-TE-001	1.4	VAX-II BASIC USERS GDE (INCLUDES UFD#1:2:3)	VAX/VHS	VAY-11 BASIC	4	SE I
AA-H932A-TE-001	1.3	VAX-11 2780/3780 PE REL NTS (INCLUDES UF141)	VAX/VHS	WAX-11 2780/3780 PE	1	EE3.
AA-H932B-TE-001	1.4	VAX-11 2780/3780 PE RELEASE HUTES	#VAX/9M5	VAX-11 2'80/3780 PE	1	1 1 2
AA-H950A-TE-001	1.3-1.4	INTRODUCTION TO VAX-11 FL/1	FVAX/VMS	VAX -11 +L		cF1 85
AA-H951A-TE-001	1.3-1.4	VAX/VMS PL/I USER'S GUIDE	*VAX/UH5	9A1-11 PL-1	1	311 7
AA-H952A-TE-001	1.3-1.4	VAX-11 PL/I ENCYCLOPEDIC REFERENCE	#9A7/985	VA(1-12 + L/1	.1	11 32

PART NUMBER REV LEVEL	VERS10N	TITLE OF MANUAL	OPERATING SYSTEM	FFOULCT NAME	E TOHT OV ANWEFE	UATE
AA-H953E-TE-001	3.0-3.4	VAX-11 FORTRAN INSTE GDE/REL NOTES	#VAX/VHS	VAX-11 FORTRAN	1	51+ 80
AA-H954A-TC-001	1.2	MUX200/VAX EMULATOR USER'S GUIDE	*VAX/VHS	HUX200/V4X	1	MAR 32
AA-H955A-TC-001	1.2	HUX200/VAX EMULATOR SYSTEM MANAGER'S GUINE	*VAX/VHS	HUX200/VAX	1	HAR 8
AA-H956C-TE-001	1.2	MUX200/VAX EMULATUR RELEASE NOTES	*VAX/VnS	MUX200/JAX	1	944 EI
AA-J106A-TC-001	2.4-2.6	BATATRIEVE PRIMER	#VAX/V#5	POP-11 DAFATRIEVE/VAX	1	SE- 82
AA-J107B-TE-001	3.0	VAX-11 RTL LANG SUFF REF MAN	VAX/UHS		E <sup>®</sup>	SEL 82
AA-J107B-TE-002	3.1-3.5	VAX-11 RTL LANG SUPP REF MAN (INCLUDES UPD#1)	#VAX/VHS			map 83
AA-J179A-TE-001	1.3	PL/1 INSTL/SYS MAN GDE (INCLUDES UPP#1.2.83)	VAX/VHS	VAX-11 FL/1	1	SEP 82
AA-J179B-TE-001	1.4	VAX-11 PL/1 INSTL/SYS MANAGEMENT GUIDE	*VAX/VHS	VAX-11 FL/I	1	MAK 83
AA-J180A-TE-001	1.3	VAX-11 PASCAL PRIMER	VAY/VHS	VAX-11 PASCAL	#") do-	5LF 82
AA-J180B-TE-001	2.0-2.2	VAX-11 PASCAL PRIMER	#VAX/VHS	VAX-11 PASCAL	2	hAR 83
AA-J1818-TE-001	1.3	VAX-11 PASCAL INSTALLATION AND RELEASE MUTES	VAX/VHS	VAX-11 PASLAL	*	SEP 82
AA-J181C-TE-001	2.0-2.2	VAX-11 PASCAL INSTALLATION/RELEASE MOTES	*VAX/VHS	VAX-11 PASCAL	1	mAR 83
AA-J201A-TK-001	3.0-4.0	XPORT PROGRAMMERS GUIDE	AVAY/VHS	VAX-11 BL195-22 IMPLEM LANG	3	3Fr 85
AA-J260A-TE-001	1.1	VAX-11 FMS SOFTWARE REFERENCE MANUAL	VAX/VnS	VAX-11 FMS	3	· Er 82
AA-J261A-TE-001	1.1	VAX-11 FMS RELEASE NOTES	VAX/VHS	VAX-11 FMS	ł	SEt. 83
AA-J268B-TK-001	3.0-3.5	VAX-11 DSR USER'S GUIDE	#UAX/UMS		3	SEF 82
AA-J415A-TE-001	1.2	VAX-11 DSM LANGUAGE REFERENCE GUIDE	VAX/VM5	9AY-11 USH	3	Eb 57
AA-J415B-TE-001	2.0	VAX-11 DSM LANGUAGE REFERENCE MANUAL	#VAX/VHS	VAY-1. USP	-3	MA: 83
AA-J434B-TC-001	2.0-2.1	CORUL-81 LANGUAGE REFERENCE MANUAL .	#VAX/VHS	FR0 100E NJT C090E-81	0 68 1	HCD 03
AA-J526B-TE-001	3.0-3.5	VAX/VHS SYS DUMP ANLZ REF HANUAL	\$9A4/V#5			1 1 1
AA-J535A-TK-001	1.1-1.2	PLXY-11 USER'S GUIDE V1.1	VAX/VMS	PLKY 11/VAX		MAR II
AA-J535B-TK-001	1.3	PLXY-11 USER'S GUIDE	#VAX /UMS	PLY7-11/9AY	1	1.2
AA-J643B-TE-001	1.1	VAX-11 CORAL-66 RELEASE NOTES	#VAX/VHS	VAX-11 LUPAL-64	1	TLE E2
AA-J643C-TE-001	1.1	VAX-11 CORAL-66 RELEASE NOTES	#VAX /VHS	MAX-11 COPAL-66		JIJ, 34
AA-J691B-TE-001	2.0	VAX-11 3271 PROTUCOL EMULATOR USERS SUIDE	TVAX/VMS	945-11 42/1 BE		had be to

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	6-5-1841C7 113-14-1	FICHE MINITE	11 p 1 p 000
AA-J691B-TE-002 2	2.1	VAX-11 3271 PE USER'S GUIDE (UPD\$1)	#VAX/VMS	VAY-11 3271 FE		JUL 34
AA-J726A-TC-001 1	.0	EDT EDITOR MANUAL	VAX/VHS	PRO DEVELOPER'S 1001 KIT	1	cip .a
AA-J726A-TE-001 3	3.0-3.5	EDT EDITOR REFERENCE MANUAL	tVAX/VHS		3	FF11 32
AA-J8238-TE-001 3	5.0-3.5	COURSE ADMINISTRATION GUIDE	#VAX/VHS		1	SEF 92
AA-J824B-TE-001 3	3.0-3.5	INTRO TO THE EDI EDITOR STUDENT GUIDE	*VAX/VHS		0	28 m 85
AA-J942A-TK-001 1	.0	GIGI GRAPHICS EDITOR MANUAL	#UAX/VHS	G161 SOFTWARE	à	3EF : E0
AA-J943A-TK-001 1	1.0	GIGI SLIDE PROJECTION SYSTEM MANUAL	#9AY/V#5	GIGI SEFTWAFE	1	TLF 2.
AA-J944A-TK-001 1	1.1	GIGI DECRITE MANUAL	#VAY/VHS	POLYGEAF1X	1	JAH 84
AA-J956A-TK-001 1	1.1	GIGI DDF MANUAL	#VAX/VHS	FOLYGRAF ()		JUL 84
AA-J960A-TE-001 1	1.1	VAX-11 DRMS DML USERS MANUAL	VAX/VMS	VMX-11 05#5	<u>£</u>	HF 82
AA-J960A-TE-002 1	1.2-1.4	VAX-11 DBHS OHL USERS HANUAL (INCLUDES UPD#1)	17A1/VHS	VAX-11 DBms	3	mak 83
AA-J961A-TE-001 1	1.1	VAX-11 DRMS DDL REFERENCE MANUAL	VAX/VMS	VAX-11 DEMS	3	3fb = 55
AA-J961A-TE-002 1	1.2-1.4	VAX-11 DRMS DDL REF HANUAL (INCLUDES UPD+1	1UAX/UN5	VAX-11 DEMS	7	MAR 83
AA-J962A-TE-001 1	1.1	VAX-11 DRMS UTILITIES REFERENCE MANUAL	94) /VHS	VAX-11 1845	3	T., 83
AA-J962A-TE-002 1	1.2-1.4	VAX-11 DBMS UTIL REF MAN (INCLUDES UPD#1)	10AX/PHS	Nex-11 084.	1	MAN 83
AA-J964A-TE-001 1	1.1	VAX-11 DEMS SUMMARY DESCRIPTION	VAX/VhS	94X-11 PBM5	66	9£1: 82
AA-J964A-TE-002 1	1.2-1.4	VAX-11 DBMS SUMMARY DESCRIP (INCLUDES UPD#1)	tVAY/VHS	VAX-11 DUMS		MAR 81
AA-J965B-TE-001 1	1.1	VAX-11 DRMS INSTE GUE/REL NOTES	THE/UNS	ANA 11 NEWS		El .:
AA-,1965C-TE-001 1	1.2	VAX-11 DBMS ENSTE GDE/REE NOTES	VAX/UHS	NAT II URMS	1	मन्। ११
AA-J965D-TE-001 1	1.3	MAX-11 DBMS INSTALLATION GDE/REL MOTES	UAX/VhS	NAX-11 litms	1	FARL SE F
AA-J965E-TE-001 1	1.4	VAX-11 DRMS INSTALLATION GUIDE/REL MOTES	*VAX/VHS	VAX-11 (CAS	+	h + 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
AA-J966A-TE-001 1	1.1	VAX-11 DRMS DEA MANUAL	Up (77)PC	Add 11 DBWC		cft ".
AA-J966A-TE-002 1	1.2-1.4	VAX-11 DRMS BBA MANUAL (INCLUDES DERFI	\$U077795	Adr-11 Winc		м Да 😟
AA-K020A-TE-001 1	1.0	VAX-11 RGL PROGRAMMERS REF MANUAL	FUAR VMS	Whitell effile skapation is the		=s {
AA-K021A-TE-001	1.0	VAX-11 DYJ2 SYS.EM MANAGERS GUIDE	UAY, VAS	VAT 11 DT3.		F4 4
AA-KO21A-TE-002 1	1.1	VAX-11 DY32 MANAGERS GOE (INCLUDES UP 111)	NAXIONE	MAY II IIV		ы 1, 1

FART NUMBER REV LEVEL	VERS10N	TITLE OF MANUAL	OPERATING SYSTEM		Senting 1	១ បែក ប្រ ការមនិត្តប	[2]	12
AA-K021B-TE-001 2	2.0-2.1	VAX-11 BY32 SYSTEM MANAGER'S GUIDE	#VAX/VHS	VAX-11	fix i	99	ilini	ñ.i
AA-K022A-TE-001 1	1.0-1.1	VAX-11 0Y32 APPLICATION PROGRAMMERS MANUAL	VAX/VMS	9AY-11	0332	4	; 5	3-0
AA-K022A-TE-002 2	2.0-2.1	VAX-11 DY32 APPE PROG ODE (INCLUDES UPD#1)	#VAX/VHS	VAX-11	fry32	1	41.8	2.
AA-K026C-TE-001 2	2.0-2.1	VAX-11 COROL INSTE GUIDE/REL NOTES	#VAX/VHS	VAX-11	LORUL	1	off 3	12
AA-K026[-TE-001 2	2.2	VAX-11 COROL INSTE GUIDE/REL NOTES	#VAX/VMS	VAX-11	COPOL	1	1 ( )	: A
AA-K079A-TE-001 1	1.2-1.3	VAX-11 OTR REF MANUAL (INCLUDES UPD#1+2)	VAY/VMS	VAX-11	DATAIRIEVE	Ç	SEr S	3.0
AA-K0798-TE-001 2	2.0-2.1	VAX-11 DTR REFERENCE MANUAL	#VAX/VHS	VAX-11	DATATRIEVE	5	001 8	33
AA-K080A-TE-001 3	1.2-1.3	VAX-11 NATATRIVE USER'S GUINE	VAX/VMS	VAX-11	Delatkituk	7	ôfe ê	20
AA-K080B-TE-001	2.0-2.1	VAX-11 DTR USER'S GUIDE	*VAX/VMS	VAX-11	DATATRIEVE		11 1 8	33
AA-K081A-TE-001 1	1.2-1.3	VAX11 DTR CALL INTERFACE MAN (INCLUDES UPDA1)	VAX/VMS	96X-11	LATATELEVE	1	SEP	12
AA-K082A-TE-001 1	1.2-1.3	INTO TO VAX-11 DIR (INCLUDES UPD#1+2)	VAX/VHS	VAX-11	DATAFRIEVI.	3	56 8	3.
AA-K082B-TE-001 2	2.0-2.1	INTRODUCTION TO VAX-11 DATATRIEVE	*VAX/VHS	VAX-11	DATATELEDE	1	901 E	:3
AA-K083C-TE-001 1	1.2	VAX-11 INSTALLATION GUIDE/RELEASE MOTES	VAX/VMS	VAX-11	DATATRIEVE	1	SEP 1	32
AA-K083D-TE-001 1	1.3	VAX-11 INSTALLATION GUIDE/RELEASE HOTES	VAX/V <b>H</b> S	VAX-11	DATATRILL'E	1	MAR 8	17
AA-K083E-TE-001	2.0	VAY-11 INSTL GUIDE/RELEASE NOTES	*UAY/UHS	VAX-11	DATAIFIEVE	9 1 de	CLT (	3 4
AA-K083F-1E-001 2	2.1	VAX-11 DATATRIEVE INSTALLATION GDE/REL NOTES	#VAY/UHS	94)(-11	PATRIETAL	2	LFR 3	<u> 4</u>
AA-K085A-TE-001	2.0	VAX-11 CND DEF LANG REF MANUAL	VAX/VMS	VAX-11	CUMMON WATE LUCTIONARY	1	St 1 8	}
AA-K085A-TE-002 2	2.1	VAX11 CMD DEF LANG REF MAN (INCLUDES UPD41)	VAX/VHS	VAY-11	YIGREEFFE ATAL MORMUS	du .	mpt &	. 2
AA-K085A-TE-003 2	2.2	VAX-11 CDD DDL MANUAL (INCLUDES UPD11 % 2)	PVAX/VMS	VAX-11	COMMON DE LA DICTIONATI		MBU (	4.
AA-K0858-TE-001 2	2.3	VAX-11 CDB THE MANUAL	*VAY/VH5	VAY-11	COMMUNICATA PICTIONALI		f_L	å
AA-K2218-TE-001	1.3-1.4	VAX-11 FE/I GUIDE TO PROGRAM DEBUSGING	#UAX/774S	VAX-11	PLC	1	. { }	}_
AA-K337A-TK-001 1	1.0	GIGI CHARACTER SET EDITOR MANUAL	tuay/yes	6161 5	DE THAPE	î a	eit :	2
AA-K410B-TE-001	3.0	VAX-11/750 SOFTWARE INSTALLATION GUIDE	VAX ZUBS				1 6	12
AA-K410R-1E-002 3	3.1	VAX-11/750 SETW INSTE ONE (INCLUDES UF 042)	VAX /VAS			1	fiA <sup>L</sup> :	.7
AA-X410C-TE-001 .	3.2-3.5	VAX-11/750 SOFTWARE INSTALLATION GUIDE	#VAX/VMS			9	AFF 8	3 1
AA-K420B-TC-001	3.5	PDF-11 TECO USER'S GUIDE	#UAT /UHS				111 5	24

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	PRUDUCT MANE	MUMEER OF FICHE	hatE
AA-N640E-TE-001	2.3	VAX-11 CDD INSTALLATION GUIDE/REL NOTES	#VAX/VHS	VAX-11 COMMON BATA DICTIONARY		JUL 34
AA-K642B-TE-001	4.4	VAX-11 COBOL-74 INSTL GUIDE/REL NOTES	VAX/VHS	VAX- 1 C080E-74	1	cEt 22
AA-K676A-TK-001	1.2	INTRODUCTION TO DSM	VAX/VHS	VAX-11 DSM	?	SEF 31
AA-K752B-TE-001	3.0	PLISS-16 RELEASE NOTES V3.0	VAX/VHS	VAX-11 BLISS-16 IMPLEM LANG	1	SEI: 82
AA-K752C-TE-001	4.0	BLISS-16 RELEASE NUTES V4.0	≉VAX/VHS	VAX-11 BEISS-16 InFLEM LANG	1	FE2 84
AA-K757R-TE-001	2.0	VAX-11 3271 PROTOCOL EMULATOR RELEASE NOTES	#VAX/VHS	VAX-11 3271 PE	1	mAR 83
AA-K763A-TE-001	1.0	DIMENSION AUTHORING LANGUAGE AUTHORS GUIDE	XVAX/VMS	COURSEWARE AUTHORING SYSTEM	***	mar 83
AA-K764A-TE-001	1.0	DIMENSION AUTHORING SYSTEM USER'S GUIDE	*VAX/VHS	COURSENARE AUTHORING SYSTEM	1	MAY 83
AA-K766A-TE-001	1.0	D.A.S. INSTALLATION GUIDE/RELEASE NOTES	#VAX/VHS	COURSEWARE AUTHORING STRIEN	1	MAY 83
AA-K767A-TE-001	1.0	D.A.S. SYSTEM MANAGER'S GUIDE	*VAX/VHS	COURSEWARE AUTHORING SYSTEM	1	58 130
* AA-K767C-TE-001	2.1	VAX-11 3271 PROTOCOL EMULATOR RELEASE NOTES	*VAX/VMS	VAX-11 3271 FE		JUL 84
AA-K768A-TE-001	1.0	D.A.S. LANGUAGE REFERENCE MANUAL	*VAX/VMS	COURSEWARE AUTHORING SYSTEM	\$	MAY 83
AA-K787A-TE-001	1.1	VAX-11 DBNS FDML REFERENCE MANUAL	VAX/VHS	VAX-11 ORMS	4	Str 82
AA-K787A-TE-002	1.2-1.4	VAX-11 DBMS FDML REF MANUAL (INCLUDES UPD#1)	#VAX/VHS	VAX-11 19885	2	MAF 83
AA-K793B-TE-001	2.1	VS11 V2.0/VAX SUFTWARE DRIVER GUIDE	*VAX/VMS	VS11-VAX DRIVER	1	46K 83
AA-L011A-TK-001	1.0	BASIC TRANSPORTABILITY HANUAL	*VAX/VHS	BASIC TRANSPURTABILITY PACKAGE	de de	SEP 82
AA-L057A-TE-001	1.3-1.4	PROGRAMMING IN VAX-11 FL/1	*VAX/VHS	VAX-11 PL/I	5	9CF 82
AA-L058A-TE-001	1.0	GIGI PKG A INSTL PROC/RELEASE NOTES	VAX/VHS	61GI SOFTWARE	1	FEF- 82
AA-L058A-TE-002	1.0	GIG PKG A INSL PROC/REE MTS (INCLUDES UPD#1)	*VAX/VnS	GIG1 SUFTWAPE	1	mar 83
AA-L067A-TE-001	1.2	INTRODUCTION TO VAX-11 PS1 (INCLUDES UPI41)	UAX/UHS	VAX-11 FSI	1	Mak 33
AA-L067A-TE-002	2.0-2.1	INTRODUCTION TO VAX-11 PS1 (UPD41 & #2)	*VAX/VMS	VAX-11 FSI	1	MT1 본분
AA-L068A-TE-001	1.2	VAX-11 PSI SYS MANAGERS GIE (INCLUDES UPIM1)	VAXZVHS	VAX-11 FS1	* ( ) do	Is Ren
AA-L069C-TE-001	1.2	VAX-11 PSI INSTALLATION PROCEDURES	VAX/VHS	VAX-1, PS1	1	हुउ तथ
AA-L069D-TE-001	2.0-2.1	VAX-11 PSI INSTALLATION PROCEDURES	#UAY, UMS	VAX-11 FUI	1	AC 32
AA-L070A-TE-001	1.2	VAX: 11 PSI USER'S SUIJE (INCLUDES UFD#1)	VAX. UMS	VAK-11 PS1		MAS 53
AA-L071B-TE-001	1.2	VAX-11 PS1 NETWORK SPECIFIC INFURNATION	VAX/VMS	VAX-11 F5!		MI Ex 11

PART NUMBER TITLE NUMBER OF OPERATING PRODUCT 1JE REV LEVEL **VERSION** MANUAL SYSTEM NAME FICHE WATE AA-L072C-TE-001 1.2 VAX-11 PSI RELEASE NOTES V1.2 VAX/VMS MAX-11 PSI MAR 83 AA-L072E-TE-001 2.1 VAX-11 PSI V2.1 RELEASE NOTES #VAX/VHS VAX-11 FS1 001 83 AA-L318A-TE-001 2.0-2.1 INTRODUCTION TO VAX-11 FMS #VAX/VHS VAX-11 FHS MAY 83 VAX-11 FHS FORM DRIVER REF MANUAL AA-L319A-TE-001 2.0-2.1 \*VAX/VHS VAX-11 FME MAY R3 MAY 63 AA-L323A-TE-001 2.C-2.1 VAX-11 FMS UTILITIES REFERENCE MANUAL \*VAX/VHS VAX-11 FHS AA-L321A-TE-001 2.0 VAX-11 FMS INSTL GOE/REL NOTS VAX/VHS VAX-11 F#S may 83 AA-L321B-TE-001 2.1 VAX-11 FMS INSTALLATION GUIDE/RELEASE NOTES \*VAX/VMS VAX-11 FMS NUV 83 AA-L3344-TK-001 2.0-2.1 BASIC REFERENCE MANUAL #VAX/VHS PRO TOOL HIT BASIC-PLUS-2 MAY 83 AA-L334A-TK-001 2.0-2.1 PASIC REFERENCE MANUAL #VAX/VHS VAX-11 BASIC MAY 83 AA-L334A-TK-002 2.2 LASIC REFERENCE MANUAL (UPIMI) #VAX/VHS PRO 100L NIT BASTC-PLUS-2 JUL 114 AA-L334A-TK-002 2.2 BASIC REFERENCE MANUAL (UPD#1) #VAX/VHS VAX-11 BASIC JUL 24 AA-1.335A-TK-001 2.0-2.1 BASIC USER'S GUIDE #VAX/UHS FRU 100L KIT BASIC-PEUS-2 MAY 83 AA-L335A-TK-001 2.0-2.1 BASIC USER'S GUIDE **\*VAX/VHS** VAX-11 BASIC MA1 83 AA-L335A-TK-002 2.2 BASIC USER'S GUIDE (UPI#1) \*9AX/96S PRO FOOL KIT BASIC-PLUS-2 JUL 24 AA-L335A-TK-002 2.2 BASIC USER'S GUIDE (UPD#1) #VAX/VHS VAX-11 BASID JUL 84 AA-L336A-TK-001 2.0-2.2 BASIC UN VAX/VMS SYSTEMS \*VAX/VHS VAX-11 BASIC MAY UZ AA-L338A-TC-001 2.0 BASIC ON RSX-11H/H-PLUS SYSTEMS VAX/VHS PRO TOOL KIT BASIC-PLUS-2 MAY 83 AA-L338A-TC-002 2.1 RASIC ON REXIIM/M-PLUS SYSTEMS (UPIL \$1) **\*VAX/VMS** PRO 100L NIT PASIC-PLUS-2 M39 83 AA-L338A-TC-003 2.2 BASIC ON RSX11M/M-FLUS SYS (UFD#1 % #2) #VAX/VhS PRO FOOL KIT BASIC-FLUS-2 JUL 84 AA-L339A-TE-001 2.0 VAX-11 BASIC INSL GDE/RELEASE NOTES VAK/UNS CLEAR 11-XAV HAY HE AA-L339B-TE-061 2.1-2.2 VAX-11 BASIC INSTL GUIDE RELEASE NOTES \*VAX/VMS VAY-11 PASIC 001 83 AA-L369A-TE-001 2.2 PROGRAMMING IN VAX-11 PASCAL \*VAX/VHS VAX-11 PASCAL DIT 53 AA-L370A-TE-001 1.0-1.4 PROGRAMMING IN VAX-11 C #VAX/VMS 2AX-1: C SE 8. AA-L371A-TE-001 1.0-1.1 USER INTRODUCTION TO DECYCHS \*VAX/585 MAX-11 DEC7LMS SE1 =2 AA-L372A-TE-001 1.0-1.1 DEC/CHS REFERENCE MANUAL \*VAX/VAS VAX-II DEL/CHS AA-L373A-TE-001 1.0-1.1 DEC/CMS INSIL AND SYSTEM MANAGERS GUIDE \*96):/UMS MAX-11 PEC/EMS SEP 82

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPEKATING SYSTEM	FRODUCT NAME	ETCHE OF MUNIVER	nate.
AA-L629B-TE-001	2.0	VAX-11 CDD UTILITITES REFERENCE MANUAL	VAX/VMS	VAX-11 COMMON DATA DICTIONARY	2	SEP 82
AA-L629B-TE-002	2.1	YAX-11 CDD UTILITIES REF MAN (INCLUDES UPD#1)	VAX/VMS	VAX-11 COMMON DATA DICTIONARY	<u></u>	MAF 83
AA-L629B-TE-003	2.2	VAX-11 CDD UTILITY MANUAL (INCLUDES UPD*182)	*VAX/VHS	VAX-11 COMMON BATH DICTIONARY	2	NOV 83
AA-L629C-TE-001	2.3	VAX-11 CDD UTILITY HANUAL	*VAX/VHS	VAX-11 COMMON DATA DICTIONARY	2	rER 84
AA-L630B-TE-001	2.0-2.1	VAX-11 CDD INSTL GDE/REL NOTES	VAX/VMS	VAX-11 CUMMON DATA DICTIONARY	1	SEF 82
AA-L630D-TE-001	2.2	VAX-11 CDD INSTE GDE/REE NTS	*VAX/VHS	VAX-11 COMMON PATA DICTIONARY	1	0L1 83
AA-L631A-TE-001	1.2-1.3	VAX DATATRIEVE GRAPHIC NOTEBOOK	VAX/VMS	VAX-11 DAFATRIEVE	1	SEP 82
AA-L631B-TE-001	2.0-2.1	VAX-11 DATATRIEVE GUIDE TO GRAPHICS	≭VAX/VHS	VAX-11 DATATRIEVE	2	GET 83
AA-L632A-TE-001	1.1	VAX-11 DATATRIEVE/DBMS INTERFACE MANUAL	VAX/VMS	VAX-11 RRMS	1	SEF 82
AA-L632A-TE-002	1.2-1.4	VAX-11 DTR/DBMS INTRFACE MAN (INCLUDES UPD#1)	*VAX/VHS	VAX-11 TEMS	1	MAR E3
AA-L669A-TC-001	1.0	RMS-11 USER'S GUIDE	#VAX/VMS	PRO DEVELOPER'S 100L KIT	<u> </u>	FER 94
AA-L670A-TC-001	1.0	RMS-11 UTILITIES MANUAL	*VAX/VHS	PRO DEVELOPER'S TOOL KIT	3	FER 84
RA-L673A-YC-001	4.0	RSX11H/H+ CRSH DUMP ANZL FEF (INCLUDES UPD#1)	*VAXZVHS	RSX-11S	3	SEF 82
AA-L675A-TC-001	4.0	RSX-11H/M-PLUS EXECUTIVE REFERENCE MANUAL	*VAX/VHS	RSX-11S	4	SEF: 82
AA-L676A-TC-001	4.0	RSX-11H/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	*VAX/VhS	RSX-119	2	SEF 82
AA-L677A-TC-001	4.0	RSX-11M/M-PLUS I/O DRIVERS REFERENCE MANUAL	*VAX/UMS	RSX-11S	6	SEF: 82
AA-L678A-TC-001	4.0	RSX-11M/M-PLUS MCR OPERATIONS MANUAL	≭VAX/VHS	RSX-119	5	SEP 82
AA-L679B-TC-001	4.0	RSX-11H/H-PLUS SYSTEM MANAGEMENT GUIDE	#VAX/VHS	RSX-11S	6	SEF 82
AA-L680A-TC-601	4.0	RSX11N/M+ TASK BLDR MANUAL (INCLUDES UFD\$1)	*VAX/VHS	RSX-11S	5	SEP 82
AA-L680A-TC-001	1.0	RSX11H/H+ TASK BEDR MANUAL (INCLUDES UPD#1)	VAX/VHS	PRO DEVELOPER'S FOOL KIT	5	may 83
AA-L680B-TC-001	1.0	RSX11H/H+ TASK BUILDER MANUAL	*VAX/VHS	PRO DEVELOPER'S TOOL KIT	ŧ	1-1: t - 84
AA-L689A-TE-001	1.0-1.1	VAX-11 DIBUL USER'S GUIDE	VAX/VMS	VAX-11 LEFEL	1	SEF 82
AA-L6898-TE-001	2.0	VAX-11 DIBOL USER'S GUIDE	#VAX/VHS	VAX-11 DIEUL	4	Ct 1 83
AA-L690A-TE-001	1.0-1.1	VAX-11 DIROL LANGUAGE REFERENCE MANUAL	VAX/VMS	VAX-11 DIBOL	2	SEP 32
AA-L691A-TE-001	1.0	VAX-11 DIROL RELEASE NOTES/INSTL GUIDE	VAX/VHS	VAY-11 DIFUE	1	100 Br
AA~L691B-TE-001	1.1	VAX-11 DIROL RELEASE NOTES/INSTL GUIUE	VAX/VMS	WAX-11 DIFUL	» A	MAR 23

PART Number Rev Level	VERSION	TITLE OF MANUAL	OPEKATING SYSTEM	PRUDUCT NAME	NUMBER OF FIURE	21A1
AA-L691C-TE-001	2.0	VAX-11 DIBOL RELEASE NOTES/INSTL GUIDE	*VAX/VHS	VAX-11 BIROL	1	001-83
AA-L724A-TE-001	1.1-1.2	PLXY-11 VAX V1.1 INSTALLATION NOTES	VAX/VHS	PLXY-11/VAX	1	MAF 83
AA-L763A-TC-001	4.0	INTRO TO RSX-11N AND RSX-11M-PLUS	#VAX/VHS	RSX-11S	2	SEF 82
A4-LB06B-TE-001	2.0	DECMAIL USER'S GUIDE	*VAX/VHS	VAX-11 DECHAIL	3	SS HUUL
AA-L808B-TE-001	2.0	DECHAIL ACCOUNT COORDINATOR'S GUIDE	#VAX/VMS	VAX-11 DECMAIL	1	JUNE 83
AA-L809B-TE-001	2.0	DECHAIL SYSTEM MANAGER'S GUIDE	#VAX/VHS	VAX-11 DECHAIL	1	JUNE 83
AA-L810C-TE-001	2.0	DECMAIL INSTALLATION GUIDE	‡VAX/V <del>H</del> S	VAX-II PECHAIL	1	JUNE 83
AA-LB24A-TE-001	3.0-3.5	VAX-11 RUN-TIME LIBRARY USER'S GUIDE	#VAX/VHS		3	SEP 82
AA-L881A-TE-001	1.0	VAX-11 DY32 RELEASE NOTES	VAX/VHS	VAX-11 IY32	1	SEP 82
AA-L881B-TE-001	1.1	VAX-11 DY32 RELEASE NOTES	VAX/VHS	VAX-11 1932	1	HAR 83
AA-L881C-TE-001	2.0	VAX-11 DY32 RELEASE NOTES	VAX/VMS	VAX-11 0732	1	001 83
AA-L881D-TE-001	2.1	VAX-11 DY32 RELEASE HOTES	*VAX/VM5	VAX-11 0Y32	1	DCT 83
AA-L979A-TC-001	1.0	PDP-11 FORTRAN-77 LANG REFERENCE HAN UPD#1)	VAX/VHS	PRO TOOL NIT FORTFAN-77	3	MOA 83
AA-NO21B-TK-001	2.0	PROVUE SYSTEM MANAGER'S GUIDE	*VAX/VHS	VAX-11 PROVUE	1	JUN 83
AA-H022B-TK-001	2.0	PROVUE SYSTEM BUILD MANUAL	*VAX/VH5	VAX-11 PHOVUE	1	JUN 83
AA-NO238-TK-001	2.0	PROVUE TERMINAL USER'S GUIDE	#VAX/VHS	VAX-11 PROVUE	***	28 MAC
AA-H024B-TK-001	2.0	PROVUE V2.0 OFFLINE PICTURE EDITING SYSTEM	#VAX/VMS	VAX-II FRUVUE	1	:8 MUL
AA-H025B-TK-001	2.0	PROVUE V2.0 UNLINE PICTURE EDITING SYSTEM	*VAX/VMS	VAX-11 PROVUE	1	IUM BI
AA-H026B-TK-001	2.0	PROVUE V2.0 PROGRAMMER GUIDE	#VA K/VMS	AUX-11 SURARE	1	314 83
AA-H0278-TK-001	2.0	PROVUE V2.0 UTILITY GUIDE	*VAX/VIIS	WAY-11 PROVUE	1 1	WW 81
AA-N045A-TE-001	1.1	VAX-11 FMS UPDATE NOTES (INCLUDES UPD#1)	VAX/VIIS	VAX-11 FMS	1	SEF 82
AA-N056A-TE-001	1.0-1.1	VAX-11 TDMS SUMMARY DESCRIPTION	*VAX/V#5	VAX-11 19MS	9	304 33
AA-H057A-TE-001	1.0	VAX-II TOMS INSTALLATION GUIDE	VAX/Uns	VAX-11 (Unis	1.	J94 83
AA-HJ57B-TE-001	1.1	VAX-11 TDMS INSTALLATION GUIDE	*VAY/VHS	VAY-11 TUME	4	41.87
AA-N058A-TE-001	2.0-1.1	VAX-11 TUMS FORMS MANUAL	*VAX/UHS	VAX-11 /DMS	2	0.64
AA-H059A-TE-001	1.0-1.1	VAX-11 TUMS REQUEST MANUAL	AVAX/VES	VAY 11 LIMS	à	JUH 13

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	UPERATING SYSIEM	PRODUCT NAME	NUMEER OF FICHE	li41£
AA-H060A-TE-001	1.0-1.1	VAX-11 TUMS APPLICATION PROGRAMMING MANUAL	*VAX/VMS	VAX-11 (UM5	4	JUN 83
AA-H061A-TE-001	1.0-1.1	VAX-11 TUMS SAMPLE APPLICATION MANUAL	*VAX/VHS	7AX-11 11MS	1	in 81
AA-M062A-TE-001	1.0	VAX-11 TDMS RELEASE NOTES	VAX/VHS	VAX-11 FRHS	1	JUN 83
AA-H062B-TE-001	1.1	VAX-11 TIMS RELEASE NOTES	EMU/XAVA	VAY-11 TUMS	1	001 83
AA-M089B-TK-001	2.0	PROVUE V2.0 RELEASE NOTES	#VAX/VHS	VAX-11 PROVUE	1	JUN 83
AA-N090B-TE-001	2.0	DECMAIL INTERCONNECT GUIDE	#VAX/VHS	VAX-11 DECMAIL	4 4	JAME 83
AA-H145B-TK-001	2.0	VAX TO RSX CROSS COMP INSTL GUE AND REL NIS	≭VAX/VMS	CORAL-66/VAX TO RSX	1	MAF 93
AA-H176A-TC-001	4.G	TAS/RSX-11 I/O OPERATIONS MEFERENCE MANUAL	*VAX/VHS	RSX-11S	3	SEP 82
AA-H179B-TC-001	2.0-2.1	COBOL-81 RSX11H/N+ USER'S GUIDE	*VAX/VHS	PRO 100L N.1 COROL-81	5	NOV 93
AA-H214A-TE-001	1.0	VAX-11 RGL INSTALLATION GUIDE FOR THE VT125	#VAX/VMS	VAX-11 REGIS GRAPHICS LIFRARY	1	6Eb A3
AA-H286A-TE-001	2.0	IEC11 VAX SOFTWARE MANUAL	*UAX/VHS	IECH19	1	MAN 83
AA-M388A-TC-001	1.4-1.5	INTRODUCTION TO MICROPOWER/PASCAL	*VAX/VHS	MICROPOWER/PASCAL-VMS		.HIL 84
AA-H389C-TC-001	1.4	HICROPOWER/PASCAL LANGUAGE GUIDE	*VAX/VHS	HICROPOWER/PASCAL-VMS	c	FEE 84
AA-N389C-TC-002	1.5	MICROPOWER/PASCAL LANGUAGE GUILLE (UPII41)	*VAX/VHS	HIEROPONER/PASCAL-UHS		JUL 84
6A-H390P-TC-001	1.4	HICROPOWER/PASCAL-RT SYSTEM USER'S GUIDE	*VAXZVMS	MICROPE «EM/PASCAL-UMS	3	HEF 84
AA-M391B-TC-001	1.4	HICROPOWER/PASCAL-RT RUNTIME SERVICE MANUAL	#VAX/VHS	MICPOPONER/PASCAL-VMS	5	FLF 84
AA-N391B-TC-002	1.5	NICROPOWER/PASCAL-RUNTIME SERVICE MAN (UPD#1)	#VAX/VMS	MICROPOWER/PASCAL-VMS		JUL 34
AA-H393A-TE-001	1.0	DECHEALTH SYSTEM ADMINISTATOR'S GUIDE	*96Y/94S	MAX-11 DECHEALTH		JUL 84
AA-H393B-TC-001	1.4	MICROPOWER/PASCAL DEBUGGER USER'S GUIDE	#VAX/VH5	HICROPONER/PASCAL-UNI	~	FEE 84
MA-M393B-TE-002	1.5	MICROPOWER/PASCAL DEGR USER'S GUIDE (UPD41)	#VAX/VMS	MICRUPOWER/PASCAL-VMC		JUL 14
AA-H394B-TC-001	1.4	HICROPOWER/PASCAL MESSAGE MANUAL	#VAX/Um5	MILIMUPUMER/MASCA - Uns		+ + 1 34
AA-M431B-TE-001	2.0	DECHAIL RELEASE INFORMATION	*DUX \ AUR	VAX-11 TECHAIL	1	-fall 51
AA-H477A-TK-001	1.0	EDT QUICK REFERENCE MANUAL	*UAY -UMS	TRO DEAFFORTER, 100F + 1		# 11
AA-H493A-TE-001	1.0	VAX-11 RGL RELEASE NOTES FOR THE 91125	#VAX/UMS	ANA-11 ELOST -EVENTOS - JECK	;	LF ti
AA-M507A-TC-001	1.0	TAS/RSX-TT ODT REFERENCE MANUAL	*UAY./VMS	ER GENERALES 100 FT.	1	MY
AA-H507A-TC-001	4.0	TAS/RSX UDT REFERENCE MANUAL	#WAX/VMS	P67-115		

PART Number Rev Level	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	None Promici	Memere CE FICHE	!!F1_
AA-H526E-TC-001	1.4	MICROPONER PASCAL-RT RELEASE NOTES	*VA);/ UMS	HICPOPOWER/PASCAL-VAS	1	FEE MA
AA-H537A-TE-001	3.0	DECNET-VAX SUFTWARE INSTALLATION GUIDE	VAX/VMS	DECNET-VAY	1	EE1 E2
AA-H537B-TE-001	3.1	DECNET-VAX SOFTWARE INSTALLATION GUILLE	#VAX/VHS	DECNET-VAT	1	Milli 83
AA-H538A-TE-001	3.0-3.5	VAX-11 SOS TEXT EDITING REFERENCE MANUAL	#VAY/VHS		**; **	SEP 82
AA-H539A-TE-001	3.0-3.5	VAX/VMS MAGNETIC USER'S GUIDE	#VAX/VHE		1	SEF 82
AA-H540A-TE-001	3.0-3.3	VAX/VHS I/O USER'S GUIDE VOL 1	VAX/VHS		1	SEN 93
AA-M540B-TE-001	3.4-3.5	VAX/VMS I/O USER'S EUIDE VOL I	#UAX/UMS		-	00+83
AA-H541A-TE-001	3.0-3.3	VAX/VMS 1/0 USER'S GUIDE VOL 11	UAX/UMS		5	3Eh 97
AA-H541B-TE-001	3.4-3.5	VAX/VMS I/O USER'S GUIDE VOL I!	#VAX/VMS		-	UC1 33
AA-H542A-TE-001	3.0-3.5	VAX-11 RKS TUNING GUIDE	ruax/v <del>h</del> s		1	SE1 32
AA-H542A-TE-001	2.0	VAX-11 RMS TUNING GUIDE	#VAX/VH5	VAX-11 DSM	1	MAY 23
AA-H543A-TE-001	3.0-3.5	VAX-11/782 USER'S GUIDE	EVAX/UMS		1	SEP 91
AA-H544A-TE-001	3.0-3.5	DECNET-VAX CROSS-SYSTEM NOTES	#VA)/VHS		*	SEF 82
AA-H545A-TE-001	3.0-3.1	VAX-11/780 SOFTWARE INSTALLATION GUILLE	VAX/VMS		1	EEF 82
AA-N545B-TE-001	3.2-3.5	VAX-11/780 SOFTWARE INSTALLATION GUIDE	*VAX/VMS		1	A1-1- 53
AA-H546A-TE-001	3.0-3.1	VAX-11/730 SOFTWARE INSTALLATION GUIDE	VAX/VHS		1	SEN 81
AA-N546B-TE-001	3,2-3,5	VAX-11/730 SOFTWARE INSTALLATION GUIDE	WVAX7UHS			APR 83
AA-H547A-TE-001	3.0-3.1	VAX/VMS SYS MAN & OPERATIONS GUIDE	PAX /VAL		3	SEL 82
AA-H547A-TE-002	3.2-3.5	VAX/VHS SYS MAN/OPE GOL (INCLUDES UPD#1)	\$VAX (VM-		4	۵. 3
AA-H554A-TE-001	3.0-3.5	VAX-11 RMS UTILITIES REFERENCE MAMUFL	#9A): 9h5		6 4a	Fi. AT
AA-H554A-TE-001	2.0	VAX-11 RMS UTILITIES REFERENCE MANUAL	*UAX7U45	VAI-11 Cah	1	417 93
AA-H650A-TE-001	2.0	VAX-11 ADE INSTALLATION GUIDE/REL MUTES	VAX/JMS	NAX-11 THE	,	:F1 (2
AA-M650B-TE-001	2.1	VAX-11 ADE INSTALLATION GDE/REL NOT/S	VAY VMS	Martin Africa	,	Wit Gi
AA-N650C-TE-001	2.2	ADE VAX/VMS INSTALLATION GUIDE/PICEASE NUTES	TUATIONS	Nex-13 Wif		464 1
AA-H651A-TK-001	2.0	ADE USER'S GUIDE	VARAMS	94x-11 31t	4	ef: hi
AA-M651E-TK-001	2.1-2.2	ADE USER'S GUIDE	#UAY (UH)	VA11 01	3	Mills of a

PART NUNBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM		PPODUCT MAME	NUMBER DE FICHU	<u>ា្រវ</u> ុ
AA-N681A-TE-001	1.0	DEC/CAS VI.O RELEASE NOTES	₹VAX/VMS	9AX-11	DEC/CHS	í	3F1. 8°,
AA-N793A-TE-001	1.1-2.1	VAX-11 DY32 INSTALLATION SUMMARY	#VAY/VMS	VAX-11	19732	1	map 31
AA-N8458-TK-001	1.0	HDE/T-11 USER'S GUIDE/REFERENCE MANUAL	#VAX/VHS	VAX-11	MDE	?	MAP 83
AA-N847B-TE-001	1.0	VAX/VMS MDE/T-11 SETW INSTE GDE/FELEASE NOTES	#VAX/VMS	VAX-11	MUL	1	88 AAR
AA-N888A-TE-001	1.0	DECHEALTH HEALTH SERVICE MANAGEMENT GUIDE	*V0X/VM5	VAC-11	DECHEALTH	2	FEP 84
AA-H889A-TE-001	1.0	DECEMALIH INDUST HYG SERVICE GUIDE	#VAX/VHS	VAX-11	PECHEALTH	1	FER 24
AA-N890A-TE-001	1.0	DECHEALTH SERVICE GUIDE	#VAX/VM5	VAX-11	DECHEALTH	F <sup>*</sup> 7 b <sub>0</sub>	FLE 81
AA-H891A-TE-001	1.0	DECHEALTH GUIDE TO MEDICAL REPORT	kVAX/VMS	VAX-11	DECHEALTH	2	reh 54
AA-N892A-TE-001	1.0	DECHEALTH GUIDE TO ENVIR REPORT	#VAX/VM5	VAX-11	DECHEALTH	1	FEB 84
AA-H894A-TE-001	1.0	DECHEALTH SYSTEM MANAGER'S GUIDE	496X/985	VAY-11	DECHEALTH	3	EFB 84
AA-H972A-TE-001	1.0	VAX-11 DECALC INSTALLATION GUIDE	#VAX/UHS	JG1-[]	DECALC	1	M& 4 = 1
AA-N974A-TE-001	1.0	DECALC USER'S GUIDE	#UAX /UnS	₩¥X~11	DECALL	*4	MAY 33
AA-K082A-TE-001	2.0-2.1	VAX-11 PSI GUIDE TO USING X.29	#VAX/VMS	VAX-11	PSI	1	011.03
AA-N209A-TE-001	2.0-2.1	VAX-11 FMS LANGUAGE INTERFACE MANUAL	*VAX/VHS	94)11	Fh5	8	may J2
AA-N2698-TK-001	1.0	BCP USER'S GUIDE	*VAX/VHS	UAX-11	BCF	2	1AN 84
AA-N320A-TE-001	1.1-1.3	ALL-IN-1 OFFICE MENU PRIMER	#UAX/UHS	ALL-IN-	-1 UFFICE MENU	1	MAR 23
AA-N321A-TE-001	1.1-1.3	ALL-IN-1 OFFICE MENU USER'S GUIDE	#VAX/VHS	ALL-IN	-1 OFFICE MENIL	<b>L</b>	M4K 83
AA-N322A-TE-001	1.1-1.3	ALL-IN-1 OFFICE MENU REFERENCE CARD	#VAX/VMS	WFF-TH-	-1 Ortice VENO	1	MAF 33
AA-N323A-TE-001	1.1-1.2	ALL-IN-1 OFFICE MENU INSTALLATION GUIDE	*UAX/UM5	ALL-IN-	-1 OFFICE MEND	1	18 PAN
AA-N323R-TE-001	1.3	ALL-IN-1 OFFICE MENU INSTALLATION GUIDE	#9A779H5	ALL-IN-	-1 DIFILE MENU		101L d4
AA-N324A-TE-001	1.1-1.3	ALL-IN-1 OFFICE MENU APF PROG REF GUIDE	#VAY/VH5	ALL IN	- L OFFICE menu		M3~ 3
AA-N382A-TE-001	1,2-1,4	VAX-11 DBMS PERFORMANCE GUIDE	FVAX/VBS	IJA)′−11	11849	1	MAF d3
AA-N435A-TK-001	1.0	RTEM-11 USER'S GUIDE	VAX/VMS	PIEH-1			whe 81
AA-N435R-TK-001	1.4	RTEH USER'S MANUAL	#VAX/945	MICEUM	WER TASCAL-UMS		r F J. 14
AA-N435B-TK-001	1.1	RTEH-11 USER'S MANUAL	#VAX/541	nten t	1		1
AA-N435C-TK-001	2.0	RTEM-11 USER'S MANUAL	£9657945	HIEH-II			311 12 4

PART TITLE MUMBER NUMBER REV 0F OPERATING PRODUCT UF VERSION MANUAL FICHE LEVEL SYSTEM NAME DATE AA-N436A-TK-001 1.4 RTEM-11 INSTALLATION GUIDE/RELEASE NOTES **\*VAX/VHS** HICROPOWER/PASCAL-VMS FEB B4 RTEH-11 INSTALLATION GUIDE/REL NOTES MAR 93 AA-N436A-TK-001 1.0 **CHU/XAU** RTEM-11 NO9 93 RTEM-11 INSTL GUIDE/RELEAGE NOTES (UPB#1) \*VAX/VHS RTEM-11 AA-N436A-TK-002 1.1 AA-N436B-TK-001 2.0 RTEM-11 INSTL GUIDE/RELEASE NOTES (UPI+1) \*VAX/UHS RTEH-11 JUL 84 VAX-11 DN11 DEVICE DRIVER USERS MARUAL \*VAY/VHS MAR 83 AA-N438A-TE-001 1.0 VAY-11 DN11 DRIVER AA-N440A-TE-001 1.0 VAX-11 IN11 DEVICE DRVR INSTL GDE/REL NTS #UAX/UMS VAX-11 BN11 BRIVER MAR 83 VAX-11 DR11-C DEVICE DRIVER USERS MANUAL AA-N441A-TE-00: 1.0 \*UAX/UHS VAX-11 BR11-0 BRIVER MAR 83 AA-N443A-TE-001 1.0 VAX-11 DR11-C DEVICE DRVR INSTERNET NTS \*UAX/VHS VAX-11 DELL-U DELVER MAR 83 AA-N472A-TE-001 3.1 VAX/VMS V3.1 RELEASE NOTES #UAX/VHS MAR 83 \*VAX/VHS DECHEALTH ENVIR SERVICE MANAGMENT GUILLE FER 84 AA-N514A-TE-001 1.0 VAX-11 BECHEALTH AA-N615A-TK-001 1:0 PRO TOOL KIT DOCUMENTATION DIRECTORY VAX/VHS PRO DEVELOPER'S FOOL KIT MAY 83 AA-N615C-TK-001 1.0 PROFESSIONAL TOOL KIT DOCUMENTATION DIRECTORY #VAX/VMS PRO DEVELOPER'S TOOL NIT FER SA VAX/VMS AA-N616A-TK-001 1.0 PRO TOOL KIT INSTL GDE/REL NOTES PRO DEVELUPER'S TOOL NIT MAY 33 AA-N617A-TK-001 1.0 PRO TOOL KIT USER'S GUIDE VAX/VMS PRO DEVELOPER'S TOOL KILL MAY 83 AA-N617C-TK-001 1.0 PROFESSIONAL TOOL KIT USER'S GUIDE \*VAXZVMS PRO DEVELOPER'S TOOL KIT FEB 84 AA-N617C-TK-002 1.0 PROFESSIONAL TOOL KIT USER'S GUIDE (UPID) JUL 34 \*!/AX/UHS PRO DEVELOPER'S TOOL HIT PRO TOOL KIT CORE GRAPHICS LIBRARY MANUAL VAX/VHS PRO DEVELOPER'S FOOL KIT HAT 83 AA-N619A-TK-001 1.0 AA-N619B-TK-001 1.0 PRO TOOL KIT CORE GRAPHICS LIBRARY MANUAL \*VAX/VMS PRU DEVELOPER'S TOOL NIT FEB 84 AA-N620A-TK-CO1 1.0 PRO TOOL KIT P/OS REFERENCE MANUAL **XUAX/UNS** PRO DEVELOPER'S TOOL KIT MAY 83 AA-N620A-TK-002 1.0 PRO TOOL KIT P/OS REFERENCE MANUAL (UF)(\$2) #VAX798S PRO DEVELOPER'S TOOL NIT JUL 84 AA-N621A-TX-001 1.0 PRO TOOL KIT DUCUMENTATION GUIDE LINES #VAX/Vh5 PRO DEVELOPER'S FOOL ST MAY E3 AA-N623A-TK-001 1.0 PROTOOL KIT IERMINAL SUBSYSTEM MANUAL VAX/UHS FRO DEVELOPER'S TOOL NIT MAL ET AA-N6238-TK-001 1.0 PRO FUOL KIT TERMINAL SUBSYSTEM MANUAL #VAX/VH5 PRO DEVELOPER'S TOOL WIT 1 LN 84 AA-N673A-TE-001 1.1-1.3 ALL-IN-1 OFFICE MENU RELEASE NOTES ₹VAXZUHS ALL-IN-1 OFFICE MENU M45. 83 AA-N685A-TE-001 1.0-1.1 VAX-11 ACMS SUMMARY DESCRIPTION #VAX/VB5 VAX-IF ACMS PRUDUE SI FE9 84 VAX-11 ACMS INSTALLATION GUILLE AA-N686A-TE-001 1.0 XVAX/VMS MAX-11 WERS PRODUCT SET FFR 33

	v	42	
к		40	
29.			

PART MUMPER **NUMBER** TITLE OPERATING. PROBUCT 95 REV OF FICHE MAIL LEVEL **VERSION** MANUAL SYSTEM NAME #VAX/VHS VAX-11 ACHS PRODUCT SET JUL 84 VAX-11 ACMS INSTALLATION GUIDE AA-N686B-TE-001 1.1 FEE 84 AA-N687A-TE-001 1.0-1.1 VAX-II ACHS TERHINAL USER'S GUIDE \*VAX/VHS VAX-11 ACMS PRODUCT SET AA-N688A-TE-001 1.0-1.1 VAX-11 ACMS APP DEF GUIDE #UAX/UNS VAX-11 ACMS PRODUCT SET 1 EE 84 AA-N689A-TE-001 1.0-1.1 VAX-11 ACHS APP HONAGEMENT GUIDE ¥VAX/VMS VAX-11 ACMS PRODUCT SET FEB 84 AA-N590A-TE-001 1.0-1.1 V4X-11 ACHS/AD APP DGN GUIDE #VAX/VHS VAX-11 ACHS PRODUCT SET FEB 84 VAX-11 ACHS/AD APP PROGRAMMING GUIDE #VAX/VHS VAX-11 ACHS PRODUCT SET FEE 24 AA-N691A-TE-001 1,0-1.1 A/-N692A-TE-001 1.0-1.1 VAX-11 ACMS/AD TASK DEF GUIDS \*UAX/VHS VAX-11 ACMS PRODUCT SET FEB 84 FEE 84 #VAX/VHS VAX-11 ACMS PRODUCT SET MM-N693A-TE-001 1.0 VAX-11 ACMS RELEASE NOTES #VAX/UHS AA-N6938-TE-001 1.1 VAX-11 ACHS RELEASE NOTES VAX-11 ACHS PRODUCT SET JUL 84 AA-N694A-TE-001 1.0-1.1 VAX-11 ACHS INFORMATION DIRECTORY #VAX/VHS VAX-11 ACHS PRODUCT SET FEB 84 VAX-11 PCL DRIVER USER'S GUIDE \*VAX/VHS An-N7244-TE-V01 1.0 VAX-11 PCL JAN 84 VAX-11 DIO7 USER'S GUIDE JAN 84 AA-N727A-TE-001 1.0 \*VAX/VHS VAX-11 1/T07 AA-N729A-TE-001 1.0 VAX-11 NTR USER'S GUIDE \*VAX/VHS VAX-11 NTR JR4 84 VAX-11 HTR STATION MANAGERS GUILLE **\*VAX/VMS** VAX-11 NIR JAN 84 AA-N730A-TE-001 1.0 AA-N731A-TE-001 1.0 VAX-11 NTR VI.O RELEASE NOTES #VAX/VHS VAX-11 NTR JAN 84 AA-N801A-TE-001 2,0-2,1 VAX-11 PSI X.25 PROGRAMMING GUIDE \*VAX/VHS VAX-11 PSI 001 83 \*VAX/VHS VAX-11 BECHAIL AA-N831A-TE-001 2.0 DECHAIL OUICK LOOKUP GUIDE JUNE 83 VAX-11 DECALC RELEASE NOTES #UAX/UHS MAY BJ AA-P020A-TE-001 1.0 VAX-11 DECALC AA-P042A-TK-001 1.0-1.6 PRO TK INTRODUCTION TO DIBUL \*VAX/VMS TOOL KIT DIBOL MAY 83 AA-P042A-TK-001 2.0 INTRODUCTION TO DIROL \*DAX/VHS VAX-11 HIRDL UEI EZ MAY 13 AA-P043A-TK-001 1.0 PRO TK DIBOL USER'S GUIVE VAX/VMS PRO TOOL FIT BIBOL AA-P043C-TK-001 1.6 PRO TOOL KIT DIROL USER'S GUIDE \*VAX/VHS PRU 100E KII BIROU FEP 84 VAX/VHS MA1 93 AA-P044A-TK-001 1.0 PRU IK DISOL LANGUAGE REF MANUAL PRO TOOL KIT NIBO! AA-P045A-TK-001 1.0 PRO TK DIBOL RELEASE NOTES/INSTL GUE 95X798S FRO TOUL NIT BIRCL MO: 44 AA-P045C-TK-001 1.6 PRO TK DIROL RELEASE NOTES/INSTL GOE #VAX/VHS PFO 100E NAT DIBOL 165 84 #VAX/VH5 MARY ES AA-P059A-TE-001 1.2 DX/UNS V1.2 RELEASE NOTES THY / UMS

Page 1/

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	PRODUCT NAME	HITHE	rail
AA-P098A-TK-001	1.0	PRO/RMS-11: AN INTRODUCTION	*VAX/VHS	FRO DEVELOPER'S 100L KIT	•	MAY 83
AA-P099A-TK-001	1.0	PRO/RMS-11 MACRO PROGRAMMER GUIDE	*VAX/VHS	PRO DEVELOPER'S TOOL KIT	ç	ray si
AA-P102A-TK-001	2.0	PRO TK BASIC+2 DOCUMENTATION SUPPLEMENT	VAX/VHS	PRO TOOL KIT BASIC-PLUS-2	1	rat 83
AA-P102R-TK-001	2.1	PRO TOOL KIT BASIC-PLUS-2 DOC SUFL	*VAN/VAC	PRO 100L KII BASIC-PLUS-2	1	NOV 83
AA-P102C-TK-001	2.2	PRO TOOL KIT BASIC-PLUS-2 DOC SUPL	#VAX/VHS	PRU 100L KIT BASIL-PLUS-2		JUL 84
AA-P103A-TK-001	1.0	PRO TOOL KIT FHS DOCUMENT SUFFLEHENT	VAX/VMS	EKO DENFTOEFK.3 100F PLL	1	MAY 83
AA-P103B-TK-001	1.0	PRO TOOL KIT FMS DOCUMENT SUPPLEMENT	*VAX/VNS	PRO DEVELOPER'S TOOL NIT	\$	FEB 84
AA-P104A-TK-001	2.0	PRO 1K BASIC+2 INSTL GUIDE/RELEASE NTS	VAX/VHS	PRO TOOL KIT BASIC-FLUS-2	1	MAY 33
- AA-P104B-TK-001	2.1	PRO TOOL KIT BASIC+2 INSTL GDE/RELEASE NTES	#VAX/VMS	PRO TOOL KIT BASEC-PLUS-7	4 4	NOV 83
MA-P119A-TE-001	1.0-1.1	VAX-11 DEC/MMS USER'S GUIDE	#VAX/VHS	VAX-11 PEC/HMS	1	3UM 83
AA-P121A-TE-001	1.0-1.1	INSTALLING VAX-11 DEC/MMS	#VAX/VHS	VAX-11 DEC/MM3	<u> </u>	JUME 83
AA-P142A-TE-001	1.0	VAX-11 APL REFERENCE MANUAL	VAX/VHS	VAX-11 APL	5	68 YA6
AA-P1428-TE-001	1.1	VAX-11 APL REFERENCE MANUAL	#VAX/VHS	VAX-11 APL	<u> </u>	NUV 83
AA-P143A-TE-001	1.0-1.1	INSTALLING VAX-11 APL	*VAX/VHS	VAX-11 APL	1	AAY 83
AA-P193A-TK-001	1.0	PRO IAS/RSX ODT SUPPLEMENT	VAX/VNS	PRO DEVELOPER'S TOOL NIT	1	ra: 83
AA-P193B-TK-001	1.0	PRO TAS/RSX OUT SUPPLEMENT	*VAX/VHS	FRO DEVELOPER'S TOC. KIT	1	FEB 84
AA-P412A-TK-001	1.0	HOST CONMUNICATIONS INSTALLATION PROCEDURES	VAX/VHS	PRO HOST COMMUNICATIONS	1	har 83
AA-P412B-TK-001	1.5	PRO HOST COMMUNICATIONS INSTL PROCEDURES	VAX/VMS	PRO HUST COMMUNICATIONS		JUL 84
AA-P412C-TK-001	1.7	PRO HOST COMMUNICATIONS INSIL PROCEDURES	*VAX/VHS	PRU HOSE COMMUNICATIONS	ì	JAN 84
AA-P425A-TE-001	1.0	VAX-11 DECOR USER'S MANUAL	*VAX/VHS	VAX-11 PECOR	4	JAN 84
AA-P426A-TE-001	1.0	GUIDE TO WRITING VAX-11 DECOR HOL	#VAX/VMS	MAX-11 DECUR	1	JAn 84
AA-P427A-TE-001	1.0	VAX-11 DECOR INSTALLATION GDE/RELEASE NTS	*VAX/VHS	VAX-11 DECOR	quad.	JAN 84
AA-P581A-TC-001	1.0	DECNET/SNA GATEWAY INTRODUCTION	*VAX/VHS	DECNET SNA GATEWAY PRODUCTS	1	FER 94
AA-P582A-TC-001	1.0	DECNET/SNA GATEWAY INSTALLATION GUIDE	<b>★V</b> AX/VHS	DECNET SHA GATEWAY PRODUCTS	2	FEP 64
AA-P583A-TC-001	1.0	DECNET/SNA RELEASE NOTES	≱VAY7VMS	DECNET SNA GATEMAY PRODUCTS	1	1 <u>E</u> 74
AA-P584A-TC-001	1.0	DECNET/SNA PROB DETERMINE GUIDE	*VAX/VHS	DECNET SHA SATEWAY PRODUCTS		JUL 21

PART NUMBER	TITLE	anco ( 7 ° No		Schuluse		NUMEER	
REV LEVEL VERSION	OF MANUAL	OPERATING SYSTEM		PRODUCT NAME		LF FICHE	MIL
AA-P585A-TE-001 1.0	SNA/GATEWAY VMS HANAGEMENT GUIDE	*VAX/VHS	DECNET	SNA GATEWAY PRO	nucrs	**1 ****	00 ± 83
AA-P586A-TE-001 1.0	SNA GATEWAY VMS MANAGEMENT RELEASE NOTES	*VAX/VHS	DECHET	SNA GATEWAY PRO	PNUCIS	1	0C1 83
AA-P587A-TE-001 1.0	SNA VMS 3270 TE USER'S GUIDE	#VAX/VHS	DECNET	SNA GATEMAY PRO	DUCTS	1	UL 1 83
AA-P591A-TE-001 1.0	SNA VHS APP INTERFACE PROGRAMMER GUILLE	#UAX/VHS	DECNET	SNA GATEWAY PRO	DUC15	2	001 83
AA-P653A-TE-001 2.0-2.1	VAX-11 DY32 TT FROG GUIDE	*VAX/VHS	VAX-11	DY32_		1	JUNE 83
AA-P763A-TE-001 3.2	VAX/VMS V3.2 RELEASE NOTES	*VAX/VHS				1	AFR 83
AA-P764A-TE-001 3.3	VAX/VHS V3.3 RELEASE NOTES	#VAX/VMS				1	JUN 83
AA-P765A-TE-001 3.4	VAX/VMS V3.4 RELEASE NOTES	#VAX/VHS				1	001 83
AA-P766A-TE-001 3.5	VAX/VMS V3.5 RELEASE NOTES	#VAX/VHS				1	FEB 84
AA-P788A-TE-001 1.3-1.4	VAX-11 & LANGUAGE SUMMARY	#VAX/VHS	VAX-11	C		4 .h	903 83
AA-P960A-TE-001 2.0	VAX-11 BTR SUMMARY DESCRIPTION	VAX/VHS	VAX-11	DATATRIEVE		1	007-83
AA-P862A-TE-001 2.0-2.1	VAX-11 PATATRIEVE GUIDE/WRITING REPORTS	*VAX/VHS	VAX-11	DATATRIEVE		1	001 83
AA-P863A-TE-001 2.0-2.1	VAX-11 DATATRIEVE GUIDE/PROGRAM/CUSTUM	#VAXZ9MS	VAX-11	DATATRIEVE		3	001-83
AA-R190A-TE-001 2.0	DECNET-VAX SYSTEM MANAGER GUILLE	VAX/VMS	VAX-11	FS1		4	00: 83
AA-R327A-TE-001 1.1	DEC/CHS V1.1 RELEASE NOTES	#VAX/VHS	VAX-11	DEC/CMS		1	FCB 34
AA-R350A-TE-001 2.3	VIA SUMMARY DESCRIPTION	#VAX/VHS	VAX-11	ווע בומון אטאאטן	TIORARY	2	FER 84
AA-R351A-TE-001 2.3	VIA INFORMATION DIRECTORY/MASTER INDEX	*VAX/VHS	VAX-11	old alad homago	. FIGHORY	3	FEB 94
AA-R380A-TE-001 1.0	MESSAGE ROUTER MANAGER'S GUIDE	*VAX/VHS	MESSAG	E ROUTER/VMS		2	MOD 83
AA-R381A-TK-001 1.0	MESSAGE ROUTER USER'S INTERFACE GUIDE	#VAX/V <del>H</del> S	MESSAG	E RUUTER/VHS		1	MO1 83
AA-R382A-TE-001 1.0	HON TO INSTALL MSG ROUTER/VMS	#VAX/VHS	MESSAG	E ROUTER/VMS		1	MÜÜ 83
AA-R385A-TE-001 1.0	MESSAGE ROUTER VAXHAIL GATEWAY GUIDE	#VAX/V#S	MESSAG	E POUTER, MAS		1	NUT E3
AA-R386A-TE-001 1.0	MESSAGE ROUTER V1.0 RELEASE INFO	#PAX/VHS	MESSAS	SHOUTER DAS			£8 VØ4
AA-R387A-TK-001 1.0	PRO TOOL KIT FORTRAN-7/ INSIL GDE/DUC SUPL	VAX/VHS	PFt 10	OL FIL FURTHER-	,	1	HU. 83
AA-R387B-TK-001 5.0	PRO HOST TK F-77 IG/DOC SUPL	#VAX/V#S	rikli tü	UL ELE FORTRAN-	1	Ţ	JON -A
AA-R418A-TE-001 1.1	REGIS GRAPHICS UTILITY MANUAL	#VAX/VHS	PULTUR	AF [7			JAN 114
A9-R759A-TK-001 1.0	PRO TOOL KIT PASCAL INSTLIKEL HTS	VAX/VHS	FE0 10	UL NIT PASCAL			$b_1 \bigcup b_1 = c - 1$

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	PRODUC" NAME	NUMBER OF FICHE	DATE
AA-R759B-TK-001	1.1	PRO TOOL KIT PASCAL INSTL/REL NIS	*VAX/VMS	PRU TUUL KII PASCAL	1	JAN 84
AA-R786A-TE-001	1.0	REAL-11/11S INSTALLATION GUIDE	*VAX/VHS	REAL-11/11S	1	JAN EA
AA-R953A-TK-001	2.6	PDP-11 FORTRAN LANGUAGE REFERENCE MANUAL	*VAX/VHS	FORTRAN IV/VAX TO ESX	<u>)</u>	MOV 83
AA-R954A-TK-001	2.6	RSX/VMS F4 INSTALLATION/RELEASE HOTES	*VaX/VHS	FURTEAN 1979AX 10 RSX	1	HOD 83
AA-R955A-TK-001	2.6	RSX VAX/VMS F4 USER'S GUIDE	#VAX/VMS	FURTRAN IV/VAX IU RSX	<u>")</u>	NOV 83
AA-U046A-TK-001	1.0-1.1	PRO 100L KIT PASCAL USER'S GUIDE	*VAX/VMS	PRU 100L N11 PASCAL	-	iiii 87
AA-U047A-TK-001	1.0-1.1	PRO TOOL KIT PASCAL LANGUAGE REFERENCE MANUAL	#VAX/VMS	PRU FOOL FIT PASCAL	2	HUV E3
AA-U061A-TC-001	1.0	DECGRAPH USER'S GUIDE	*VAX/VMS	VAX-11 DECGRAPH	1	88 YUN
AA-U062A-TC-001	1.0	DECGRAPH REFERENCE MANUAL	*VAX/VHS	VAX-11 DECGRAFH	1	400 83
AA-U063A-TC-001	1.0	DECGRAPH RELEASE NOTES/INSTALLATION GUIDE	#VAX/VHS	VAX-11 DECGRAPH	4 4	NOV 83
AA-U066A-TK-001	1.6	DIBOL-83 LANGUAGE REFERENCE MANUAL (UPD#1)	*VAX/VMS	PRO FOOL KIT DIRUL	-11 4+	FEB 84
AA-U066A-TK-001	2.0	DIROL-83 LANGUAGE REFERENCE MANUAL.	*VAX/VHS	VAX-11 DIPOL	)	OCT 83
AA-U415A-TE-001	1.1	REGIS GE INSTALLATION/RELEASE NOTES	*VAX/VMS	PULTGRAFIX	1	FEB 84
AA-U418A-TE-001	1.1	REGIS CSE INSTALLATION/RELEASE NOTES	*VAX/VHS	POLYGRAFIX	1	FEB 34
AA-U421A-TE-001	1.1	SPS INSTALLATION/RELEASE NUTES	#VAX/VMS	POLYGRAFIX	1	FEB 34
AA-U430A-TE-001	1.1	DPP INSTL/RELEASE NOTES	*VAX/VHS	POLYGRAFIX	g very	FER 34
AA-U439A-TE-001	1.1	DECRITE INSTALLATION/RELEASE NOTES	*VAX/VHS	FULYGRAF1X	1	FEB 84
AA-U715A-TE-001	1.0-1.1	VAX-11 ACMS APP DEF REFERENCE MANUAL	*VAX7VHS	VAX-11 ACMS FRODUCT SET	4	FLE 84
AA-V027A-TC-001	1.5	PDP-11 MACRO-11 LANGUAGE REF MANUAL	#VAX/VHS	M1CROFONER/FASCAL-VMS		JUL 34
AA-V027A-TC-001	1.0	PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	*VAX/VMS	PRO DEVELOPER'S 100L KIT	_3	FEB 84
AA-V193A-TK-001	5.0	PDP-11 F-77 LANGUAGE REFERENCE MANUAL	#VAX/VMS	FORTRAN 77/VAY TU REY	i	JEH 84
AA-V193A-TK-001	5.0	PDP-11 F-77 LANGUAGE REFERENCE MANUAL	*VAX/VHS	PRO 100L KIT FORTPAN-/1	?	JeH 34
AA-V194A-TK-001	5.0	PDP-11 F-77 USER'S GUIDE	TVAY/VAS	FORTRAN 22/VAX TO FSX	3	Jan 34
AA-V194A-TK-001	5.0	PRP-11 F-77 USER'S GUIDE	39A7./98S	PRU TUOL KIT FURTEAR /	3	JAN 84
AA-V195A-TK-001	5.0	PDP-11 F-77 UTS REFERENCE MANUAL	TVAK/VHS	FORTRAN 177/MAX TO ESS		John 24
AA-V195A-TK-001	5.0	PMP-11 F-77 GTS REFERENCE MANUAL	tVAX/VMS	PRO HOUL NIT FURTERY- "	,	Just 34

PART HUMBER REV LEVEL	VERSION	TITLE OF MANUAL	UPERATING SYSTEM	PRODUCT NAME	F TOHE	UATE
AA-V196A-TK-001	5.0	POP-11 F-7/ INSTALLATION GUIDE/RELEASE NOTES	*VAXZV#S	FORTRAM 27/VAX TO RSX	1	JAM BA
AA-V197A-TK-001	1.0	PDP-11 F-77/DEBUG USER'S GUIDE	#VAX/VHS	FORTRAN // BERUG. FDF-11	.)	JAN 84
AA-V327A-TE-001	1.0-1.1	VAX-11 ACMS DEF POCKET GUIDE	\$VAAAVMS	VAX-11 ACHS PRODUCT SET	1	FEB 84
AA-V328A-TE-001	1.0-1.1	VAX-11 ACMS MANAGEMENT POCKET GUIDE	#VAX/VMS	VAX-11 ACHS PRODUCT SET	*	FEE 84
AA-V33VA-TE-001	1.0-1.1	VAX-11 ACMS/AD PROGRAMMING POCKET GUIDE	#UAX/VHS	VAX-11 ACHS PRODUCT SET	1	FEB 84
AA-V549A-TK-001	1.0	DECNET SNA GATEWAY PAR IRM/SNA ENV	*VAX/VHS	DECNET SHA GATEMAY PRODUCTS	1	460 83
AA-V594A-TE-001	1.4	VAX-11 HUST USER'S GUIDE	#VAX/VMS	#ICROPOWER/PASCAL-VMS	2	FEP 84
A4-V595A-TE-001	1.4	MICROPOWER/PASCAL-VMS INSIL SDE/REL NOTES	#UAX/VHS	HICKOPOWER/PASCAL-VHS	*	FL1 84
AA-V596A-TC-001	1.4	RT-11 SYSTEM USER'S GUIDE	#VAX/VH5	HICROPOWER/PASCAL-VHS	7	168 84
AA-V597A-TC-001	1.4	RT-11 SYSTEM MESSAGE MANUAL	#VAX/VHS	mICROMONER/MASCAL-VMS	.1	tib =a
AA-V810A-TK-001	2.0	DIBUL-83 COMPATIBILITY MANUAL	*VAX/VMS	VAX-11 ((BUL	1	uc. tr
AA-V810B-TK-001	1.6	DIROL-83 COMPATABILITY MANUAL	rvax/vms	PRO 100L KII DIROL	1	FEE JA
AA-V801A-TE-001	2.0	VAX-11 DIROL MESSAGE MANUAL	#VAX/VHS	V4X-11 E180L	1	UU 83
AA-V910A-TE-J01	1.0	VAX-11 DECSLIDE OUICK REFERENCE GUIDE	#VAX/UHS	VAX-11 DEUSLIDE	1	64 34
AA-V911A-T5-001	1.0	VAX-11 DECSLIDE USER'S GUILLE	*UAX/VHS	VAX-11 DECSLIDE	2	Jan 04
AA-V912A-TE-001	1.0	VAX-11 DECSLIDE RELEASE NOTES	*VAX/VHS	MAX-11 DECSLIDE	1	JAN 84
AA-X650A-TK-001	1.0	F-77/DEBUG INSTALLATION GUIDE/RELEASE NOTES	TUAX/UHS	FORTRON 1/ BERUGE FOR 11	4	JAN 84
AA-X910A-TH-001	1.0	PRO TOUL KIT DOCUMENTATION DIRECTORY	KNAX7965	rko nenfforfe.2 100r VII		्राष्ट्र स्टब्
AA-X911A-TH-001	1.0	PRO/TOOL KIT INSTALLATION GDE/DOC SUPPLEMENT	#VAX/VM5	PHO DEVELOPTE'S 100L F11		201, 84
AA-X912A-TH-001	1.0	PRU/TOOL KIT COMMAND LANG UTILITIES HANUAL	\$96X7985	PRE REVELOPER 5 100E +17		JEE 24
AA-Y285A-TH-001	2.1	PROJEK COROL 81 INSTALLATION GREZUOL SUF	EJAK/Vhs	PRE 1000 ATT 1,0800-51		JHL 81
AA-Y615A-TK-001	1.5	KX111-C SOFTWARE USER'S GUIDE	tvar/ums	MICHOPOWER FAS AL UM		HIL PA
AA-Z384A-TK-001	1.0	PRO IK F-77 DRG IG/DOC SUPP	TUAX / UNIC	PRI 4051 TE FOR MAR-7" DEBITE	1	.E 34
AA-2515A-TK-001	1.6	PRO/FOUL KIT BIROL MESSAGE MANUAL	EVAX/VMS	akto tid vil alkor		i   11 - ₹4
AE-BB27A-TK-001	1.1	ADDENUUM TO SPD	ZVAN/UMS	FULTURALLY		JC 80
AE-BB27A-TK-001	1.7	ADDENDUM TO SPE	tVAX/VBS	THE HEST CHAMENICATIONS		16 - 4

PART NUMBER REV LEVEL VERS10	TIILE OF MANUAL	OPERATING SYSTEM	PRUMULT NAME	of white	JAIŁ
AE-C770Q-TE-001 3.5	VAX/VHS V3.5 SPD 25.1.17	#VAX/VMS		1	FEE 84
AE-C770R-TE-001 3.5	VAX/VMS V3.5 SP0 25.01.18	#VAX/VHS			HUL 84
AE-D888E-TX-001 1.2	DX/VHS V1.2 SPD 25.25.4	#VAX/VHS	0x/VMS	1	FEE 34
AE-H113L-TE-001 2.6	DATATRIEVE/VAX V2.6 SFD 25.14.11	*VAX/VMS	PDF-11 DATATRIEVE/VAX	1	EFB 84
AE-H113M-TE-001 2.6	PDP-11 DATATRIEVE/VAX V2.6 SPD 25.14.12	*VAX/VMS	PDP-11 DATATRIEVE/VAX		JUL 84
AE-H114J-TE-001 4.0	VAX-11 RLISS-32 V4.0 SPD 25.12.09	¥UAX/UHS □	VAX-11 ELISS-52 IMPLEM LANG	1	1 EF 84
AE-H1151-TE-001 2.6	FORTRAN 10/VAX TO RSX V2.6 SPD 25.17.08	AVAX/VMS	FORTRAN IV/VAY TU RSX	1	FEB 84
AE-H598F-TE-001 1.2	MUX200/VAX V1.2 SPD 25.2.05	#UAX/V#S	HUY200./VAX	1	FEF 24
AE-H938G-TE-001 2.0	VAX11/786 MIGROPROME 100LS SPD 25.09.06	\$VAX/VHS	VAX-1. 780 MICRUFROSKAMMING TOOLS	1	FEB 84
AE-1574F-TE-001 1.4	VAX-11 2780/3780 PE SPD 25.07.05	1967 (9 <del>6</del> 5	7AX-11 2780/3780 PE	n di	FFF 54
AE-H994G-TE-001 1.4	VAX-11 2780/3780 PE SPD 25.07.06	*VAX/VHS	VAX-11 2780/3/80 PE		JUL 84
AE-J707F-TE-001 1.1	VAX-11 CORAL-66 SPD 25.37.05	#VAY/965	24Y-11 CQRAL-66		FER E4
AE-J847G-TE-001 2.2	VAX-11 COBOL V2.2 SPD 25.04.06	#VAX/VHS (	VAX-11 CUFOL	1	FES 84
AE-J847J-TE-001 3.0	VAX-11 COROL V3.0 SPU 25.04.09	#VAX/VHS	JAX-11 LUPOL		JUL 84
AE-J848J-TE-001 2.2	VAX BASIC V2.2 SPB 25.36.9	#UAX/VHS	VAX-11 BASIC	1	FER 84
AE-J840K-TE-001 2.2	VAX BASIC V2.2 SPU 25.36.10	PPAX/UHS !	ZAX-11 BASIL		तिर हर
AE-K538D-TE-001 1.3	PLXY-11/VAX V1.3 SPD 25.42.03	\$VAX/VMS	PLX1~11/VAX	1	FEE 84
AE-K754E-TE-001 4.0	VAX-11 RLISS-16 V4.0 SPI 25.19.04	#VAX/VhS	MAX-11 BLISS-16 IMPLEM LAND		JUL BA
AE-K792C-TE-001 2.0	VAX-11 32/1 PE SPD 25-21-2	*VAX/UHS !	7AX-11 J271 PE		JUL 81
AE-K792D-TE-001 2.1	3270 TT EMULATOR MEYBOARD LAYOUT	MAXZVAS I	74X-11 3271 FE		JEL 14
AE-K792D-TE-001 2.1	VAX-11 3271 PE V2.1 SP# 25.21.03	*VAX/VHS	VHX-11 3271 PE		JU 84
AE-L230Y-TE-001 3.5	VAX CROSS REF TABLE SPD 25.99.24	#VAXZVHS			WL 54
AE-L517B-TK-001 1.0	BASIC TRANSPORT PACKAGE SPD 30.13.1	#UAX/UMS	BASIC TRANSPORTABILITY PACKAGE	1	FEB 84
AE-L9346-TE-001 2.3	VAX-11 CDD V2.3 SPD 25.33.06	AVAX/VMS I	ZAX-11 CUMMUN DATA DICTIONARY	1	EII HV
AE-L815H-TE-001 2.3	VAX-11 CDD V2.3 SPD 25.53.07	#9AX/9M5 3	VAX-11 COMMON WAFA DISFIGNA Y		WE 34
AE-L817H-TE-001 2+1	VAX-11 DTR V2.1 SPD 25.44.07	₹ŲĄYZŲMS Ų	PAY-11 BRIATPIEVE	à	÷ <u>4</u>

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	FRUIDUCT NAME	NUMPER OF FICHE	1967 E
AE-L818H-TE-001	1.4	VAX-11 DBMS SPD 25.48.07	#VAX/UHS	VAX-11 ORMS		JUL 80
AE-M629B-TE-001	1,1	DEC/CMS V1.1 SPD 25.52.1	*VAX/VMS	VAX-11 DEC/CMS	1	FER 84
AE-M746D-TE-U01	2.0	CORAL-66 VAX/RSX V2.0 SPD 25.69.03	*VAX/VHS	CORAL-66/VAX TO RSX	1	FEE 84
AE-H854C-TE-001	2.2	VAX-11 ARE V2.2 SPD 25.76.02	*VAX/VHS	VAX-11 AUE		JUL 34
AE-M854E-TE-001	2.3	VAX-11 ADE V2.3 SPB 25.76.04	*VAXZUHS	VAX-11 ADE		JUL 84
AE-N373E-TE-001	1.3	VAX-11 C V1.3 SPD 25.38.04	#UAX/UHS	VAX-11 E	1	FEB 84
AE-M878G-TE-001	1.4_	VAX-11 C V1.4 SPD 25.38.06	*VAX/UHS	VAX-11 C		JUL 84
AE-N0318-TE-001	2.0	IEC11 V2.0 SPD 25.74.01	*VAX/VHS	1EC117	1	FEE: 84
AE-N416D-TE-001	1.2	ALL-IN-1 V1.2 SPD 25.85.03	*VAX/VHS	ALL-18-1 OFFICE MEHU	1	FE3 84
AE-N416E-TE-001	1.3	ALL-IN-1 V1.3 SPD 25.85.04	*VAX/VHS	ALL-IN-1 UFFICE MENU		JUL 84
AE-N571E-TK-001	2.0	RFEM-11 V2.0 SPD 30.21.04	#VAX/VMS	RTEM-11		JUL 84
AE-M571E-TK-001	2.0	RTEH-11 V2.0 SPN 30.21.04	*VAX/VMS	RTEM-11		PUL 34
AE-N683B-TE-001	1.0	COURSEWARE AUTHORING SYSTEM VI.0 SPD 25,95,01	#VAX/VĦS	COURSEWARE AUTHORING SYSTEM	3	FEB 84
AE-H875B-TE-901	1.0	VAX-11 DECHEALTH V1.0 SFD 25.78.01	*VAX/VHS	VAX-11 DECHEALTH	1	FEV 34
AE-P450C-TE-001	1.1	VAX-11 APL V1.1 SPD 25.31.02	*VAX/VHS	VAX-11 AFL	****	> FEB 84
AE-P648D-TK-001	1.7	PRO HOST COMMUNICATIONS V1.7 SFR 30.20.03	#VAX/VBB	FRO HOST COMMUNICATIONS		JUL 84
AE-P650B-TK-091	2.1	PRO FOUL KIT BASIC + 2 SPD 30.27.1	#UAX/UHS	PRO 1001 XII BASIC-PLUS-2	1	FEB 84
AE-P650D-1K-001	2.2	PRO TOOL KIT BASIC + 2 V2.2 SPH 30.27.03	«VAX/VMS	PPO 100L N11 HASIC-PLUG-"		ML 34
AE-R429C-TE-001	1.1	DEC/MMS V1.1 SPD 26.03.02	#VAX/Vas	VAX-11 UEL /MMS	1	rt2 84
AE-V398B-TK-001	1.0	PRP F-77/REBUG V1.0 SPD 30.33.01	*VAX/VHS	FUETEEN // DERUG, PTF-11		Jul 54
AE-V489A-TE-001	1.0	REAL-11/11S V1.0 SPD 26.22.00	*VAX/VH5	REAL-11/115		JUI. 14
AE-W597C-TK-001	5.0	PRO-TOOL KIT FORTRAN-77 V5.0 SFB 30.38.02	*UAX/VHS	PRO TOOL AND FORTPAN-7		WL 34
AE-W942A-TE-001	71.0	VAX-11 BCF V1.0 SPB 26.26.0	#VAX/UM5	VAX-11 ECT	1	FER *
AE-X069B-TE-001	1.0	HESSAGE ROUTER/VMS VI.0 SPN 26.33.01	*VAX/VNS	MESSAGE ROUTER/VnS		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
AE-X547A-TE-001	1.4	HICROPUNER/PASCAL VMS V1.4 SPB 26.24.00	#VA:/VMS	MICPUPUWER/PASCAL-VM5	1	tef "
AE-X547D-TE-001	1.5	MICROPOWER/PASCAL V1.5 SPB 26,24.03	#VAX/VNS	HICKUMUMER/MASCAL-UMS		JM 94

PART NUMBER REV LEVEL	VERSION	TITLE OF MANUAL	OPERATING SYSTEM	HAME MAME	NUMBER OF FICHE	HAJE
AE-X605B-TE-001	1.1	POLYGRAFIX V1.1 SPD 26.14.61	#VAX/VHS	POLYGRAFIX	1	FEB 84
AE-Y155B-TE-001	5.0	F-77 VAX/RSX V5.0 SPD 26.16.01	TVAXZVHS	FURTRAN /7/VAX 10 RSX		JUL EA
AE-Y991A-TH-001	1.0	PROFESSIONAL DEV TOOL KIT SPD 40.19.00	#VAX/VHS	PRU DEVELOPER'S TOOL KIT		JUL 84
AE-Y992A-TH-001	1.1	PRO TOOL KIT PASCAL SPD 40.20.00	#VAX/VHS	PRU TOOL KIT PASCAL		JUL 84
AE-Y995A-TE-001	1.0	VAX-11 ACMS V1.0 SPD 20.50.00	*VAX7VMS	VAX-11 ACMS PRODUCT SET	1	FEB 84
AE-Y995C-TE-001	1.1	VAX-11 ACMS V1.0 SPD 25.50.02	#VAX/VHS	VAX-11 ACMS FRODUCT SET		JUL 34
AE-Z764A-TH-001	2.1	PRO TOOL KIT COBOL-81 V2.1 SPD 40.24.00	#VAX/VHS	PRO FOOL AIT COROL-81		JUL BA
AE-Z847A-TH-001	1.0	PRO TK F-77/DRG V1.0 SFD 40.25.00	#VAX/VHS	PRO HOST (K FORTRAN-7) DEBUG		JUL 84
AV-5287C-TE-001	1.4	RT11 V4.0 POCKET GUIDE	*VAX/VMS	M1CROFDWER/PASCAL-VMS	r.	FEB 84
AV-5570B-TC-001	4.0	RSX-11H HINE REFERENCE	#VAX/VHS	KSX-11S	2	STA 65
AV-ACO7A-TK-001	2.3	ADE REFERENCE CARD	#VAX/VHS	VAX-11 ADE		JUL 84
AV-AT45A-TK-001	4.0	SLISS POCKET GUIDE	#VAX/VMS	VAX-11 BLISS-16 IMPLEM LANS	1	FEH B4
AV-AT45A-TK-001	4.0	BLISS POCKET GUIDE	*VAX/VHS	VAX-11 PLISS-32 IMPLEM LANG		JUL 84
AV-D827A-TE-001	3.0-3.3	VAX-11 PROGRAHMING CARD	VAX/VH5		1	SEF 32
AV-D827B-TE-001	3.4	VAX-11 PROGRAMMING CARD	VAX/VHS		1	001 83
AV-D827C-TE-001	3.5	VAX-11 PROGRAMMING CARD	*VAX/VHS		<u>1</u>	FER 84
AV-H289C-TK-001	3.0	BLISS POCKET GUIDE	VAX/VHS	VAX-11 BLISS-16 IMPLEM LANG	1	SEP 80
AV-H289C-TK-001	3.0	BLISS POCKET GUIDE	VAX/VHS	VAX-11 BUISS-32 IMPLEM LANG	1	SEP 82
AV-H630C-TC-001	2.0-2.1	COBOL-81 POCKET GUIDE	*VAX/VMS	PRO 100L K11 COROL-81	2	NUV 83
AV-H633B-TE-001	2.0-2.2	VAX-11 COROL PUCKET GUIDE	*VAX/VHS	VAX-11 COROL	1	ÆF 82
AV-H633C-1E-001	3.0	VAX-11 COBOL POCKET GUIDE	*VAX/VHS	VAX-11 COEOL		114 84
AV-J262A-TE-001	1.1	VAX-11 FMS HINI-REFERENCE	VAX/VHS	VAX-11 FMS	1	SEP 82
AV_J416A-TE-001	1,2	VAX-11 DSM SUMMARY	VAX/VMS	VAX-11 DSM	1	26H 85
AV-J416B-TE-001	2.0	VAX-11 DSM SUMMARY	#VAX/VHS	VAX-11 NSM	1	may 83
AV-J756A-TC-001	3.0-3.5	EDT EDITOR REFERENCE CARD	#VAX/VMS		1	arr 65
AV-J757A-TE-001	1.3-1.4	VAX-11 PL/1 LANGUAGE SUMMARY CARD	*VAX/VHS	VAX-11 PL/1	1	TF 83

PART NUMBER REV LEVEL	VERS10N	TITLE OF MANUAL	UPERATING SYSTEM	PEUDUCT NAME	NUMEER UF FICHE	DATE
AV-K765A-TE-001	1.0	D.A.S. STUDENT GUIDE	#VAX/VHS	COURSEWARE AUTHORING SYSTEM	1	nay 83
AV-L322A-TE-001	2.0-2.1	VAX-11 FMS MINI REFERENCE PUCKET GUIDE	#VAX/VHS	VAX-11 FMS	¶ .5	MAY 83
AV-L341A-TK-001	2.0-2.2	BASIC POCKET REFERENCE GUIDE	#VAX/VHS	PRU 100L FIT BASIE-PLUS-2	2	MAY 83
AV-L341A-TK-001	2.0-2.2	BASIC POCKET REFERENCE GUINE	#VAX/VMS	VAX-11 FASIC	?	MAY 83
AV-L368A-TE-001	2.0-2.2	VAX-11 FASCAL LANGUAGE SUMMARY	¥VAX/V45	VAX-11 PASCAL	1	MAH 83
AV-L374A-TE-001	1.0-1.1	DECICHS FOCKET REFERENCE GUIDE	#VAX/UHS	VAX-11 DEC/ERS	1	SEF 82
AV-L491A-TE-001	1.0-1.4	INSTALLING VAX-11 C SUFTWARE	#VAX/VHS	VAX-11 C	1	E8 74M
AV-L814B-TE-001	2.0	DECHAIL ACCOUNT COORD REFERENCE CAMD	#VAX/VMS	VAX-11 DECHARL	1	JUNE 83
AV-L815B-TE-001	2.0	SYSTEM MANAGER'S REFERENCE CARD	#VAX/VHS	VAX-11 DECMAIL	1	JUNE 83
AV-M290A-TE-001	1.0	VAX-11 RGL SUMMARY CARD FUR THE V1125	*VAX/VHS	VAY-11 REGIS GRAPHICS LIBRARY	1	SEF 82
AV-H395A-TC-001	1.4-1.5	MICROPONER/PASCAL REFERENCE CARD	#VAX/VHS	MICRUPOWER/PASCAL-VMS	1	FEB 84
AV-N433A-TE-001	1.4	VAX-11 BASIC POCKET GUIDE	VAX/VHS	VAX-11 BASIL	1	SEP 82
AV-M548A-TE-001	3.0-3.5	DIGITAL STANDARD RUNOFF POCKET GUIDE	#VAX/VHS		1	SEP 82
AV-H552A-TE-001	1.0-1.1	VAX-11 DIBOL LANGUAGE REFERENCE CARD	VAX/VHS	VAX-11 PIROL	1	SEP 82
AV-H763A-TE-001	3.1-3.4	VAX-11 FURTRAN LANGUAGE SUMMARY	*VAX/VHS	VAX-11 FURTRAN	i	Ath 83
AV-H846P-TK-001	1.0	MDE/T-11 COMMAND REFERENCE CARD	*VAX/VHS	VAX-11 APE	1	MAR 83
AV-H907A-TE-001	1.1-2.1	VAX-11 BY32 PROGRAMMING REFERENCE CARD	#VAX/VMS	VAX-11 6732	1	MAR 83
AV-H967A-TE-001	1.0	DECALC REFERENCE CARD	xVAX/VHS	VAX-11 PECALC	1	K6Y 83
AV-N014A-TE-001	1.2-1.4	VAX-11 DRMS UTILITITES POCKET GUIDE	*VAXZVMS	VAY-11 DRMS	1	MAR: 83
AV-N015A-TE-001	1.2-1.4	VAX-11 DBMS ODL POCKET GUIDE	#VAX/VHS	VAX-11 DEMS	3	MAR 93
AVN016A-TE-001	1.2-1.4	VAX-11 DBMS DML POCKET GUIDE	#VAX/VnS	VAX-11 DRMS	1	NAH 83
AV-N193A-TE-001	1.2-1.3	VAX-11 DRMS FINE POCKET GUIDE	*VAXZVMS	VAX-11 FEMS	1	to ten
AV-N385A-TE-001	2.0	DECMIAL DIRECTORY	*VAX/VHS	VAX-11 (EUMAIL	•	דא באטנ
AV-N460A-TE-001	1.0-1.1	TOMS OFERATOR'S CARD	KVAX/VMS	VAX-11 IDMS	1	IN ES
AV-N6748-TE-001	1.2	ALL-IN-1 READ HE FIRST	#VAX/VHS	ALL-TH-1 UFFICE MENU	ł	Ct 1 83
AV-NB04A-TE-001	2.0-2.1	PSI NSI PSS CARD	PNOXAUMS	VAX-11 PSI	1	23 (20

PART HUMBER REV LEVEL VERS10	TITLE OF MANUAL	UPERATING SYSTEM	PRODUCT MAHE	NUMBER OF FICHE	PATE
AV-N805A-TE-001 2.0	PSI NSI DATANET-1 CARD	VAX/VMS	VAX-11 FSI	1	001 83
AV-N805B-TE-001 2.1	PS1 NSI NATANET-1 CARD	#VAX/VHS	VAX-11 FS1	1	EB VUM
AV-NE06A-TE-001 2.0	PSI NSI TRANSPAC CARD	VAX/VHS	VAX-11 FS1	1	001 83
AV-N806B-TE-001 2.1	PSI NSI TRANSPACE CARI	*VAX/VNS	VAX-11 PSI	1	MOV 83
AV-N807A-TE-001 2.0	PSI NSI TELENET CARD	VAX/VNS	VAX-11 FSI	1	001 83
AV-N807B-1E-001 2.1	PSI NSI TELENET CARI	#VAX/VHS	VAX-11 PS1	1	NOV 83
AV-N808A-TE-001 2.0-2.1	PSI NSI DATEXP CARD	*VAX/VHS	VAX-11 PSI	1	001 93
AV-N809A-TE-001 2.0-2.1	PSI HOST BASED PAD CARD	*VAX/VMS	VAX-11 FS1	1	0CT 83
AV-P120A-TE-001 1.0-1.1	VAX-11 DEC/HMS SUMMARY CARD	*VAX/VHS	VAX-11 DEC/MMS	1	JUNE 83
AV-P378A-TE-001 1.0	VAX-11 KHS-11-BID/BE X.25 V1.0 REL NOTES	#VAX/VHS	VAX-11 KHS X.25 LINK	1	mAR 93
AV-P428A-TE-001 1.0	VAX-11 DECOR PROGRAMMER REFERENCE CARD	≭VAX/VHS	VAX-11 DECOR	1	FEB 84
AV-P466A-TE-001 1.0-1.1	VAX-11 TOMS QUICK REFERENCE GUIDE	#UAX/VHS	VAX-11 HIMS	1	JUN 83
AV-P467A-TE-C01 1.0	BEFORE YOU INSTALL VAX-11 TOMS	VAX/VHS	VAX-11 TDMS	1	58 HUL
AV-P467R-TE-001 1.1	VAX-11 TDMS REFORE YOU INSTALL	#VAX/VHS	VAX-11 +DHS	1	001 83
AV-P549A-TE-001 1.0-1.1	VAX-11 TOMS FORM DEFINERS CARD	*VAX/VMS	VAX-11 FIMS	1	28 NUC
AV-P864A-TE-001 2.0-2.1	VAX-11 DATATRIEVE POCKET GUILLE	*VAX/VHS	VAX-11 DATATRIEVE	1	001 33
AV-U064A-TC-001 1.0	DECGRAPH REFERENCE CARD	*VAX/VMS	VAX-11 DECGRAPH	4 6	40V 83
AV-U067A-TK-001 1.6	DIBOL-83 LANGUAGE REFERENCE CARD	#VAX/VHS	PRO TOOL KIT DIROL	e a	FLB 84
AV-V508A-TE-001 2.0	IEC11-V V2.0 RELEASE NOTES	#VAX/VHS	IEC11V		JUL 84
AV-W295A-TE-001 1.0	VAX-11 PCL V1.0 REAL ME FIRST	#VAX/VMS	VAX-11 PCL	A	FEB 84
AV-X696A-TE-001 1.0	VAX-11 DECSLIDE KEYPAU REFERENCE CARD	#UAXZVHS	VAX-11 DECSLIPE	1	FEB 84
AV-Z758A-TE-001 1.0	VAX-11 RCP RELEASE NOTES	*VAX/VHS	VAX-11 FCF		JUL 84
AV-Z779A-TE-001 1.3	ALL-IN-1 READ ME FIRST	*VAX/VMS	ALL-IN-1 UFFICE MENU		JUL 84
EH-S1046-78-001 1.5	PDF-11 FROGRAMMING CARD	*VAX/VMS	Hlururuwer/Pascal-Vhs		ोति हैं।
EH-S1046-78-001 4.0	PDP-11 PROGRAMMING CARD	*VAX/VH3	R3X-115	*	3E1 82

PART

TITLE OF MANUAL	NOMBER REV LEVEL	VERSION	PRODUCT NAME	OPERATING SYSTEM		NAIL
	and the second					
3270 TERNINAL ENULATUR KEYBOARD LAYOUT	AV-9075A-TE-001	3.0	RSX 11M 3271 PROTOCOL EMULATOR	1RSX	1	AFT: 83
ADDENDUH TO SPD	AE-FR27A-1K-001	1.0	COMM TOE-THE	*RSX	1	MAY 84
ADDENDUH TO SPD	AE-RB27A-TK-001	1.0	COMM TOP-DZ	#RSX		JUL 84
ADDENDUM TO SPD	AE-BR27A-TK-001	3.1	DX/11M	tRSX		JUL 84
ADDENDUH TO SPD	AE-BB27A-TK-001	1.2	LABORATURY SUBROUTINE PACKAGE	*PSX		JUL 84
ADSENDUM TO SPD	AE-RR27A-TK-001	1.3	SSP-11	*RSX		JUL 34
BASIC ON REX-11H/H-PLUS SYSTEMS (UPD#1 & #2)	AA-L338A-TC-002	2.2	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	RSX	3	MAY 84
BASIC ON RSX-11H/H-PLUS SYSTEMS (UPD#1)	AA-L338A-10-001	2.1	BASIC-FLUS-2 FUR REY-11M/M-FLUS	*RSY	3	JAN 84
BASIC ON RSX-11M/N-PLUS SYSTEMS (UPD#1)	AA-L338A-TC-001	2.1	PROFESSIONAL LOUE KIT BASIC-PLUS-2	*RSX	1	JAN 84
BASIC ON RSX-11H/H-PLUS SYSTEMS (UPD#1)	AA-L338A-1C-002	2.2	PROFESSIONAL 100% KIT BASIC-PLUS-2	*RSX		JUL 84
BASIC POCKET REFERENCE GUIDE	AV-L341A-TK-001	2,6-2,2	RASIC-PLUS-2 FOR RSX-11h/h-PLUS	#FSX	r) ~	APE 83
BASIC POCKET REFERENCE GUIDE	AV-L341A-TK-001	2,0-2,2	PROFESSIONAL TOOL KIT BASIC-PLUS-2	#REX	2	APR 83
BASIC REFERENCE MANUAL	AA-L334A-TK-001	2.0-2.1	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	*RSX	6	APR 83
RASIC REFERENCE MANUAL	AA-L334A-TK-001	2,0-2,1	PROFESSIONAL 100L KIT BASIC-PLUS-2	#R5X	t	APR 83
BASIC REFERENCE MANUAL (UPD \$1)	AA-L334A-TK-002	2.2	PROFESSIONAL TOOL KIT BASIC-PLUS-2	#PSX		JUL 84
BASIC REFERENCE MANUAL (UPD#1)	AA-L334A-TK-002	2.2	BASIC-PLUS-2 FUR RSX-11M/M-PLUS	*RSX	6	MAY 24
RASIC USER'S GUIDE	AA-L335A-FK-001	2.0-2.1	BASIC-PLUS-2 FUR RSX-11H/H-PLUS	#RSX	2	APR 83
BASIC USER'S GUIDE	AA-L335A-TK-001	2,0-2,1	PROFESSIONAL 100L K11 BASIC-PLUS-2	4RS)	3	AFR 93
BASIC USER'S GUIDE (UPD#1)	AA-L335A-TK-002	2.2	BASIC-PLUS-1 FOR RSX-11h/H-PLUS	#R9X	3	MAY 84
BASIC USER'S GUIDE (UPD#1)	AA-L335A-1K-002	2,2	PROFESSIONAL 100L KIT BASTU-PLUS-2	#RS):		JUL 94
RASIC+2 RSX-11M/M-PLUS INSTL GDE/REL NOTES	AA-0158E-TC-001	2.1	RASIC-PLUS-2 FOR RSX-11A/M-PLUS	*R5%	1	JAN 84
BASIC+2 RSX-11M/M-PLUS INSTL GDE/REL HOTES	AA-0158F-1C-001	2+2	BASIC-PLUS-2 FOR RSX-11h/H-PLUS	THEY	i	нау уа
BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	AA-P102B-FK-001	2.1	PROFESSIONAL FOOL KIT BASIC-PLUS-2	\$147.7	1	J4N 24
BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	AA-F102C-1K-001	2.2	PROFESSIONAL 100E RTT BASTU-PLUS-2	*RS%	i	MAY EA

TITLE OF	PART NUMBER REV		PRODUCT	orerally6		
HANUAL	LEVEL	VERSION	NAME	SYSTEM	FICHE	UATE
BASIC-PLUS-2 V2.1 SPD 14.11.8	AE-J1971-TC-001	2.1	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	#R5.4	1	FEE 01
BASIC-PLUS-2 V2.2 SPD 14.11.10	AE-J197K-TC-001	2,2	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	TESX	1	MAY 84
BCP USER'S GUIDE	AA-N269B-TK-001	1.0	PCF	\$85%	3	1EE 34
BCF V1.0 RELEASE NOTES	AV-N270R-TC-001	1.0	BCF	FRSY	1	APR 83
BCP V1.0 SPD 14.72.0	AE-N202A-TU-001	1.0	BC.E.	#RSX	1	FEB 84
BEFORE YOU INSTALL DBMS-11 V2.1	AV-P666A-TC-001	2.1	DBMS-11	#RSX	1	APE: 33
CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	AA-N061A-TC-001	1.0	CHR11/CHV11 SOFTWARE DRIVER	RSX	1	APR 83
CMR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	AA-N061B-1C-001	3.0	CMR11/CMV11 SOFTWARE DRIVER	*RSY	1	FEB 84
CHR11/CHV11 SOFTWARE DRIVER RELEASE NOTES	AV-N058A-FE-001	1.0	CHR11/CHV11 SOFTWARE DRIVER	FSX	1	APR 83
CMR11/CMV11 SOFTWARE DRIVER USER'S GUIDE	AA-N060R-TC-001	3.0	CMR11/CMV11 SOFTWARE DRIVER	#RSX	1	FEB 84
CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE	AA-N060A-TC-001	1.0	CHR11/CHV11 SOFTWARE DRIVER	FSX	1	APR 83
CHR11/CHV11 V3.0 SPD 14.76.01	AE-N059B-TC-001	3.0	CMR11/CMV11 SOFTWARE URIVER	#ESX	1	may d4
COBOL-81 LANGUAGE REFERENCE MANUAL	AA-J434B-TC-001	2.0	COROL-81/RSX	#RS%	4	JAN 84
COBOL-81 LANGUAGE REFERENCE HANUAL	AA-J434B-TC-001	2.1	PROFESSIONAL TOOL KIT COROL-81	#RSX		JUL 84
COBOL-81 PUCKET GUIDE	AV-H630C-TC-001	2.0	COBOL-81/RSX	<b>*</b> R5X	2	JAN 84
COBOL-81 POCKET GUIDE	AV-H630C-TC-001	2.1	PROFESSIONAL TOOL KIT COPOL-81	#RSX		JUL E4
COBOL-81 RSX V2.0 SPD 14.26.03	AE-P07/E-TC-001	2.0	COROL-81/RSX	#RSX	Ter	FEB 84
CONN IOP-DUP PROGRAMMER'S MANUAL	AA-5670A-1C-001	1.0	COMM TOP-DUP	*RSX	1	SEF 82
CONN 1/1P-DUP RELEASE NOTES (INCLUDES UPD#1)	AA-1/367A-TC-001	1.0	COMM TOR-DUF	≢RSX	1	dtb 81
COMM IOP-DUP V1.0 SPD 10.12.2	AE-14121C-TC-001	1.0	COMM TOP-DUP	TRSX		JUL 84
CONN IOP-DZ PROGRAMMER'S MANUAL	AA-5127A-TC-001	1.0	COMB 10F-02	*RSX	1	3EP 82
CONN-TOP-DZ RELEASE NOTES (INCLUDES UPD#1)	AA-D368A-1C-001	1.0	COMM 10F-HZ	*HSX	1	SFE 85
COMM IOP-DZ V1.0 SPD 10.11.2	AE-1/1220-TC-001	1.0	COMM 10F-02	#RS%		JUL 84
COKAL-66 LANGUAGE REFERENCE MANUAL	AA-D111C-TK-001	4.0	CUMAL-66	rrsx.	>	58 41A
CORAL-66 V4.0 SPD 14.56.10	AE-34501-FC-001	4.0	CURAL-66	1P5X	1	MAY 84
CORE GRAPHICS LIBRARY MANUAL	AA-N619A-1K-001	1.0	PROFESTIONAL HUST TUCK HIT	regy	2	APE 83

TITLE OF MANUAL	PART NUMBER REV LEVEL	VERSION	PRODUCT NAME	OFEFATING SYSTEM	NUMPER CF F1CHE	half
CORE GRAPHICS LIBRARY MANUAL	AA-N619B-TK-001	1.0	PROFESSIONAL HOST FOOL KIT	#RSX	ES de	MAY 04
CRM11/CMV11 SUFTWARE URIVER KELEASE NOTES	AV-N058B-TC-001	3.0	CHR11/CHV11 SOFTWARE DRIVER	#RSX	1	FEH 84
DATATRIEVE-11 CALL INTERFACE MANUAL	AA-U050A-TC-001	3.0	9ATATRIEVE-11	#RS	2	JAN 84
DATATRIEVE-11 GUIDE TO WRITING REPURTS	AA-U051A-1K-001	3.0	DATATRIEVE-11	#85X	1	FEB 84
DATATRIEVE-11 INSTALLATION GDE/REL NOTES	AA-X022A-TC-001	3.0	DATATRIEVE-11	*RSX	1	JAN 84
DATATRIEVE-11 POCKET GUIDE	AA-X103A-TK-001	3.0	DATATRIEVE-11	*RSX	1	FEB 84
DATATRIEVE-11 REFERENCE MANUAL	AA-U049A-TK-001	3.0	DATATRIEVE-11	*RSX	4	FEB 84
DATATRIEVE-11 SUMMARY DESCRIPTION	AA-U052A-10-001	3.0	PATATRIEVE-11	#R(S)X	1	JAN 94
DAYATRIEVE-11 USER'S GUIDE	AA-X02JA-TK-001	3.0	DATATRIEVE-11	*RSX	3	FEB 84
DATATRIEVE-11 V3.0 SPD 12.48.11	AE-C777L-1C-001	3.0	DAYATRIEVE-11	ARSX	1	MAY 84
DBMS-11 DATA BASE ADMINISTRATOR'S (DBA) GUIDE	AA-HB058-TC-001	2.0-2.1	DBMS-11	*R5%	4	SEF 82
- DBMS-11 INSTALLATION GUIDE	AA-K885B-TC-001	2.0-2.1	DBMS-11	*RSX	2	SEP 82
DBMS-11 V2.0 RELEASE NOTES	AA-K886R-TC-001	2.0-2.1	DBMS-11	*RSX	1	SEP 82
DBMS-11 V2.1 SPD 12.66.2	AE-M130D-TC-001	2.1	DEMS-11	*RSX	1	FEB 84
DBHS-11/N+ DDL/DEVICE MEDIA CON LANG REF NAN	AA-H804B-FC-001	2.0-2.1	DBMS-11	*RSX	3	SEF 92
DBMS11 COBOL DATA MANIPULATION LANG REF MAN	AA-K884E-TC-001	2.0-2.1	IRMS-11	tRSX	2	SEF 82
DBHS11 FORTRAN DATA MANIPULATION LANG REF MAN	AA-KB83R-TC-001	2.0-2.1	DBM5-11	*RSX	2	SEP 82
DECLAB-11/NINC USER'S GUIDE	EK-MNC11-UG-001	1.1-1.2	RSX 11M F ENHANC FKG FOR MINC	*RSX	2	APR 83
DECNET RSX SYSTEM MANGER'S MINI REF GUIDE	AA-X924A-TC-001	4.0	DECNET-11M	*RSX	1	MAY 84
DECNET-11H V4.0 SPD 10.75.10	AE-3431K-TC-001	4.0	DECMET-11M	#RSX	1	MAY 84
DECNET-RSX VOLUME II USER'S INFORMATION	AV-Y553A-TC-001	4.0	DECNET-11M	#RSX		JUL 84
DIBOL LANGUAGE REFERENCE CARD	AA-U067A-TK-001	1.6	FROFESSIONAL FOOL KIT BIRDL	RSX	1	MAY 84
DIBOL-83 COMPATIBILITY MANUAL	AA-V810B-TK-001	1,6	PROFESSIONAL FOOL NIT DIBOL	#RSX	1	MAY 84
DIBOL-83 LANGUAGE REFERENCE CARD	AV-U067A-1K-001	1.6	PROFESSIONAL FOOL NIT DIROL	*R5X		JUL 24
DIBOL-83 LANGUAGE REFERENCE MANUAL (UPD#1)	AA-U066A-TK-001	1.6	PROFESSIONAL FOOL KIT DIBOL	*RSX	2	FEB 84
DOCUMENTATION GUIDE LINES	AA-N621A-1K-001	1.0	PROFESSIONAL HOST TOOL KIT	#R5X	1	APR 83

TITLE OF HANUAL	PART Number Rev Level	VERS10N	PRODUCT MAME	OPERATING SYSTEM	NUMBER OF FICHE	IAIE
BPH V4.1 SPD 15.6.6	AE-5730H-TC-001	4.1	DPM	*RSX	1	FEB 84
DPN/DPN PLUS REFERENCE GUIDE	AV-M195A-TC-001	4.1	DPH	4R9X	1	SEP 82
DPH/DPH PLUS RELEASE NOTES	AA-N150A-TC-001	4.1	UPM	*RSX	1	SEP 82
DPN/DPH+ BECDATA INTELL SUBS USRS GDE (UPD41)	AA-J529R-TC-001	4.1	DPH	#RSX	3	SEP 82
IPH/DPH+ SYSTEM GENERATION/MANAGEMENT GDE	AA-J5310-70-001	4.1	DFM	<b>≯</b> RSX	2	SEP 82
DPN/DPN+ TERNIANL USER'S GUIRE (UPD#1)	AA-J530k-10-001	4.1	DPA	*RSX	2	SEP B2
DT07-11H V1.1 SPD 14.36.1	AE-K5348-TC-001	1.1	DF07-11M	#RSX	1	FEB 84
DT07-11M V1.1 USER'S GUIDE	AA-K568A-TC-001	1.1	D107-11M	*RSX	1	SEP 82
DX PRODUCTS PROGRAMMER'S REFERENCE MAMUAL	AA-5469C-FC-001	3.1	0X/11H	*RSX	1	AFR 83
DX PRODUCTS USER'S GUIDE	AA-54761-1C-001	3.1	DX/11M	*RSX	1	AFR 83
DX/11H INSTALLATION GUIDE	AA-B997A-TC-001	3.1	DX/11h	≉RSX	1	AFR 83
DX/11H V3.1 SPB 10.96.4	AE-5274F-10-001	3.1	DX/11M	#RSX	1	FER 84
DX/11H VERSION 3.1 RELEASE NOTES	AA-H288B-TC-001	3.1	DX/11M	*RSX	1	APR 83
EDT EDITOR MANUAL	AA-J726A-1C-001	4.1	RSX-11H	RSX	3	NON 83
EDT EDITOR HANUAL	AA-H476A-TK-001	4.1	RSX-11M	*RSX	8	FEB 84
EDT EDITOR HANUAL	AA-J726A-TC-001	2.1	RSX-11M-PLUS	RSX	3	NOV 83
EDT EDITOR NAMUAL	AA-M476A-TK-001	2.1	RSX-11H-PLUS	*RSX	8	FEB 84
EDT EDITOR REFERENCE CARD	AV-J756A-TC-001	4.1	RSX-11M	RSX	3	MDA 83
EDT EDITOR REFERENCE CARD	AV-J756A-TC-001	2.1	RSX-11M-PLUS	RSX	1	NOV 83
EDT QUICK REFERENCE HANUAL	AA-M47/A-TK-001	4.1	RSX-11H	#RSX	1	FER 84
EDT. QUICK REFERENCE MANUAL	AA-H477A-TK-001	2.1	RSX-11M-FLUS	#RSX	1	FEB 84
FMS-11/RSX RELEASE HOTES	AA-H857A-10-001	1.0	PROFESSIONAL HOST TOOL KIT	*R5X	1	APR 83
FNS-11/RSX SOFTWARE REFERENCE MANUAL	AA-H855A-TC-001	1.0	PROFESSIONAL HOST TOOL KIT	*RSX	3	AFR 83
FMS-11/RSX V1.0 SPD 12.27.07	AE-J405H-TC-001	1.0	FMS-11/RSX	*RSX		JUL 84
FMS-11/RSX V1.0 SPD 12.27.5	AE-J405F-TC-001	1.0	FMS-11/RSX	*RSX	1	FEB 84
FMS-11/RSX-11M HIMI REFERENCE GUIDE	AV-H856A-TC-001	1.0	FMS-11/RSX	*HSX	1	SEP 82

	TITLE OF MANUAL	PART NUMBER REV LEVEL	VERS10N	PRODUCT NAME	OPERALING SYSTEM	NUMBER OF FICHE	PATE
F	NS-11/RSX-11M RELEASE NOTES	AA-H257A-TC-001	1.0	FMS-11/RSX	#RS t	1	SUF 82
fi	MS-11/RSX11M SOFTWARE REF MANUAL (UPD#1)	AA-H855A-TC-001	1.0	FMS-11/RSX	#RSX	3	SEF 82
F	ORTRAN 1V/RSX V2.6 SPD 14.63.10	AE-3443K-TC-001	2.6	FORTRAN IV/RSX	*RSX	1	MAY 84
F	DRTRAN IV/RSX V2.6 SPD 14.63.9	AE-3443J-TC-001	2.6	FORTRAN 19/RSX	*RSX	1	FEH B4
F	ORTRAN-77/DEBUG INSTAL GUIDE/REL NOTES	AA-X650A-TK-001	1.0	FURTRAN-7/ DEBUG, PDP-11	*RSX	1	JAN 84
I	AS/RSX ODT REFERENCE MANUAL SUPPLEMENT	AA-P193R-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	MRSX	1	JAN 84
I	AS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	AA-H176A-TC-001	4.1	RSX-11H	#RS>	3	NOV B3
I	AS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	AA-H176A-TC-001	2.1	RSX-11M-FLUS	#RSX	3	HOU 33
I	AS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	AA-M176A-TC-001	4.1	RSX-11S	#FSX	3	NBV 83
I	AS/RSX-11 ODT REFERENCE MANUAL	AA-M507A-TC-001	4.1	RSX-118	*HSX	1	E8 VON
I	AS/RSX-11 ODT REFERENCE MANUAL	AA-M507A-TC-001	2.1	RSX-11M-PLUS	#RSX	1	NÚV 83
I	AS/RSX-11 ODT REFERENCE MANUAL	AA-H507A-1C-001	4.1	RSX-11S	<b>KRSX</b>	1	NOV 83
I	AS/RSX-11 ODT REFERENCE MANUAL	AA-M507A-TC-001	1.0	PROFESSIONAL HOST 100L KIT	*RSX	1	APR 83
I	AS/RSX-11 SYS LIB ROUTINE REF MANUAL	AA-5580B-TC-001	4.1	RSX-11S	#RSX	2	40V 83
I	AS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL	AA-5580R-TC-001	4.1	RSX-11H	*RSX	2	83 VON
I	AS/RSX-11 SYSTEM LIR ROUTINE REF MANUAL	AA-5580R-TC-001	2.1	RSX-11H-FLUS	*RSX	2	NUV 83
I	EC-11M RELEASE NOTES	AV-V507A-TC-001	3.0	IEC-11h	#RSX	1	PER 84
11	EC-11H RSX SOFTWARE MANUAL	AA-H275A-10-001	3.0	IEC-11H	#RSX	1	SEP 32
I	EC-11M V3.0 SPD 14.64.0	AE-N029A-FC-001	3.0	1EU-11M	*RSX	1	FEB 84
I	NTRO TO FEP & FRP ERRATA SHEET	AV-V191A-TE-001	1.2	RSX 11H F ENHANC PRG FOR MINC	¥fiSX	1	JAN 84
1	NTRODUCTION TO DATATRIEVE-11	AA-X025A-FK-001	3.0	DATATRIEVE-11	*RSX	1	H.B 84
I	NTRODUCTION TO DECNET	AA-J055C-1K-001	3.1	DECNET-11H	#RSX	2	FER 84
Ii	NTRODUCTION TO DECNET	AA-J055U-TK-001	4.0	DECNET-11H	#FSx	3	MFT 84
I	NTRODUCTION TO DIBOL	AA-P042A-1K-001	1.0-1.6	PROFESSIONAL (DOL MI) 0180L	ARSX	1	८६ पयस
I	NTRODUCTION TO FEP AND FRP	AA~J302B-TC-001	1,1-1,2	RSX 11M F ENHANC PKG 10K MINC	*FSX	1	AFF 83
J	NTRODUCTION TO RSX-11 FSI	AA-M369A-10-001	2.0	RSX 11 PS1/M	1887	1	SEF 82

TITLE OF MANUAL	PART NUMBER REV LEVEL	VERS10N	FRODUCT NAME	UPERATING SYSTEM	HUMPER UF FICHE	( NATE
INTRODUCTION TO RSX-11M AND RSX-11M+	AA-L763A-TC-001	2.1	RSX-11M-PLUS	*RSX	2	NOV 83
INTRODUCTION TO RSX-11H AND RSX-11H-PLUS	AA-L763A-TC-001	4.1	RSX-11H	#RSX	2	NOV 83
KMC-11 TOOLS V1.0 SPD 12.49.04	AE-0776E-T0-001	1.0	KMC-11 TOOLS	*RSX	1	mA1 84
KNC11 PROGRAMMER'S MANUAL	AA-5244B-TC-001	1.0	KMC-11 100LS	#RSX	2	SEF 82
KHV11-A HOLC FRAMING SETWARE FOR RSX REF HAN	AA-N565A-TC-001	1.0	KMV11-A HDLC FRAMING SOFTWARE	#RSX	1	APR 93
KNV11A-HDLF FRAMING SOFTWARE V1.0 SPD 14.22.0	AE-R298A-10-001	1.0	KNV11-A HULC FRAHING SOFTWARE	*RSX	1	FER 84
LAB SUBROUTINES PROG REF MAN (UPD#1)	AA-09840-T0-001	1.1-1.2	RSX 11M F EMMANC PKG FOR HINC	*RSX	3	APR 83
LABORATORY SUB PROGRAMMER'S REF MAN (UPD#1)	AA-C984C-TC-001	1.2	LABORATORY SUBROUTINE PACKAGE	*R9X	1	SEP 82
LSP REFERENCE MANUAL ERRATA SHEET	AV-V190A-TC-001	1.2	RSX 11M F ENHANC PKG FOR MINC	#RSX	1	JAN 84
LSP V1.2 SPD 15.44.06	AE-06076-TC-001	1.2	LABORATORY SUBROUTINE PACKAGE	<b>1</b> 85%	1	MAY 84
LSP V1.2 SPD 15.44.5	AE-0607F-TC-001	1.2	LABORATORY SUBROULINE PACKAGE	*RSX	1	FEB 84
MDE/T-11 USER'S GDE/REF HANUAL	AA-H845R-TK-001	1.0	RSX MDE/111	*RSX	2,	AFR 33
MDE/T-11 V1.0 INSTE GDE/REL MTS	AV-P511A-TC-001	1.0	RSX ADE/T11	<b>*</b> F'5X	1	APK 83
HUE/TIL REFERENCE CARD	AV-M846R-1K-001	1.0	RSX MDE/T11	*RSX	1	FEF 84
HICROCOMPUTERS AND HEHORIES HANDBOOK	EB-20912-20-001	1.1-1.2	RSX 11M F ENHANC PMG FOR MINC	*RSX	8	APR 83
MINC THERMOCOUPLE PREAMPLIFIER USER'S GUIDE	EK-MNCTP-UG-001	1.1-1.2	RSX 11M F ENHANC PRG FOR MINC	*RSX	1	APR 83
MUX200/RSX-IAS SYSTEM MANAGER GUIDE	AA-1344C-TC-001	2.1	MUX200/RSX-IAS	†FS)	9.	JAN 84
HUX200/RSX-1AS USER'S GUIDE	AA-1346C-1C-001	2.1	MUX200/RSX-1AS	#F5X	1	JAN 64
NUX200/RSX-IAS V2.1 RELEASE NOTES	AA-1343C-TC-001	2.1	MUX200/RSX-IAS	#RSX	1	JAN 94
HUX200/RSX-IAS V2.1 SPI 10.77.07	AE-34531-16-001	2.1	MUX200/RSX-1AS	1FSY	1	FER 84
OBSERVER EVENT MESSAGE REFERENCE MANUAL	AV-X074A-TC-001	1.1	URSERVER	152/		JUL 84
OBSERVER INSTA GUIDE AND GEN GUIDE	AA-N959A-10-001	1.0	ORSERVER	ESX	1	aft 13
OBSERVER INSTL GUIDE AND GON GUIDE	AA-N759B-TC-001	1.1	ORSERVER	THSX	1	rF# Bq
OBSERVER REFERENCE CARD	AV-X073A-16-001	1.1	ORSERVER	*\$\\$%	1	FEE EA
OBSERVER RELEASE NOTES	AA-N982A-10-001	1.0	ORSERVER	F5X	6 2 3	APF 83
OBSERVER RELEASE NOTES	AA-N9628-TC-001	1.1	ORSERVER	#31	1	- EB +4

## INDEX BY THE TITLE-OF-THE-MANUAL

TITLE OF HANUAL	PART NUMBER REV LEVEL	VERS10N		PRODUCT NAME	0FERA [No	NUMPER (1)° FILHE		116
OBSERVER USER'S GUIDE	AA-N960A-TC-001	1.0	UBSERVER		R/5.3	3	AFR	83
ORSERVER USER'S GUIDE	AA-N960E-TC-001	1.1	OBSERVER		trsy.	7	FER	84
OBSERVER V1.1 SPD 13.18.02	AE-P335C-TC-001	1.1	OBSERVER		*RSX	1	YAH	84
OVERVIEW OF RSX DECNET	AA-M096A-TC-001	5.1	DECNET-11M		IRSX	2	FEB	24
OVERVIEW OF RSX DECNET	AA-N096B-TC-001	4.0	DECNET-11M		#RSX	2	MAT	99
OVERVIEW TO DIGITAL NETWORK PROCESURES	AA-X105A-1K-001	4.0	DECHET-11H		TRSX	2	MAY	84
P/OS SYSTEM REFERENCE HANUAL	AA-N620A-IK-001	1.0	PROFESSIONAL I	HOST TOOL KIT	tRSX	4	erk	83
P/OS SYSTEM REFERENCE HANUAL (UP142)	AA-N620A-TK-002	1.0	PROFESSIONAL I	HOST 100L XIT	TRSX.		[H]	84
PDP-11 COBOL INSTALLTION GUIDE	AA-1745F-TC-001	4.4	PDF-11 COBOL		*RSX	1	SEF	62
PDP-11 COBOL USER'S GUIDE (INCLUDES UPD41)	AA-1757E-TE-001	4.4	PDF-11 COBBL		#ESX	5	SFr	83
PDP-11 COBOL V4.4 SPD 12.40.18	AE-3417S-FC-001	4.4	POP-11 COBOL		#FSX	1	111	84
POP-11 CORAL-66 V4.0 INSTE GDE/REL NOTES	AA-1744E-10-001	4.0	CCRAL-66		#RSX	1	APF	53
PDP-11 F-77 LANGUAGE REFERENCE HANUAL	AA-V193A-TK-001	5.0	PROFESSIONAL	FOOL KII FORTRAH-77	TRSX	3	FEB	84
PDP-11 FORTRAN LANGUAGE REFERENCE MANUAL	AA-R953A-TK-001	2.6	FORTKAN 1V/RS	X	<b>FRSX</b>	,1	JAN	H4
PDF-11 FORTRAN-77 DEBUG V1.0 SPD 30.33.00	AE-Y398B-TK-001	1.0	FORTRAN-/7 DE	RUG: PIP-II	*RSX	1	tēt	84
PDP-11 FORTRAN-77 INSTL GUIDE/REL NOTES	AA-V196A-1K-001	5.0	FURTRAN-77/RS	Yo PDF-11	#RSX	1 4	JAN	84
PDP-11 FORTRAN-77 LANGUAGE REFERENCE MANUAL	AA-V193A-TK-001	5.0	FORTEAM-77/ES	x, FTF-11	*RSX	3	FER	84
PDP-11 FORTRAN-77 OTS REFERENCE MANUAL	AA-V195A-TK-001	5.0	FORTRAN-77/RS	X- Pur-11	#R:SX	2	FEF	84
PDP-11 FORTRAM-77 OTS REFERENCE HANUAL	AA-V195A-TK-001	5.0	PROFESSIONAL	TUUL FIT FORTRAN-7/	tRSX		FEB	21
PDP-11 FORTRAN-77 USER'S GUIDE	AA-V194A-TK-001	5.0	FORTRAN-77/RS	X FUP-11	*ReX	2	t[j.	84
PDP-11 FORTRAN-77 USER'S GUIDE	AA-V194A-TK-001	5.0	PROFESSIONAL	TOUL KIT FORTRAN-77	#FS).	?	11.	34
PDP-11 FORTRAN-77/DEBUG USER'S GUIDE	AA-V197A-TK-001	1.0	FORTRAN-77 DE	RUG, F1F-11	\$85)	2	JAN	84
PDP-11 FORTRAN-77/RSX V5.0 SPI 14.31.06	AE-J139G-TC-001	5.0	FORTRAN-77/ES	λ, F07-11	185x	1	FEL	84
PDP-11 FORTRAN-77/RSX V5.0 SPIE 14.31.07	AE-J139H-TC-001	5.0	FURTEAN-777ES	X, FIF-11	\$177.A	1	MAY	84
PDF-11 MACRU-11 LANGUAGE REF MANUAL	AA-V027A :FC-001	4.1	RUX IIN		*I(5)	77	NO.	91
PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	AA-V027A-FC-001	2.1	PSX-11H-F1/15		4 ft Z 3	3	NUI	87

	TITLE OF HANUAL	PART NUMBER REV LEVEL	VERSION	PROBUCT NAME	UPERACING SYSTEM	HUMBER UF FILHE	VATE
PDP-1	1 MACRO-11 LANGUAGE REFERENCE MANUAL	AA-V02/A-TC-001	4.1	R92-115	#RSY	3	HOV 93
PDP-11	1 MACRO-11 LANGUAGE REFERENCE MANUAL	AA-V027A-TC-001	1.0	PROFESSIONAL HOST TOOL NIT	*RSX	3	JAN 84
PDP-1	1 HICROCOMPUTER INTERFACES HANDBOOK	ER-23144-18-001	1.1-1.2	RSX 11M F ENHANG PKG FOR MENC	#RSX	7	APR 83
PDP-1	1 PASCAL INSTALLATION GDE/REL NOTES	AA-4877A-TC-001	1.0	PASCAL/RSX, FDF-11	RSX	1	JAN 84
PDP-1.	I PASCAL INSTALLATION GDE/REL NUTES	AA-H8775-10-001	1.1	PASCAL/RSX, PDF-11	*KSX	1	MAY 84
PDF-11	1 PASCAL LANGUAGE REF HANUAL (UPI) \$1)	AA-H875A-TC-002	1.1	PASCAL/RSX, FUP-11	*RSX	1)	FEH 84
PNP-1	1 PASCAL LANGUAGE REFERENCE MANUAL	AA-M875A-TC-001	1.0	PASCAL/RSX: PUF-11	RSX	2	JAN 84
PDP-11	1 PASCAL USER'S GUIDE	AA-H876A-TC-001	1.0	PASCAL/RSX, FDF-11	HSX.	2	JAH 84
PDP-1	1 PASCAL USER'S GUIDE (UPD\$1)	AA-H876A-TC-002	1.1	PASCAL/RSX, PUP-11	#RSX	2	FEE 84
PDP-11	1 PASCAL/RSX V1.1 SFD 14.18.02	AE-N9170-T0-001	1.1	PASCAL/RSX, PDF-11	*RSX	1	FEE 34
PDP-1	1 PASCAL/RSX V1.1 SPD 14.18.03	AE-N917E-TC-001	1 i	FASCAL/RSX+ PPP-11	*#S4	1	mar 84
PDP-11	1 PROGRAMHING CARD	EH-S1046-78-001	4.1	RSX-11H	4ESX	1	NOV 83
PDP-1	1 PROGRAMMING CARD	EH-S1046-78-001	2+1	RSX-11H-PLUS	*RSX	1	NUV 83
PDP-11	1 PROGRAMMING CARD	EH-S1046-78-001	4+1	R9X-119	₹RSX	1	NOA 83
PDP11	CODOL LANG REF MANUAL (UPD#1 & #2)	AA-1749E-TC-001	4.4	PDF-11 COROL	*RSX	3	SEF 82
PDP11	KEYPAD EDITOR REFERENCE CARD	AV-H854A-TC-001	1.0	FMS-11/RSX	##SX	1	8Etr. 83
PDP11	KEYPAD EDITOR RELEASE NOTES	AA-J892A-TC-001	1.0	FHS~11/RSX	≭RSX	!	SEF 82
PDP11	KEYPAD EDITOR USER'S GRE (UFD#1)	AA-H853A-TC-001	1.0	FMS-11/RSX	#ESX	2	SEP 82
PDP11	SORT REFERENCE HANUAL (UPDATE \$!)	AA-3341C-TC-001	2.0	SURT-11	*ĒSX	2	SEP 82
PLXY-	11 USER'S GUIDE	AA-J535B-TK-001	1.3	PLXY-11H	#FSX	1	MAY 84
PLXY-	11 V1.1 USER'S GUIDE	AA-J535A-TK-001	1+1	PLX) -IIh	*830	Ī	9LP 81
PLXY-	11 V1.3 SPD 14.39.01	AE-K797R-10-001	1.3	FLXY-11M	#HSX	1	MAY 84
PRO H	OST TK F-77 IG/DOC SUPL	AA-R3º/B-TK-001	5.0	PROFESSIONAL TOOL KIT FURTRAM-7/	#REX	1	JAN 184
PRO TO	OOL KIT BASIC + 2 INSTL GDE/REL NTS	AA-F104R-TK-001	2.1	PROFESSIONAL 1001 KIT FASIC-FLUS-	S ALPX	1	ोसत हैय
PRO T	00. KIT BASIC-PLUS-2 V2.2 SPB 36.27.01	AE-P650B-TK-001	2.2	PROFESSIONAL TOOL KIT BASIC-PLUS-	1 K'51	ı	min bi
PRO TO	OOL KIT COROL-81 INSTE GDE/DOC SUPL	AA-Y285A-TH-001	2.1	PROFESSIONAL TOOL KIT CUROL-81	thor		41. 44

TITLE OF MANUAL	PART NUMBER REV LEVEL	VERSION		PRODUCT NAME	UMERALING SYSTEM	NUMBER OC FICHE	iait
PRO TOOL KIT FORTRAN-77 V5.0 SPD 30.38.01	AE-W587R-TK-001	5+0 PR	OFESSIONAL	FOOL KIT FORTRAN-77	#R5X	1	MAT 84
PRO TOOL KIT FORTRAN-77/DBG 1G/DOC SUFL	AA-Z384A-TK-001	1.0 FH	O TOOL KIT	FURTRAN-77 PBG	TRSX	1	MAY 84
PRO TOOL KIT FORTRAN-77/DBG V1.0 SPD 40.25.00	AE-Z847A-TH-001	1+0 PR	0 100L KII	FORTRAN-77 DEG	*RSX		JUL 34
PRO TOOL KIT INSTL GDE/REL NTS	AA-N616B-1K-001	1.0 PR	OFESSIONAL	H097 T00L K17	RSX	1	JAN 84
PRO TOOL KIT MESSAGE MANUAL	AA-Z515A-TN-001	1.6 PR	OFESSIONAL	100F K11 D180F	‡RSX	1	FEB 84
PRO TOOL KIT PASCAL INSTL/REL NOTES	AA-R7593-TK-001	1.1 PR	OFESSIONAL	100L KIT PASCAL	*RSY	i	MAY 84
PRO TOOL KIT PASCAL LANGUAGE REFERENCE MANUAL	AA-U047A-TK-001	1.1 PR	OFESSIONAL	TOOL NIT PASCAL	‡RSX	2	JAY 84
PRO TOOL KIT PASCAL USER'S GUIDE	AA-U046A-IK-001	1+1 PE	OF ESSIONAL	100L KIT FASCAL	FRSK		JAN 84
PRO TOOL KIT PASCAL V1.1 SPD 40.20.00	AE-Y992A-TH-001	1.1 PR	OFESSIONAL	FOOL KIT PASCAL	*RSX		JUL 84
PRO/FMS-11 DOCUMENTATION SUPPLEHENT	AA-P1038-TK-001	1.0 FR	OFESSIONAL	HUST TOOL KIT	WESX	1	JAN 64
PRO/RMS-11 MACRO PROGRAMMER'S GUIDE	AA-F099A-TK-001	1+0 FR	OFESSIONAL	HOST FOOL KIT	†RSX	5	APF 83
PRO/RMS-11: AN INTRODUCTION	AA-P098A-TK-001	1.0 PR	UFESSIONAL	HOST TOOL NIT	rRSX.	ţ	APR 83
PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL	AA-X912A-TH-001	1.0 PR	OFESSIONAL	HOST TOOL KIT	*RSX		JUL 84
PRO/TOOL KIT DOCUMENATION DIRECTORY	AA-X910A-TH-001	1.0 FR	OFESSIONAL	HOST 100L KIT	#RSX		JUL 84
PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES	AA-X911A-TH-001	1.0 FR	OFESSIONAL	HOST TOOL KIT	#RSX		JUL 84
PROFESSIONAL HOST COMM INSTL PROCEDURES	AA-F4128-1K-001	1.5 FR	OFESSIONAL	HOST COMMUNICATIONS	#RSX	1	JAN 84
PROFESSIONAL HOST COMM INSTL PROCEDURES	AA-P412C-TK-001	1.7 PR	OFESSIONAL	HOST COMMUNICATIONS	*RSX	1	Ma. 84
PROFESSIONAL TOOL KIT DIRCL LANG REF MANUAL	AA-F044A-TK-001	1.0 FK	OFESS10NAL	TUOL NIT DIEDL	HSX	3	APR 83
PROFESSIONAL TOOL KIT DIBOL REL NTS/INSTL HOE	AA-P045A-TK-001	1.0 PR	OFESSIONAL	LOOF KILL DIBOF	RSX	1	APR 83
PROFESSIONAL TOOL KIT DIROL REL NTS/INSTL GOE	AA-F045C-TK-001	1.6 FR	OFESSIONAL	TOOL KIT DIROL	¥15%	1	MAY 84
PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE	AA-P043A-FK-001	1.0 PR	OFESSIONAL	100L KII 0180L	FSX	2	ALE: 83
PROFESSIONAL TOOL KIT DIROL USER'S GUIDE	AA-F043C-TK-001	1.6 PR	OFESSIONAL	190E KIT 0180E	TESX	2	MAT 54
PROVUE OFFLINE PICTURE SYSTEM MANUAL	AA-M024B-TK-001	2.0 RS	X 11/6E0VU	E	¥P54	1	JAN 34
PROVUE ONLINE PICTURE SYSTEM MANUAL	AA-#025R-TK-001	2.0 FS	X 11/PROVUE		4R54	Į,	JAN SA
PROVUE PROGRAMMING GUIDE	AA-M026B-TK-001	2.0 RS	X 11/FROVUE		#P3x	1	JAN 84
PROVUE SYSTEM BUILD MANUAL	AA-H022R-TK-001	2.0 RS	X 11/PROVUE		#FISX	4	JAN 84

TITLE OF HANUAL	PART NUMBER REV LEVEL	VERSION	PRODUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	DATE
PROVUE SYSTEM MANAGER'S GUIDE	AA-H021B-TK-001	2.0	RSX 11/PROVUE	1RSX	1	JAN 64
PROVUE TERMINAL USER'S GUIDE	AA-H023E-TK-001	2.0	RSX 11/PROVUE	*RSX	1	JAN 84
PROVUE UTILITY GUIDE	AA-H027B-TK-001	2.0	RSX 11/PROVUE	#RSX	1	JAN 84
PROVUE V2.0 RELEASE NOTES	AA-H089E-TK-001	2.0	RSX 11/FROVUE	#RSX	1	JAN 84
PROVUE V2.0 SPD 14.33.1	AE-N271B-TC-001	2.0	RSX 11/PRUVUE	*RSX	1	FEB 84
REAL-11 PROBRAMMERS REFERENCE MANUAL ERRATA	AV-V187A-TC-001	1.2	RSX 11M F ENHANC FKG FUR HINC	*RSX		JUL 84
REAL11H/NNC FORTTRAN PROG REF MAN (UPD\$1,2)	AA-D631C-TC-001	1.1-1.2	RSX 11M F ENHANC PKG FOR MINC	1RSX	4	APR 83
RELEASE NOTES FOR RGL-11	AA-M839A-TC-001	1.1	RGL-11	RSX	1	API: 83
RELEASE NOTES FOR RGL-11	AA-H839E-TC-001	1.1	RGL-11	1RSX	1	FER 84
RELEASE NOTES FOR RSX-11M/FEP AND FRP	AA-H055II-TC-001	1.2	RSX 11H F ENHANC PKG FOR HIND	*HSX	1	JAN 84
RGL-11 INSTALLATION GUIDE	AA-M838A-TC-001	1.1	RGL-11	*RSX	1	APR 83
RGL-11 PROGRAMMER'S REFERENCE MANUAL	AA-H837A-TC-001	1.1	RGL-11	*RSX	3	APR 83
RGL-11 V1.1 SPD 14.62.04	AE-M802E-TC-001	1.1	RGL-11	*RSX	1	MAY 84
RGL-11 V1.1 SPD 14.62.3	AE-M802D-TC-001	1.1	RGL-11	*RSX	1	FEB 84
RGL/11 PROGRAMMER'S REFERENCE MANUAL	AA-M837A-TC-001	1.1-1.2	RSX 11M F ENHANC PKG FOR HINC	*RSX	3	APR 83
RGL/11 PROGRAMMERS REFERENCE MANUAL ERRATA	AV-V185A-TC-001	1.2	RSX 11M F ENHANC PEG FOR MINC	*RSX	3	JAN 84
RJE/HASP WORKSTATION INSTALLATION GUIDE	AA-5426C-FC-001	1.1	RSX 11h IAS RJE/HASP	#RSX	1	SEP 82
RJE/HASP WORKSTATION OPERATOR'S GUIDE	AA-5427C-TC-001	1.1	RSX 11M 1AS RUE/HASP	#RSX	1	SEP 82
RMS-11 PROGRAMMERS MANUAL	AA-L668A-TC-001	4.1	RSX-11M	#RSX	5	MOV 83
RNS-11 PROGRANMERS MANUAL	AA-L668A-TC-001	2.1	RSX-11M-FLUS	FRSX	5	hEA 83
RMS-11 USER'S GUIDE	AA-L669A-TC-001	4.1	RSX-11M	*KSX	7	NOV 83
RMS-11 USER'S GUIDE	AA-L669A-TC-001	2.1	RSX-11M-FLUS	#RSX	?	NOV 83
RMS-11 UTILITIES	AA-L670A-TC-001	2.1	RSX-11H-PLUS	*83}	3	NOW UE
RHS-11 UTILITIES MANUAL	AA-L670A-TC-001	4.1	RSX-11H	FRSX	3	WOA R3
RMS-11: AN INTRODUCTION	AA-L682A-TC-001	4.1	RSX-11H	#F5X	1	NOV 83
RMS-11: AN INTRODUCTION	AA-L682A-TC-001	2.1	RSX-11M-FLUS	#RSX	1	MON 83

	TITLE OF MANUAL	PART NUMBER REV LEVEL	VERSION	PRUDUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	UATE
RSX 11H SNA PE V	71.1 SPD 14.04.1	AE-J512C-TC-001	1,1	RSX 11m SNA PE	#RSX	1	FEB 84
RSX DECNET GUIDE	TO USER UTILITIES	AA-H223B-TC-001	3.1	DECNET-11H	*RSX	2	FEB 84
RSX DECNET GUIDE	TO USER UTILITIES	AA-H223C-TC-001	4.0	DECNET-11H	*RSX	2	HAT 84
RSX DECNET NETWO	RK CEN AND INSTALLATION GUILLE	AA-H225C-TC-001	4.0	DECNET-11M	*RSX	5	MAY 84
RSX DECNET NETWO	RK GEN AND INSTL GUIDE	AA-H225B-TC-001	3.1	DECNET-11M	*RSX	3	FEB 84
RSX DECHET POST-	INSTL CHECKOUT PROCEDURES	AA-J3198-TK-001	3.1	DECNEY-11M	*RSX	2	FER 84
RSX DECNET POST-	INSTL CHECKOUT PROCEDURES	AA-J319C-TK-001	4.0	DECNET-11M	‡RSX	1	MAY 84
RSX DECNET PROGR	AMMER'S REF MANUAL	AA-M098A-TC-001	3.1	DECNET-11H	*RSX	5	FEB 84
RSX DECNET PROGR	RANNER'S REFERENCE MANUAL	AA-H098B-TC-001	4.0	DECNET-11M	#RSX	4	MAY 84
RSX DECNET RELEA	SE NOTES	AA-J517B-1C-001	3.1	DECNET-11M	*RSX	1	FER 84
RSX DECNET RELEA	SE NOTES	AA-J517C-TC-001	4.0	DECNET-11H	*RSX	1	18 TAN
RSX DECNET SYSTE	H HANAGER'S GUIDE	AA-H224B-TC-001	3.1	DECNET-11M	*RSX	5	FEE 84
RSX DECNET SYSTE	M MANAGER'S GUIDE	AA-H224C-TC-001	4.0	DECNET-11M	*RSX	5	MAY 84
RSX DLX-11 RELEA	SE NOTES	AA-K143A-TC-0U1	1.0	RSX DLX-11	#RSX	1	SEP 82
RSX DLX-11 USER'	S GUIDE	AA-K142A-TC-001	1.0	RSX DLX-11	‡RS)	2	SEF 82
RSX DLX-11 V1.0	SPD 10.6.0	AE-K4348-TC-001	1.0	RSX DLX-11	*R5X	1	FER 84
RSX MDE/T-11 V1	0 SPD 14.23.0	AE-P081B-TC-001	1.0	RSX MDE/TI1	*RSX	1	FEB 84
RSX-11 2780/3780	ENULATOR USER'S GUIDE	AA-J581A-TC-001	4.1	RSX 11 2780/3780 EMULATOR	*RSX	1	3EF 82
RCX-11 PSJ GENER	RATION GUIDE	AA-H372A-TC-001	2.0	RSX 11 FSI/M	*RSX	2	SEP 82
RSX-11/PSI NETWO	ORK SPECIFIC INFORMATION	AA-H373A-1C-001	2.0	RSX 11 PSI/M	*RSX	1	SEP 82
RSX-11 PSI REFER	RENCE CARD	AV-H749A-TC-001	2.0	RSX 11 FSI/M	#RSX	1	SEF 82
RSX-11 PSI RELEA	SE NOTES	AA-H374A-10-001	2.0	RSX 11 PSI/H	*F:SX	1	SEF 82
RSX-11 PSI SYSTE	EN MANAGER'S GUIDE	AA-M370A-TC-001	2.0	RSX 11 FSI/h	‡RSX	3	8FF 85
RSX-11 PSI USER	S GUIDE	AA-#371A-TC-001	2.0	RSX 11 PS1/H	*RSX	B Joe	YEF 32
RSX-11 FSI/M V2	0 SPB 10.42.0	AE-N141B-TC-001	2.0	RSX 11 FSI/M	*PSX	1	FER 84
RSX-11 SYS GENER	RATION AND INSTALLATION GDE	AA-H625C-TC-001	4.1	RSX-11h	*R5X	E.	K6 V0N

TITLE OF MANUAL	HART NUMBER REV LEVEL	VERSIUN	FRODUCT MANE	OFERATING SYSTEM	NUMBER OF FICHE	! PATE
RSX-11/3271 PE PROGRAMMER'S GUIDE	AA-C739B-TC-001	3.0	RSX 11H 3271 PROTOCOL EMULATOR	*883	# 3 6n	APF 83
RSX-11/3271 PE RELEASE MOTES V3.0	AA-H032U-TU-001	3.0	RSX 11M 3271 FR0T0C0L EMULATOR	FRSX	1	AFR 83
RSX-11/3271 PE SYSTEM MANAGER'S GUIDE	AA-C739C-TC-001	3.0	RSX 11h 3271 PROTOCOL EMULATOR	*RSX	4	AFR 83
RSX-11M BCP USER'S GUIDE	AA-N269A-TC-001	1.0	RCF	PSX		SEP 92
RSX-11M CROSS REFERENCE TABLE	AE-H778F-TC-001	4.1	RSX-11m	≯RSX		JUL 84
RSX-11M FEP AND FRP INSTALLATION/USRS GDE	AA-J303IHTC-001	1.2	RSX 11M F ENHANC PKG FUR MINC	#RSX	2	JAN 84
RSX-11H GUIDE TO WRITING AN I/O DRIVER	AA-2600E-TC-001	4.1	RSX-11M	#RSX	3	NOV 83
RSX-11H GUIDE TO WRITING 1/O DRIVER	AA-2400E-10-001	4.1	RSX-11S	#HSX	5	HOV 83
RSX-11H MINI REFERENCE	AV-5570E-TC-001	4.1	RSX-11M	<b>≭</b> RS /₁	٥	EB VUN
RSX-11M HIN1 REFERENCE	AV-5570E-TC-001	4.1	ESX-11S	*RSX	Ĭ.	800 83
REX-11M SYSTEM GENERATION/INSTALLATION GUIDE	AA-H625C-TC-001	4.1	RSX-11S	#RSX	5	NOV 83
RSX-11M V4.1 SPD 14.32.21	AE-3407V-TC-001	4.1	RSX-11H	*R5X	1	MAY 84
RSX-11M V4.1 SPD 14.35.20	AE-3407U-TC-001	4.1	RSX-11h	*RSX	1	FER 84
RSX-11M-H-PLUS 1/O DRIVERS REF MAN (UPD#1)	AA-L677A-TC-001	2.1	RSX-11M-PLUS	#R5X	5	NOV 83
RSX-I1M-H-PLUS HCR OP MANUAL (UPD#1)	AA-L678A-TC-001	2.1	RSX-11h-FLUS	#I:SX	5	NOV 33
RSX-11M-H-PLUS SYSTEM MANAGEMENT GDE (UPD+1)	AA-L679K-TC-001	2.1	RSX-11M-PLU3	#R5Y	6	NOA 83
RSX-11M-N-PLUS TASK BUILDER MANUAL	AA-L680B-TC-001	2.1	RSX-11M-PLUS	#FSX	5	NOV 83
RSX-11M-MLUS GUIDE TO WRITING I/O IRIVER	AA-H267H-TC-001	2.1	RSX-11 <del>H</del> -PLUS	*RSY.	4	NOV 83
RSX-11M-PLUS INFORMATION DIRECTORY AND INDEX	AA-H426C-TC-001	2.1	RSX-11M-PLUS	*#8Y	4	NIJ!! 83
RSX-11H-PLUS HINI REFERENCE	AV-H435C-TE-001	2.1	RSX-11M-PLUS	*FSX	3	NOV 83
RSX-11M-PLUS SYSTEM GEN/INSTALLATION GUIDE	AA-H431C-TC-001	2.1	RSX-11M-PLUS	*RSX	3	NU7 83
RSX-11M-PLUS V2.1 CROSS REFERENCE SPD	AE-M779I-10-001	2.1	RSX-11M-FLUS	#RSY	1	MAY 84
RSX-11M-PLUS V2.1 RELEASE MOTES	AA-H427C-1C-001	2.1	RSX-11M-PLUS	#85 (	1	ES VUK
RSX-11M-PLUS V2.1 SPD 14.70.08	AE-H8621-TC-001	2.1	RSX-11M-PLUS	THSX.	1	FEE R4
RSX-11M-PLUS V2.1 SPD 14.70.09	AE-HS621-TU-001	2.1	RSX-11h-PLUS	HRSY		JUL 84
RSX-11M/11S INFORMATION DIRECTORY/INDEX	AA-2593G-10-001	4.1	RSX-11H	HET	4	407 83

TITLE OF MANUAL	PART NUMBER REV LEVEL	VERS10N	PROLUCT NAME	OPENATINU SYSTEM		
RSX-11M/11S V4.1 UPDATE B INFORMATION	AA-W259B-[C-001	4,1	RSX-119	<b>1</b> 65.X	1	FEE 84
RSX-11M/11S V4.1 UPDATE C INFORMATION	AA-W259C-1C-001	4.1	RSX-11S	ARSY.	1	MAY 84
RSX-11N/FEP V1.2 SPD 14.44.4	AE-L/62E-TC-001	1.2	RSX 11M F ENHANC FKG FOR HINC	†RS):	1	FER 84
RSX-11M/H+ BATCH AND QUEUE OFER MANUAL	AA-L671A-10-001	2.1	RSX-11H-PLUS	*FSX	<u>}</u>	NOV 83
RSX-11M/H+ COMMAND LANGUAGE MANUAL	AA-L672D-FC-001	2.1	RSX-11M-PLUS	#RSX	6	NOV 83
RSX-11M/H+ CRASH DUMP ANZ REF MANUAL	AA-L673R-10-001	4.1	RSX-11H	#FSX	3	400 RZ
RSX-11M/M+ CRASH DUMP ANZ REF MANUAL	AA-L673R-TC-001	2.1	RSX-11H-FLUS	<b>‡</b> £5X	3	NOV 83
RSX-11M/H+ CRASH DUMP ANZ REF MANUAL	AA-L673B-TC-001	4.1	RSX-11S	#FSX	3	NOV 83
RSX-11M/N+ GUIDE TO PROGRAM DEVELOPMENT	AA-L576A-TC-001	2.1	RSX-11h-PLUS	#P5%	2	NOV 83
RSX-11M/M+ I/O DIRVERS REF MANUAL (UPD#1)	AA-L677A-TC-001	4.1	RSX-115	*FBX	6	409 83
RSX-11M/H+ I/O DRIVERS REF HAN (UPD#1)	AA-L677A-TC-001	4.1	RSX-11h	*FSX	6	NUV 83
RSX-11M/H+ HCR OPERATIONS HANUAL (UFD#1)	AA-L678A-10-001	4.1	RSX-11M	TRSX	5	83 VON
RSX-11H/H+ SYSTEM MANAGEMENT GDE (UPD+1)	AA-L679R-TC-001	4.1	RSX-11H	#RSX	6	NOV 33
RSX-11M/H+ SYSTEM MANAGEMENT GUIDE (UPD#1)	AA-L679E-TE-001	4.1	RSX-115	#HSX	6	NUV 83
RSX-11M/M-PLUS BATCH AND QUEUE OPERATIONS HAI	AA-L671A-TC-001	4.1	RSX-11M	<b>*</b> FS);	2	NUV 83
RSX-11M/M-PLUS COMKAND LANGUACE MANUAL	AA-L6728-1C-001	4,1	RSX-11H	#F5X	6	NO0 83
RSX-11H/H-PLUS ERROR LOGGING HANUAL	AA-L6748-TC-001	4.1	RSX-11m	#RSX	7	MCh 81
RSX-11M/M-PLUS ERROR LOGGING MANUAL	AA-L674B-TC-001	2.1	RSX-11M-PLUS	#RSX	2	HCA 83
RSX-11N/H-PLUS EXECUTIVE REFERENCE MANUAL	AA-L675A-10-001	4.1	RSX-11M	<b>1</b> PS1	4	NOA 83
RSX-11M/M-PLUS EXECUTIVE REFERENCE MANUAL	AA-L675A-TC-001	2.1	RSX-11M-PLUS	*RSX	-Î	NOV 83
RSX-11H/H-PLUS EXECUTIVE REFERENCE MANUAL	AA-L675A-TC-001	4.1	RSX-11S	*R5 <	q	E8 VIGH
RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	AA-L676A-TL-001	4.1	RSX-11M	AF5X	"]; 4-	MON 83
RSX-11M/N-PLUS GUIDE TO PROGRAM DEVELOPMENT	AA-L676A-TC-001	4.1	RSX-115	<b>*</b> FS7	6	E3 NCA
RSX-11M/M-PLUS INSTALLATION/RELEASE HOTES	AA-m181C-1C-001	2.0	COROL-81/RSX	TRSX	1	JAN E4
RSX-11H/H-PLUS HCR OPERATIONS MANUAL (UPD41)	AA-L578A-10-001	4.1	RSX-115	<b>1</b> 881	(1)	MB0 81
RSX-11M/M-PLUS RMS-11 UTILITIES MANUAL	AA-L670A-TC-001	1.0	PROFESSIONAL HOST TOOL NIT	<b>NEED</b>	3	HAT 54

TIILE OF KANUAL	PART NUMBER REV LEVEL	VERSION		PRODUCT MAME	OPERATING SYSTEM	NLMEER UF FILHE	DATE
RSX-11M/M-PLUS TASK BLDR MANUAL (UPD#1)	AA-L6808-TC-001	4.1	RSX-11h		1RSX	5	NO: 83
RSX-11M/M-PLUS TASK BUILDER MANUAL	AA-L680R-TC-001	4.1	RSX-11S		#RSX	5	NOV 83
RSX-11H/H-PLUS TASK BUILDER MANUAL	AA-L6808-TC-001	1.0	PROFESSIONAL	HOST TOOL KIT	*RSX	5	JAN 84
RSX-11M/H-PLUS USER'S GUIDE	AA-H179B-TU-001	2.0	COPOL-81/RSX		FRSX	5	JAN 84
RSX-11M/M-PLUS USER'S GUIDE	AA-H179R-TC-001	2.1	PROFESSIONAL	100L KIT COROL-81	*RSX		JUL 84
RSX-11M/M-PLUS UTILITIES MANUAL (UPIN+1)	AA-L681A-TC-001	4.1	E3X-11M		TRSX	6	NOV 83
RSX-11M/M-PLUS UTILITIES MANUAL (UPD#1)	AA-L681A-FC-001	2.1	RSX-11M-FLUS	5	*FSX	É	NUV 83
RSX-11H/RSX-11S INFORMATION DIRECTORY & INDEX	AA-2593G-TC-001	4.1	ESX-11S		<b>V</b> ESX	4	MON 83
RSX-11H/RSX-11S RELEASE NOTES	AA-2573H-TC-001	4.1	RSX-11n		##SX	2	MOV 83
RSX-11M/RSX-11S RELEASE NOTES	AA-2573H-TC-001	4.1	RSX-115		#RSX	2	10v 83
RSX-11S SYS GEN/INSTL GDE (INCLUDES UPD#1)	AA-2874E-IC-001	4.1	R\$X-119		*RSX	2	NOV 83
RSX-115 V4.1 SPD 09.21.14	AE-34270-1C-001	4.1	RSX-11S		175X	1	MAY E4
RSX-115 V4.1 SPD 9.21.13	AE-3427N-TC-001	4.1	RSX-11S		*R5).	1	FEB 84
RSX-DECMET REFERENCE GUIDE	AA-M097A-TC-001	3.1	DECNET-11H		#RSX	1	FEE 84
RSX/RMS USER'S GUIDE	AA-L669A-TC-001	1.0	PROFESSIONAL	HOST TOOL KIT	*RSX	2	MAY 84
RSX/VAX/VMS FORTRAN IV USER'S GUIDE	AA-R955A-TK-001	2.6	FORTRAN 1V/KS	B)X	1PSY	2	JAN 84
RSX/VMS CORAL-66 USER'S GUDE	AA-D112C-TK-001	4.0	CORAL-66		<b>7</b> RS (	4	APK 83
RSX/VHS FORTRAN IV INSTALLATION/REL NTS	AA-R954A-TK-001	2.6	FORTRAN IV/RS	SX	*RSX	1	JAN 84
RSX11 2780/3780 EMUL V4.1 SFB 10.01.01	AE-K9978-TC-001	4.1	RSX 11 27807	3780 EMULATUR	*RSX	1	MAY 84
RSX11M IAS RJE/HASP V1.1 SPD 10.51.6	AE-5248G-1C-001	1.1	HSX 1 h 14S H	RJE/HASP	*RSY	1	FEB 84
RSX11H/H+ HDE/T11 SFTW INSTL GDE/REL NTS	AA-N998A-TC-001	1.0	RSX MDE/TII		≇RSX	1	APR 83
RSX11M/SNA PE APPLICATIONS PROGRAMMER'S GUIDE	AA-5503R-10-001	1.1	RSX 11M SNA I		*RSX	2	SEF 82
RSX11M/SNA PE CONCEPTS AND FACILITIES (UPD#1)	AA-5501A-TC-001	1.1	RSX 11m SNA F	F·E	TREX	2	275 85
RSX11M/SNA PE RELEASE NOTES (UPD#1)	AA-J549A-1C-001	1.1	RSX 11M SNA F	FE	\$F(\$X	1	SEF 82
RSX11H/SNA PE SYSTEM MANAGER'S GUIDE (UPD#1)	AA-5502A-TC-001	1 - 1	RSX 11h SMA F	). [	A Plant	2	967 82
RTCA-11 INSTALLATION GUIDE	AA-N436B-TK-001	2.0	ETEM-11		168X	1	15/1 54

TITLE OF	PART NUMBER REV		ecopiic t	NUMBER OPERATING OF		
HANUAL	LEVEL	VERSION	PRODUCT NAME	SYSIEM	FICHE	DAIL
RTEM-11 INSTL GUIDE/RELEASE NOTES (UFD#1)	AA-N436A-TK-001	1.1	RTEH-11	#RSY	2	JAN 84
RTEM-11 RELEASE NOTES	AA-W325A-TK-001	2.0	RTEM-11	*PSX	1	hAY 94
RTEM-11 USER'S GUIDE	AA-N435C-TK-001	2.0	RTEH-11	*R5X	2	MAY 84
RTEN-11 USER'S MANUAL	AA-N4358-TK-001	1.1	RTEM-11	#REX	2	JAN 84
RTEH-11 V2.0 SP0 30.21.04	AE-N571E-TK-001	2.0	RTEM-11	*RSX	1	HAY 84
SCIENTIFIC SUB PROGRAMMER'S REF MAN (UPI#1)	AA-11018-TC-601	1.3	SSF-11	*RSX	?	SEP 82
SCIENTIFIC SUBROUTINES PROG REF HAN (UPD#1)	AA-1101B-TC-001	1.1-1.2	RSX 11M F ENHANC PKG FOR HINC	tRSX	2	AFR 93
SORT-11 V2.0 SPD 12.7.5	AE-5429G-TC-001	2.0	SORT-11	*RSX	1	FEB: 84
SSP REFERENCE MANUAL ERRATA SHEET	AV-V189A-TC-001	1.2	RSX 11h F ENHANC PKG FOR MINC	*RSX	1	JAN 84
SSP-11 V1.3 SPD 15.45.10	AE-3413I-TC-001	1.3	SSP-11	#RSX	1.	MAY 84
SSP-11 V1.3 SPD 15.45.9	AE-3413H-TC-001	1.3	\$\$P-11	*RSX	1	FER 84
TERMINAL SUBSYSTEM MANUAL	AA-N623R-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	KRSX	2	JAN 84
TOOL KIT DOCUMENATION DIRECTORY	AA-N615C-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	<b>≭</b> ₹5×	1	MAY 84
TOOL KIT DOCUMENTATION DIRECTORY	AA-N615B-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	#RSX	1	JAN 84
TOOL KIT USER'S GUIDE	AA-N617C-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	*RSX	3	MAY 84
UN1004 V2.0 SPD 10.79.06	AE-3454G-TC-001	2,0	UN1004	#RSX	1	FEB 84
UN1004/RSX RELEASE NOTES	AA-1341C-TC-001	2.0	UN1004	#RSX	1	SEP 82
UH1004/RSX USRS GDE/SYS GEN GDE (UPD#1)	AA-1342B-10-001	2.0	UN1004	*RSX	1	SEF 82
USING THE DATATRIEVE-11/DBMS-11 INTERFACE	AA-K887B-TC-001	2.0-2.1	DBMS-11	*RSX	1	SEF 82
VOLUME I GENERAL INFORMATION	AA-X919A-TC-001	4.0	DECNET-11K	*RSX		JUL 84
VOLUME II USER'S INFORMATION	AA-X920A-TC-001	4.0	DECNET-11h	#R5X		JUL 84
VOLUME 111 GEN/INSTALLATION INFORMATION	AA-X921A-TC-001	4,0	DECNET-11H	*PSX		JUL 84
VOLUME IV SYSTEM MANAGEMENT INFORMATION	AA-X922A-TC-601	4.0	DECNET-11M	<b>1</b> 653		JUL 84
VSV11-H SOFTWARE BRIVER GUIDE	AA-J287B-TK-001	2.0	VSV11-M DRIVER	#PSY	1	SEF 32
VSV11-H SOFTWARE DRIVER GUIDE	AA-J287C-TK-001	2.1	VSV11-M DRIVER	*RSX		JUL 84
VSV11-H V2.0 RELEASE NOTES	AA-M615A-TC-001	2.0	USV11-M DRIVER	#R\$Y	1	JAN BA

TITLE OF MANUAL	PART NUMBER REV LEVEL	VERS10H	PRODUCT NAME	OPERALING SYSTEM	MUMBER U.F. FICHE	DATE
VSV11-h V2.1 SPD 14.53.03	AE-K851II-TC-001	2.1	VSVII-h DRIVER	#RSX	1	FEB 84
VTV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY	AA-H809A-TC-001	1.0	VTV31-K RSX11H DRIVE/SUB PKG	#FSX	1	APR 83
VTV31-K/RSX V1.0 SPD 14.73.0	AE-P079A-TC-001	1.0	VTV31-K RSXIIM DRIVE/SUB PKG	*RSX	1	FEE 84